

# Manual

Distributed network components protection & control  
EuroProt+/DTIVA


## E9-FEEDER

## VERSION INFORMATION

| NAME  | DOCUMENT ID  | VERSION | DATE       |
|---|--------------|---------|------------|
| EuroProt+ DTIVA type  | PP-13-21885  | 1.1     | 2020-02-21 |
| EuroProt+ Hardware description  | PP-13-19958  | 2.0     | 2023-02-10 |
| Definite time undervoltage protection function  | PP-13-21403  | 1.1     | 2017-01-11 |
| Directional overpower protection function   | PP-13-22276  | 2.0     | 2021-01-06 |
| Directional underpower protection function  | PP-13-22277  | 2.0     | 2021-01-06 |
| Broken conductor protection   | PP-13-22162  | 1.1     | 2020-06-29 |
| Breaker failure protection  | PP-13- 22253 | 2.1     | 2022-10-03 |
| Three-phase overcurrent protection  | PP-13-21408  | 2.4     | 2022-08-22 |
| Residual overcurrent protection   | PP-13-20320  | 1.3     | 2022-08-22 |
| Definite time overvoltage protection function   | PP-13-21400  | 1.2     | 2017-01-11 |
| Residual definite time overvoltage protection function                                  | VERSION 1.0  | 1.0     | 2011-06-27 |
| Overfrequency protection function   | PP-13-21379  | 2.2     | 2021-07-30 |
| Underfrequency protection function  | PP-13-21379  | 2.2     | 2021-07-30 |
| Rate of change of frequency function  | PP-13-21385  | 2.1     | 2020-02-11 |
| <u>Vector jump protection function</u>  | VERSION 1.0  | 1.0     | 2013-01-17 |
| Phase-Selective Trip Logic  | PP-13-21531  | 2.0     | 2019-03-12 |
| Circuit breaker wear monitoring   | PP-13-21310  | 1.1     | 2016-09-06 |
| Circuit Breaker control   | PP-13-21877  | 2.0     | 2019-04-01 |
| Disconnecter control  | PP-13-20396  | 2.0     | 2019-04-01 |
| Ethernet Links function   | PP-13-21870  | 1.0     | 2019-02-19 |
| Trip Circuit Supervision (TCS)  | PP-13-21875  | 1.2     | 2019-08-09 |
| Application of high-speed TRIP contacts   | PP-13-21592  | 1.1     | 2017-10-02 |
| Dead Line Detection Function  | PP-13-22522  | 2.0     | 2022-03-04 |
| Voltage transformer supervision and dead line detection                                 | VERSION 1.1  | 1.1     | 2011-10-25 |
| Current unbalance function  | PP-13-22163  | 2.0     | 2020-06-25 |
| Current input function block setting guide  | VERSION 1.1  | 1.0     | 2015-01-29 |
| Voltage input function block setting guide  | VERSION 1.0  | 1.0     | 2015-01-29 |
| Line measurement<br>Frequency measurement<br>Voltage measurement<br>Current measurement | PP-13-21168  | 2.3     | 2021-09-02 |
| Disturbance recorder  | PP-13-20368  | 3.0     | 2017-06-02 |
| Average and maximum measurement function  | PP-11-20109  | 1.0     | 2013-09-27 |
| Metering function   | PP-13-22238  | 2.1     | 2022-10-19 |
| Trip value recorder function  | PP-13-20947  | 2.1     | 2020-12-10 |
| Voltage measurement selection function  | VERSION 1.0  | 1.0     | 2013-02-06 |
| Distance protection function setting guide  | VERSION 1.1  | 1.0     | 2015-06-12 |
| Automatic reclosing function for high voltage networks setting guide                    | PP-13-21370  | 1.2     | 2017-02-08 |
| Setting guide to the directional overcurrent protection                                 | -            | 1.0     | 2014-10-21 |
| AIC current input function  | PP-13-21392  | 1.0     | 2017-01-03 |
| Remote I/O (RIO) server description   | PP-13-22346  | 1.0     | 2021-06-02 |
| Technical notes on EOB interoperability   | -            | 1.0     | 2011-06-27 |




|  |                     |            |                   |
|--|---------------------|------------|-------------------|
| <a href="#">Maintenance guide</a>              | <b>PP-13-226045</b> | <b>2.0</b> | <b>2022-11-18</b> |
| <a href="#">RTD temperature input function</a> | <b>PP-13-21394</b>  | <b>1.0</b> | <b>2017-01-03</b> |
| <a href="#">EP+ Installation manual</a>        | <b>PP-06-22516</b>  | <b>1.0</b> | <b>2022-03-09</b> |




## Table of Contents

|   |     |
|---|-----|
| 1. Introduction .....   | 6   |
| 1.1. Application.....   | 6   |
| 1.1.1. General features .....                                       | 6   |
| 1.2. Pre-defined configuration variants .....                       | 7   |
| 1.2.1. Meeting the device .....                                     | 8   |
| 1.2.2. System design.....   | 9   |
| 1.2.3. CPU and COM module .....                                     | 10  |
| 1.2.4. Device housings .....  | 30  |
| 1.2.5. Human-Machine Interface (HMI) module .....                   | 32  |
| 1.2.6. Current input module .....                                   | 39  |
| 1.2.7. Voltage input module.....                                    | 44  |
| 1.2.8. Binary input module.....                                     | 46  |
| 1.2.9. Signaling module .....                                       | 49  |
| 1.2.10. Tripping module.....  | 52  |
| 1.2.11. RTD input module.....                                       | 73  |
| 1.2.12. Analog input module (AI) .....                              | 75  |
| 1.2.13. Analog output module (ATO) .....                            | 77  |
| 1.2.14. Sensor input module.....                                    | 79  |
| 1.2.15. INJ module.....   | 81  |
| 1.2.16. Generator protection modules .....                          | 82  |
| 1.2.17. Power supply module.....                                    | 85  |
| 1.2.18. Sampling synchronization module.....                        | 89  |
| 1.2.19. Mixed function modules .....                                | 90  |
| 1.2.20. General data.....   | 100 |
| 1.2.21. Mechanical data.....  | 102 |
| 1.2.22. Mounting methods.....                                       | 105 |
| 1.2.23. Product availability (special and obsolete modules) .....   | 125 |
| 1.2.24. Remote I/O (RIO) server description.....                    | 130 |
| 1.2.25. Technical notes on EOB interoperability.....                | 139 |
| 1.2.26. EP+ Installation manual.....                                | 142 |
| 2. Function and I/O listing.....                                    | 150 |
| 3. Software configuration .....                                     | 152 |
| 3.1. Protection functions .....                                     | 152 |
| 3.1.1. Definite time undervoltage protection function .....         | 152 |
| 3.1.2. Directional over-power protection function.....              | 160 |
| 3.1.3. Directional under-power protection function.....             | 166 |
| 3.1.4. Broken conductor protection.....                             | 172 |
| 3.1.5. Breaker failure protection .....                             | 180 |
| 3.1.6. Three-phase time overcurrent protection .....                | 189 |
| 3.1.7. Residual overcurrent protection function.....                | 205 |
| 3.1.8. Definite time overvoltage protection function .....          | 214 |
| 3.1.9. Residual definite time overvoltage protection function ..... | 223 |
| 3.1.10. Over-frequency protection function.....                     | 230 |
| 3.1.11. Underfrequency protection function .....                    | 234 |
| 3.1.12. Rate of change of frequency protection function.....        | 238 |
| 3.1.13. Vector jump protection function .....                       | 242 |
| 3.2. Control & supervision functions.....                           | 249 |





|        |   |     |
|--------|---|-----|
| 3.2.1. | Phase-Selective Trip Logic .....                                    | 249 |
| 3.2.2. | Circuit breaker wear monitoring function.....                       | 253 |
| 3.2.3. | Circuit breaker control function block .....                        | 258 |
| 3.2.4. | Disconnecter control function.....                                  | 264 |
| 3.2.5. | Ethernet Links function.....  | 271 |
| 3.2.6. | Trip Circuit Supervision .....                                      | 274 |
| 3.2.7. | Dead Line Detection Function .....                                  | 281 |
| 3.2.8. | Voltage transformer supervision function.....                       | 290 |
| 3.2.9. | Current unbalance function.....                                     | 305 |
| 3.3.   | Measuring functions .....   | 311 |
| 3.3.1. | Current input function .....  | 313 |
| 3.3.2. | AIC current input function.....                                     | 318 |
| 3.3.3. | Voltage input function .....  | 320 |
| 3.3.4. | Line and frequency measurement functions .....                      | 328 |
| 3.3.5. | Average and maximum measurement function.....                       | 338 |
| 3.3.6. | Metering .....  | 340 |
| 3.3.7. | Voltage selection function block.....                               | 346 |
| 3.3.8. | Trip Value Recorder .....   | 348 |
| 3.3.9. | RTD temperature input function.....                                 | 351 |
| 3.4.   | Disturbance recorder function .....                                 | 354 |
| 3.4.1. | Mode of recording.....  | 354 |
| 3.4.2. | Format of recording.....  | 355 |
| 3.4.3. | Downloading and evaluating the disturbance records .....            | 355 |
| 3.4.4. | Parameters of the disturbance recorder functions.....               | 355 |
| 3.4.5. | The input signals of the disturbance recorder functions .....       | 356 |
| 3.4.6. | The function blocks .....   | 356 |
| 3.4.7. | The recorded signals.....   | 356 |
| 3.5.   | Event recorder .....  | 357 |
| 4.     | Maintenance guide for EuroProt+ devices .....                       | 358 |
| 4.1.   | Foreword .....  | 358 |
| 4.2.   | Safety precautions .....  | 358 |
| 4.2.1. | General guidelines for a scheduled maintenance of EP+ devices ..... | 359 |
| 4.3.   | Power supply maintenance.....                                       | 360 |
| 4.4.   | Elements and Batteries .....  | 362 |



## 1. Introduction

The **DTIVA** product type is a member of the **EuroProt+** product line, made by Protecta Co. Ltd. The **EuroProt+** complex protection in respect of hardware and software is a modular device. The modules are assembled and configured according to the requirements, and then the software determines the functions. This manual describes the **DTIVA** product type.

### 1.1. Application

The **DTIVA** products are configured to protect, control and supervise elements of the utility and industrial distribution systems, including radial, looped and meshed distribution networks.

The main application fields of the **DTIVA** type are the not solidly grounded radial networks. Here the application of Petersen coils or grounding resistances results relatively low currents in case of single phase-to-ground faults. The majority of the protections are based on current measurements only, but the application of distributed generation or loops in the network topology require additional voltage measurement and directional protection functions.

The relays of this type support double breaker terminals such as breaker and a half or ring bus topology.

The main protection functions of the **DTIVA** type include directional and non-directional overcurrent protections, voltage-based protections and frequency-based protections

The MV automatic reclosing function (wherever present) provides multi-shot autoreclosing with a synchro-check feature. The dead times and shot numbers can be set individually for earth faults and phase faults.

Additionally, the **DTIVA** product type includes a variety of versatile protection functions, such as high-speed distance protection with five independent protection zones and line differential protection.


More specialized applications, such as MV motor protection and capacitor bank protection, are also covered in this type by dedicated configuration variants.

Because of the implemented control, measuring and monitoring function, the IEDs can also be used as a bay control unit.

The **EuroCAP configuration tool**, which is available free of charge, offers a user-friendly and flexible application for protection, control and measurement functions to ensure that the IED-EP+ devices are fully customizable.

#### 1.1.1. General features

- Native IEC 61850 IED with Edition 2 compatibility
- Scalable hardware to adapt to different applications
- 84 HP or 42HP wide rack size (height: 3U)
- The pre-defined factory configuration can be customized to the user's specification with the powerful EuroCAP tool
- Flexible protection and control functionality to meet special customer requirements
- Advanced HMI functionality via color touchscreen and embedded WEB server, extended measuring, control and monitoring functions
- User configurable LCD user screens, which can display SLDs (Single Line Diagrams) with switchgear position indication and control as well as measuring values and several types of controllable objects.
- Various protection setting groups available
- Enhanced breaker monitoring and control
  
- High capacity disturbance recorder (DRE) and event logging (data is stored in non-volatile memory):



- DRE for up to 32 analogue and 64 digital signal channels.
- Event recorder can store more than 10,000 events.
- Several mounting methods: Rack; Flush mounting; Semi-flush mounting; Wall mounting; Wall-mounting with terminals; Flush mounting with IP54 rated cover.
- Wide range of communication protocols:
  - Ethernet-based communication: IEC61850; IEC60870-5-104; DNP3.0 TCP; Modbus TCP
  - Serial communication: DNP3.0; IEC60870-5-101/103; MODBUS, SPA
- The EuroProt+ family can handle several communication protocols simultaneously.
- Built-in self-monitoring to detect internal hardware or software errors
- Different time sources available: NTP server; Minute pulse; Legacy protocol master; IRIG-B000 or IRIG-B12X

## 1.2. Pre-defined configuration variants

The number and the functionality of the members of each product type is put together according to the application philosophy, keeping in mind the possible main usages. The available configurations of the DTIVA type are listed in the table below.

| VARIANT           | MAIN APPLICATION   |
|-------------------|--|
| <b>E1-Feeder</b>  | Non-directional 3ph+Io overcurrent protection, control & automation                            |
| <b>E2-Feeder</b>  | Non-directional three-phase, directional residual overcurrent protection, control & automation |
| <b>E3-Feeder</b>  | Directional 3ph+Io overcurrent, over- undervoltage, frequency protection & autorecloser        |
| <b>E4-Feeder</b>  | MV distance protection, control & automation   |
| <b>E5-Feeder</b>  | Line differential protection, control & automation   |
| <b>E6-Feeder</b>  | Combined MV distance and line differential protection, control & automation                    |
| <b>E7-Feeder</b>  | Motor protection   |
| <b>E8-Feeder</b>  | Frequency and over- undervoltage protection  |
| <b>E9-Feeder</b>  | Vectorjump, over- and underpower and frequency protection                                      |
| <b>E10-Feeder</b> | Capacitor bank protection  |

Table 1-1 The members of the DTIVA type

### 1.2.1. Meeting the device

The basic information for working with the **EuroProt+** devices are described in the document “**Quick start guide to the devices of the EuroProt+ product line**”.



*Figure 4 The 84 inch rack of **EuroProt+** family*



*Figure 5 The 42 inch rack of **EuroProt+** family*

## 1.2.2. System design

The EuroProt+ protection device family is a scalable hardware platform to adapt to different applications. Data exchange is performed via a 16-bit high-speed digital non-multiplexed parallel bus with the help of a backplane module.

Each module is identified by its location and there is no difference between module slots in terms of functionality. The only restriction is the position of the CPU module because it is limited to the “CPU” position. The built-in self-supervisory function minimizes the risk of device malfunctions.





Figure 1-1 CPU block diagram

The backplane board itself is a passive board but it provides a 16-bit bus, power supply distribution, a two-wire interface (TWI) supporting module inventory management and module identification. It is designed to meet the requirements for high-speed digital buses and to comply with electromagnetic emission standards.





### 1.2.3. CPU and COM module

#### 1.2.3.1. CPU+ module

The CPU module contains all the protection, control and communication functions of the EuroProt+ device. Dual 500 MHz high-performance Analog Devices Blackfin processors separate relay functions (RDSP) from communication and HMI functions (CDSP). Reliable communication between processors is performed via high-speed synchronous serial internal bus (SPORT).

Each processor has its own operative memory such as SDRAM and flash memories for configuration, parameter and firmware storage. Both firmwares are stored in a dedicated flash memory independent from the disturbance recorder and event storage.

The CDSP's operating system (uClinux) utilizes a robust JFFS flash file system, which enables fail-safe operation and the storage of disturbance record files, configuration and parameters.

The RDSP core runs at 500 MHz and its external bus speed is 125 MHz. The backplane data speed is limited to approx. 20 MHz, which is more than enough for module data throughput. An additional logic element (CPLD and SRAM) is used as a bridge between the RDSP and the backplane. The CPLD collects analogue samples from CT/VT modules and also controls signaling outputs and inputs.



### 1.2.3.1.1. Fast start-up

After power-up the RDSP processor starts up with the previously saved configuration and parameters. Generally, the power-up procedure for the RDSP and relay functions takes only a few seconds. That is to say, it is ready to trip within this time. CDSP's start-up procedure is longer because its operating system needs time to build its file system, initializing user applications such as HMI functions and the IEC61850 software stack.

### 1.2.3.1.2. HMI and communication tasks

- Embedded WEB-server:
  - Firmware upgrade possibility
  - Modification of user parameters
  - Events list and disturbance records
  - Password management
  - Online data measurement
  - Commands
  - Administrative tasks
- Front panel TFT display handling: the interactive menu set is available through the TFT and the touchscreen interface
- User keys: capacitive touch keys on front panel
- The built-in 5-port Ethernet switch allows EuroProt+ to connect to IP/Ethernet-based networks. The following Ethernet ports are available:
  - Station bus (100Base-FX Ethernet) SBW
  - Redundant station bus (100Base-FX Ethernet) SBR
  - Process bus (100Base-FX Ethernet)
  - EOB2 (Ethernet Over Board) or RJ-45 Ethernet user interface on front panel
  - Optional 10/100Base-T port via RJ-45 connector
- PRP/HSR seamless redundancy for Ethernet networking (100Base-FX Ethernet)
- Other communication:
  - RS422/RS485 interfaces (galvanic interface to support legacy or other serial protocols, ASIF)
  - Plastic or glass fiber interfaces to support legacy protocols, ASIF
  - Proprietary process bus communication controller on COM+ module
  - Telecommunication interfaces: G.703, IEEE C37.94



| CPU VERSION | PRIMARY STATION BUS SBW | SECONDARY (REDUNDANT) STATION BUS SBR | LEGACY PORT/PROTOCOL | PROCESS BUS (FIBER) PB | SERVICE PORT ON FRONT PANEL EOB/ RJ45 |
|-------------|-------------------------|---------------------------------------|----------------------|------------------------|---------------------------------------|
| CPU+/0007   | -                       | -                                     | -                    | -                      | +                                     |
| CPU+/0091   | -                       | -                                     | -                    | + SM SH                | +                                     |
| CPU+/0201*  | -                       | + RJ45                                | -                    | -                      | +                                     |
| CPU+/0211*  | -                       | + RJ45                                | -                    | + MM                   | +                                     |
| CPU+/0281*  | -                       | + RJ45                                | -                    | + SM LH                | +                                     |
| CPU+/0291*  | -                       | + RJ45                                | -                    | + SM SH                | +                                     |
| CPU+/0301   | -                       | -                                     | + POF                | -                      | +                                     |
| CPU+/0401   | -                       | -                                     | + GS                 | -                      | +                                     |
| CPU+/0501*  | -                       | -                                     | + Galv. RS485/422    | -                      | +                                     |
| CPU+/1001   | + MM                    | -                                     | -                    | -                      | +                                     |
| CPU+/1004   | + MM                    | -                                     | -                    | -                      | +                                     |
| CPU+/1011   | + MM                    | -                                     | -                    | + MM                   | +                                     |
| CPU+/1091   | + MM                    | -                                     | -                    | + SM SH                | +                                     |
| CPU+/1101*  | + MM                    | + MM                                  | -                    | -                      | +                                     |
| CPU+/1111   | + MM                    | + MM                                  | -                    | + MM                   | +                                     |
| CPU+/1181   | + MM                    | + MM                                  | -                    | + SM LH                | +                                     |
| CPU+/1191   | + MM                    | + MM                                  | -                    | + SM SH                | +                                     |
| CPU+/1201*  | + MM                    | + RJ45                                | -                    | -                      | +                                     |
| CPU+/1202   | + MM                    | + RJ45                                | -                    | -                      | +                                     |
| CPU+/1211   | + MM                    | + RJ45                                | -                    | + MM                   | +                                     |
| CPU+/1281   | + MM                    | + RJ45                                | -                    | + SM LH                | +                                     |
| CPU+/1291*  | + MM                    | + RJ45                                | -                    | + SM SH                | +                                     |
| CPU+/1292   | + MM                    | + RJ45                                | -                    | + SM SH                | +                                     |
| CPU+/1301   | + MM                    | -                                     | + POF                | -                      | +                                     |
| CPU+/1311   | + MM                    | -                                     | + POF                | + MM                   | +                                     |
| CPU+/1331   | + MM                    | -                                     | + double POF         | -                      | +                                     |
| CPU+/1381   | + MM                    | -                                     | + POF                | + SM LH                | +                                     |
| CPU+/1391   | + MM                    | -                                     | + POF                | + SM SH                | +                                     |
| CPU+/1401   | + MM                    | -                                     | + GS                 | -                      | +                                     |
| CPU+/1411   | + MM                    | -                                     | + GS                 | + MM                   | +                                     |
| CPU+/1481   | + MM                    | -                                     | + GS                 | + SM LH                | +                                     |
| CPU+/1491   | + MM                    | -                                     | + GS                 | + SM SH                | +                                     |
| CPU+/1501   | + MM                    | -                                     | + Galv. RS485/422    | -                      | +                                     |
| CPU+/1511   | + MM                    | -                                     | + Galv. RS485/422    | + MM                   | +                                     |

| CPU VERSION       | PRIMARY STATION BUS (FIBER) SBW | SECONDARY (REDUNDANT) STATION BUS SBR | LEGACY PORT/PROTOCOL | PROCESS BUS (FIBER) PB | SERVICE PORT ON FRONT PANEL EOB/ RJ45 |
|-------------------|---------------------------------|---------------------------------------|----------------------|------------------------|---------------------------------------|
| <b>CPU+/1581</b>  | + MM                            | -                                     | + Galv. RS485/422    | + SM LH                | +                                     |
| <b>CPU+/1611</b>  | + MM                            | -                                     | + Galvanic sync      | + MM                   | +                                     |
| <b>CPU+/1681</b>  | + MM                            | -                                     | + Galvanic sync      | + SM LH                | +                                     |
| <b>CPU+/6001</b>  | + MM/LC                         | -                                     | -                    | -                      | +                                     |
| <b>CPU+/6004</b>  | + MM/LC                         | -                                     | -                    | -                      | +                                     |
| <b>CPU+/6093</b>  | + MM/LC                         | -                                     | -                    | + SM SH                | +                                     |
| <b>CPU+/6094</b>  | + MM/LC                         | -                                     | -                    | + SM SH                | +                                     |
| <b>CPU+/6601*</b> | + MM/LC                         | + MM/LC                               | -                    | -                      | +                                     |
| <b>CPU+/9201</b>  | + SM SH                         | + RJ45                                | -                    | -                      | +                                     |
| <b>CPU+/9291</b>  | + SM SH                         | + RJ45                                | -                    | + SM SH                | +                                     |
| <b>CPU+/9501</b>  | + SM SH                         | -                                     | + Galv. RS485/422    | -                      | +                                     |
| <b>CPU+/9901</b>  | + SM SH                         | + SM SH                               | -                    | -                      | +                                     |
| <b>CPU+/A001*</b> | + MM/LC PRP/HSR                 | -                                     | -                    | -                      | +                                     |
| <b>CPU+/A004</b>  | + MM/LC PRP/HSR                 | -                                     | -                    | -                      | +                                     |
| <b>CPU+/A011</b>  | + MM/LC PRP/HSR                 | -                                     | -                    | + MM                   | +                                     |
| <b>CPU+/A081</b>  | + MM/LC PRP/HSR                 | -                                     | -                    | + SM LH                | +                                     |
| <b>CPU+/A091</b>  | + MM/LC PRP/HSR                 | -                                     | -                    | + SM SH                | +                                     |
| <b>CPU+/A094</b>  | + MM/LC PRP/HSR                 | -                                     | -                    | + SM SH                | +                                     |

*\*Note: the modules can be equipped with a different handle (narrower and made of aluminum, instead of the standard plastic), if the other modules of the device are equipped with top-screw terminals (see Chapter 20.2). In these cases, a "T" letter appears on the label of the module (e.g. CPU+/1201T), but all other properties remain the same.*

For legacy CPU cards (e.g. CPU+0001, ...) see [Product availability](#) chapter.

**PRP/HSR** option: A and F types can be ordered with PRP/HSR communication as sw option **Legend for CPU version table:**

|   |   |
|---|---|
| <b>MM:</b> Multimode with ST connector                      | <b>GS:</b> Glass with ST connector                |
| <b>MM/LC:</b> Multimode with LC connector                   | <b>SFP:</b> Small Form-factor Pluggable connector |
| <b>SM:</b> Single mode with FC/PC connector                 | <b>SB:</b> Station Bus                            |
| <b>LH:</b> Long Haul with FC/PC connector                   | <b>SBW:</b> Station Bus Working                   |
| <b>SH:</b> Short Haul with FC/PC connector                  | <b>SBR:</b> Station Bus Redundant                 |
| <b>POF:</b> Plastic Optical Fiber with 1 mm fiber connector | <b>PB:</b> Proprietary Process Bus                |

|               |               |             |             |               |               |                 |              |               |   |   |
|---------------|---------------|-------------|-------------|---------------|---------------|-----------------|--------------|---------------|---|---|
| CPU+ 0007     | CPU+ 0091     | CPU+ 0201   | CPU+ 0211   | CPU+ 0281     | CPU+ 0291     | CPU+ 0301       | CPU+ 0401    | CPU+ 0501     | CPU+ 1001                                 | CPU+ 1004                                 |
|               |               |             |             |               |               |                 |              |               | MM/ST                                     | MM/ST                                     |
|               |               |             |             |               |               |                 |              |               | SB<br>                                    | SB<br>                                    |
|               |               | RJ-45       | RJ-45       | RJ-45         | RJ-45         | POF<br>Tx<br>Rx | GS/ST        | <br>ASIF<br>  | Tx+ 1<br>Tx- 2<br>GND 3<br>Rx- 4<br>Rx+ 5 |   |
|               | SM SH<br>FCPC |             | MM/ST       | SM LH<br>FCPC | SM SH<br>FCPC |                 |              |               |   |   |
|               | <br>PB<br>    |             | <br>PB<br>  | <br>PB<br>    | <br>PB<br>    |                 |              |               |   |   |
| CPU+ 1011     | CPU+ 1091     | CPU+ 1101   | CPU+ 1111   | CPU+ 1181     | CPU+ 1191     | CPU+ 1201       | CPU+ 1202    | CPU+ 1211     | CPU+ 1281                                 | CPU+ 1291                                 |
| MM/ST         | MM/ST         | MM/ST       | MM/ST       | MM/ST         | MM/ST         | MM/ST           | MM/ST        | MM/ST         | MM/ST                                     | MM/ST                                     |
| <br>SB<br>    | <br>SB<br>    | <br>SBW<br> | <br>SBW<br> | <br>SBW<br>   | <br>SBW<br>   | <br>SB<br>      | <br>SBW<br>  | <br>SB<br>    | <br>SB<br>                                | <br>SB<br>                                |
|               |               | MM/ST       | MM/ST       | MM/ST         | MM/ST         | RJ-45           | RJ-45        | RJ-45         | RJ-45                                     | RJ-45                                     |
| MM/ST         | SM SH<br>FCPC | <br>SBR<br> | <br>SBR<br> | <br>SBR<br>   | <br>SBR<br>   | <br>SBR<br>     |              | <br>SBR<br>   | <br>SBR<br>                               | <br>SBR<br>                               |
| <br>PB<br>    | <br>PB<br>    |             | <br>PB<br>  | <br>PB<br>    | <br>PB<br>    |                 | <br>PB<br>   | <br>PB<br>    | <br>PB<br>                                | <br>PB<br>                                |
| CPU+ 1292     | CPU+ 1301     | CPU+ 1311   | CPU+ 1331   | CPU+ 1381     | CPU+ 1391     | CPU+ 1401       | CPU+ 1411    | CPU+ 1481     | CPU+ 1491                                 | CPU+ 1501                                 |
| MM/ST         | MM/ST         | MM/ST       | MM/ST       | MM/ST         | MM/ST         | MM/ST           | MM/ST        | MM/ST         | MM/ST                                     | MM/ST                                     |
| <br>SBW<br>   | <br>SB<br>    | <br>SB<br>  | <br>SB<br>  | <br>SB<br>    | <br>SB<br>    | <br>SB<br>      | <br>SB<br>   | <br>SB<br>    | <br>SB<br>                                | <br>SB<br>                                |
| RJ-45         | POF           | POF         | POF1        | POF           | POF           | GS/ST           | GS/ST        | GS/ST         | GS/ST                                     | Tx+ 1<br>Tx- 2<br>GND 3<br>Rx- 4<br>Rx+ 5 |
|               | Tx<br>Rx      | Tx<br>Rx    | Tx<br>Rx    | Tx<br>Rx      | Tx<br>Rx      | <br>ASIF<br>    | <br>ASIF<br> | <br>ASIF<br>  | <br>ASIF<br>                              |   |
| SM SH<br>FCPC |               | MM/ST       | POF2        | SM LH<br>FCPC | SM SH<br>FCPC |                 | MM/ST        | SM LH<br>FCPC | SM SH<br>FCPC                             |   |
| <br>PB<br>    |               | <br>PB<br>  | Tx<br>Rx    | <br>PB<br>    | <br>PB<br>    |                 | <br>PB<br>   | <br>PB<br>    | <br>PB<br>                                |   |



|            |            |               |               |               |               |               |               |           |            |            |
|------------|------------|---------------|---------------|---------------|---------------|---------------|---------------|-----------|------------|------------|
| CPU+ 1511  | CPU+ 1581  | CPU+ 1611     | CPU+ 1681     | CPU+ 6001     | CPU+ 6004     | CPU+ 6093     | CPU+ 6094     | CPU+ 6601 | CPU+ 9201  | CPU+ 9291  |
| MM/ST      | MM/ST      | MM/ST         | MM/ST         | MM/LC         | MM/LC         | MM/LC         | MM/LC         | MM/LC     | SM SH FCPC | SM SH FCPC |
| (Tx)       | (Tx)       | (Tx)          | (Tx)          | Rx Tx         | Rx Tx         | Rx Tx         | Rx Tx         | Rx Tx     | (Tx)       | (Tx)       |
| SB         | SB         | SB            | SB            |               |               |               |               |           | SB         | SB         |
| (Rx)       | (Rx)       | (Rx)          | (Rx)          |               |               |               |               |           | (Rx)       | (Rx)       |
| Tx+ 1      | Tx+ 1      | -             | -             |               |               |               |               | MM/LC     |            |            |
| Tx- 2      | Tx- 2      | -             | -             |               |               |               |               | Rx Tx     | RJ-45      | RJ-45      |
| GND 3      | GND 3      | GND 3         | GND 3         |               |               |               |               |           |            |            |
| Rx- 4      | Rx- 4      | Sy- 4         | Sy- 4         |               |               |               |               |           |            |            |
| Rx+ 5      | Rx+ 5      | Sy+ 5         | Sy+ 5         |               |               |               |               |           |            |            |
| MM/ST      | SM LH FCPC | MM/ST         | SM LH FCPC    |               |               | SM SH FCPC    | SM SH FCPC    |           |            | SM SH FCPC |
| (Tx)       | (Tx)       | (Tx)          | (Tx)          |               |               | (Tx)          | (Tx)          |           |            | (Tx)       |
| PB         | PB         | PB            | PB            |               |               | PB            | PB            |           |            | PB         |
| (Rx)       | (Rx)       | (Rx)          | (Rx)          |               |               | (Rx)          | (Rx)          |           |            | (Rx)       |
| CPU+ 9501  | CPU+ 9901  | CPU+ A001     | CPU+ A004     | CPU+ A011     | CPU+ A081     | CPU+ A091     | CPU+ A094     |           |            |            |
| SM SH FCPC | SM SH FCPC | PRP/HSR MM/LC | PRP/HSR MM/LC | PRP/HSR MM/LC | PRP/HSR MM/LC | PRP/HSR MM/LC | PRP/HSR MM/LC |           |            |            |
| (Tx)       | (Tx)       | Rx Tx         | Rx Tx         | Rx Tx         | Rx Tx         | Rx Tx         | Rx Tx         |           |            |            |
| SB         | PB         | LAN A LAN B   | LAN A LAN B   | LAN A LAN B   | LAN A LAN B   | LAN A LAN B   | LAN A LAN B   |           |            |            |
| (Rx)       | (Rx)       | A B I         | A B I         | A B I         | A B I         | A B I         | A B I         |           |            |            |
| Tx+ 1      | SM SH FCPC | LINK/ACT      | LINK/ACT      | LINK/ACT      | LINK/ACT      | LINK/ACT      | LINK/ACT      |           |            |            |
| Tx- 2      | (Tx)       |               |               |               |               |               |               |           |            |            |
| GND 3      | PB         |               |               |               |               |               |               |           |            |            |
| Rx- 4      | (Rx)       |               |               |               |               |               |               |           |            |            |
| Rx+ 5      | (Rx)       |               |               |               |               |               |               |           |            |            |
|            |            |               |               | MM/ST         | SM LH FCPC    | SM SH FCPC    | SM SH FCPC    |           |            |            |
|            |            |               |               | (Tx)          | (Tx)          | (Tx)          | (Tx)          |           |            |            |
|            |            |               |               | PB            | PB            | PB            | PB            |           |            |            |
|            |            |               |               | (Rx)          | (Rx)          | (Rx)          | (Rx)          |           |            |            |

Figure 2-1 CPU versions

**Interface types:**

- 100Base-FX Ethernet:
  - MM/ST 1300 nm, 50/62.5/125 μm connector, (up to 2 km) fiber
  - SM/FC 1550 nm, 9/125 μm connector, (LH: long haul, up to 120 km)
  - SM/FC 1550 nm, 9/125 μm connector, (SH: short haul, up to 50 km)
  - MM/LC 1300 nm, 50/62.5/125 μm connector, (up to 2 km) fiber
- 10/100 Base-TX Ethernet: RJ-45-8/8
- Service port on HMI:
  - 10/100 Base-T Ethernet: RJ-45-8/8
  - EOB2 interface: attachable to the front panel by a proprietary magnetic connector; the connector box ends in a RJ-45 8/8 plug. It is 10Base-T full duplex interface, and it enables 10/100Base TX communication with service computers.
- ASIF: Asynchronous Serial Interface
  - plastic optical fiber (ASIF-POF)
  - glass with ST connector (ASIF-GS)
  - galvanic RS485/422 (ASIF-G)



### 1.2.3.2. COM modules

The COM+ modules are responsible for special communication tasks, these are the following:

- binary signal transmission
- line differential protection communication via Ethernet or telecommunication networks
- busbar differential protection communication
- multi-port Ethernet switch using MODBUS/TCP protocol for Remote I/O (RIO) servers

### 1.2.3.2.1. COM modules for binary signal transmission

| MODULE TYPE       | INTERFACE TYPE  | NUMBER OF INTERFACES | UNIT WIDTH | APPLICATION   |
|-------------------|---|----------------------|------------|---|
| <b>COM+/1801*</b> | MM/ST 1300 nm,<br>50/62.5/125 μm and<br>SM/FC 1550 nm,<br>9/125 μm<br>connector,<br>100Base-FX Ethernet | 2                    | 4 HP       | Line differential protection,<br>binary signal transmission<br>up to 2 km and<br>up to 120 km |
| <b>COM+/1901*</b> | MM/ST 1300 nm,<br>50/62.5/125 μm and<br>SM/FC 1550 nm,<br>9/125 μm<br>connector,<br>100Base-FX Ethernet | 2                    | 4 HP       | Line differential protection,<br>binary signal transmission<br>up to 2 km and<br>up to 50 km  |
| <b>COM+/8882</b>  | SM/FC 1550 nm,<br>9/125 μm<br>connector,<br>100Base-FX Ethernet   | 3                    | 4 HP       | 3 direction<br>binary signal transmission<br>up to 120 km                                     |
| <b>COM+/9902</b>  | SM/FC 1550 nm,<br>9/125 μm<br>connector,<br>100Base-FX Ethernet   | 2                    | 4 HP       | 2 direction<br>binary signal transmission<br>up to 50 km                                      |
| <b>COM+/9992</b>  | SM/FC 1550 nm,<br>9/125 μm<br>connector,<br>100Base-FX Ethernet   | 3                    | 4 HP       | 3 direction<br>binary signal transmission<br>up to 50 km                                      |

\*Note: the modules can be equipped with a different handle (narrower and made of aluminum, instead of the standard plastic), if the other modules of the device are equipped with top-screw terminals (see Chapter 20.2). In these cases, a "T" letter appears on the label of the module (e.g. **COM+/1801T**), but all other properties remain the same





Figure 2-2 COM modules for binary signal transmission



### 1.2.3.2.2. COM modules for line differential communication

| MODULE TYPE       | INTERFACE TYPE   | NUMBER OF INTERFACES | UNIT WIDTH | APPLICATION  |
|-------------------|--|----------------------|------------|--|
| <b>COM+/0091</b>  | G703.1 (64 kbit/s)   | 1                    | 4 HP       | Line differential protection via telecom network                                 |
| <b>COM+/1101</b>  | MM/ST 1300 nm, 50/62.5/125 µm connector, 100Base-FX Ethernet                             | 2                    | 4 HP       | 3 terminals / redundant line differential protection up to 2 km                  |
| <b>COM+/1801*</b> | MM/ST 1300 nm, 50/62.5/125 µm and SM/FC 1550 nm, 9/125 µm connector, 100Base-FX Ethernet | 2                    | 4 HP       | 3 terminals / redundant line differential protection up to 2 km and up to 120 km |
| <b>COM+/1901*</b> | MM/ST 1300 nm, 50/62.5/125 µm and SM/FC 1550 nm, 9/125 µm connector, 100Base-FX Ethernet | 2                    | 4 HP       | 3 terminals / redundant line differential protection up to 2 km and up to 50 km  |
| <b>COM+/8801</b>  | SM/FC 1550 nm, 9/125 µm connector, 100Base-FX Ethernet                                   | 2                    | 4 HP       | 3 terminals / redundant line differential protection up to 120 km                |
| <b>COM+/9901</b>  | SM/FC 1550 nm, 9/125 µm connector, 100Base-FX Ethernet                                   | 2                    | 4 HP       | 3 terminals / redundant line differential protection up to 50 km                 |

\*Note: the modules can be equipped with a different handle (narrower and made of aluminum, instead of the standard plastic), if the other modules of the device are equipped with top-screw terminals (see Chapter 20.2). In these cases, a "T" letter appears on the label of the module (e.g. **COM+/1801T**), but all other properties remain the same




Figure 2-3 COM modules for line differential applications

### 1.2.3.2.3. COM modules for busbar differential protection communication

| MODULE TYPE       | INTERFACE TYPE  | NUMBER OF INTERFACES | UNIT WIDTH | APPLICATION   |
|-------------------|---|----------------------|------------|---|
| <b>COM+/1111</b>  | MM/ST 1300 nm, 50/62.5/125 $\mu$ m connector, 100Base-FX Ethernet | 3                    | 4 HP       | Busbar protection for 3 bay units up to 2 km          |
| <b>COM+/1111D</b> | MM/ST 1300 nm, 50/62.5/125 $\mu$ m connector, 100Base-FX Ethernet | 3                    | 4 HP       | Busbar protection for 3x2 bay units (dual) up to 2 km |




Figure 2-4 COM modules for busbar differential protections



### 1.2.3.2.4. COM modules for Remote I/O (RIO) servers

| MODULE TYPE | INTERFACE TYPE   | NUMBER OF INTERFACES | UNIT WIDTH | APPLICATION                               |
|-------------|--|----------------------|------------|---|
| COM+/1202*  | MM/LC 1300 nm, 50/62.5/125 μm connector, 100Base-FX Ethernet | 2                    | 8 HP       | 2-port Ethernet switch for MODBUS via RIO |
| COM+/1324*  | MM/LC 1300 nm, 50/62.5/125 μm connector, 100Base-FX Ethernet | 4                    | 8 HP       | 4-port Ethernet switch for MODBUS via RIO |
| COM+/1335   | MM/LC 1300 nm, 50/62.5/125 μm connector, 100Base-FX Ethernet | 5                    | 8 HP       | 5-port Ethernet switch for MODBUS via RIO |
| COM+/6603   | MM/LC 1300 nm, 50/62.5/125 μm connector, 100Base-FX Ethernet | 2                    | 4 HP       | 2-port Ethernet switch for MODBUS via RIO |
| COM+/6663   | MM/LC 1300 nm, 50/62.5/125 μm connector, 100Base-FX Ethernet | 3                    | 4 HP       | 3-port Ethernet switch for MODBUS via RIO |

**\*Obsolete module. These modules are not recommended for new designs!**




Figure 2-5 COM modules for RIO servers

### 1.2.3.3. Communication interface characteristics

#### 1.2.3.3.1. Ethernet multi-mode transmitter and receiver

##### 1.2.3.3.1.1. MM/ST connector

Up to approximately 2 km.

###### Transmitter

| PARAMETER   | SYMBOL      | MIN.                       | TYP. | MAX.      | UNIT     |
|---|-------------|----------------------------|------|-----------|----------|
| OPTICAL OUTPUT POWER<br>62.5/125 $\mu\text{m}$ , NA = 0.275 FIBER | $P_O$       | BOL*: -19<br>EOL*: -20     | -    | -14       | dBm avg. |
| OUTPUT OPTICAL POWER<br>50/125 $\mu\text{m}$ , NA = 0.20 FIBER    | $P_O$       | BOL*: -22.5<br>EOL*: -23.5 | -    | -14       | dBm avg. |
| OPTICAL EXTINCTION RATIO  | ER          | -                          | -    | 10<br>-10 | %<br>dB  |
| CENTER WAVELENGTH   | $\lambda_C$ | 1270                       | 1308 | 1380      | nm       |

\* BOL: Beginning of life, EOL: End of life

Note: according to field experiences, the 62.5/125  $\mu\text{m}$  cabling is recommended for applications where the center wavelength is 1300/1310 nm.

Receiver sensitivity is measured with  $2^{23} - 1$  PRBS pattern within BER =  $2.5 \times 10^{-10}$

| PARAMETER                                  | SYMBOL      | MIN.                   | TYP. | MAX. | UNIT          |
|--|-------------|------------------------|------|------|---------------|
| SIGNAL DETECT - ASSERTED                   | $P_A$       | $P_D + 1.5 \text{ dB}$ | -    | -33  | dBm avg.      |
| SIGNAL DETECT - DEASSERTED                 | $P_D$       | -45                    | -    | -    | dBm avg.      |
| SIGNAL DETECT - HYSTERESIS                 | $P_A - P_D$ | 1.5                    | -    | -    | dB            |
| SIGNAL DETECT ASSERT TIME<br>(OFF TO ON)   | AS_Max      | 0                      | 2    | 100  | $\mu\text{s}$ |
| SIGNAL DETECT DEASSERT TIME<br>(ON TO OFF) | ANS_Max     | 0                      | 8    | 350  | $\mu\text{s}$ |



### 1.2.3.3.1.2. MM/LC connector

Up to approximately 2 km.

#### Transmitter

| PARAMETER   | SYMBOL      | MIN.                       | TYP.         | MAX.       | UNIT     |
|---|-------------|----------------------------|--------------|------------|----------|
| OPTICAL OUTPUT POWER**<br>62.5/125 $\mu\text{m}$ , NA = 0.275 FIBER | $P_O$       | BOL*: -19<br>EOL*: -20     | -15.7        | -14        | dBm avg. |
| OUTPUT OPTICAL POWER<br>50/125 $\mu\text{m}$ , NA = 0.20 FIBER      | $P_O$       | BOL*: -22.5<br>EOL*: -23.5 | -            | -14        | dBm avg. |
| OPTICAL EXTINCTION RATIO  | ER          | -                          | 0.002<br>-47 | 0.2<br>-27 | %<br>dB  |
| CENTER WAVELENGTH   | $\lambda_C$ | 1270                       | 1308         | 1380       | nm       |

\* BOL: Beginning of life, EOL: End of life

Note: according to field experiences, the 62.5/125  $\mu\text{m}$  cabling is recommended for applications where the center wavelength is 1300/1310 nm.

Receiver sensitivity is measured with  $2^{23} - 1$  PRBS pattern within BER =  $2.5 \times 10^{-10}$

| PARAMETER                                  | SYMBOL      | MIN.           | TYP. | MAX. | UNIT          |
|--|-------------|----------------|------|------|---------------|
| SIGNAL DETECT - ASSERTED                   | $P_A$       | $P_D + 1.5$ dB | -    | -33  | dBm avg.      |
| SIGNAL DETECT - DEASSERTED                 | $P_D$       | -45            | -    | -    | dBm avg.      |
| SIGNAL DETECT - HYSTERESIS                 | $P_A - P_D$ | 1.5            | -    | -    | dB            |
| SIGNAL DETECT ASSERT TIME<br>(OFF TO ON)   | AS_Max      | 0              | 2    | 100  | $\mu\text{s}$ |
| SIGNAL DETECT DEASSERT TIME<br>(ON TO OFF) | ANS_Max     | 0              | 5    | 100  | $\mu\text{s}$ |

## 1.2.3.3.2. Ethernet single mode transmitter and receiver

### 1.2.3.3.2.1. Long haul single mode transceiver

Up to approximately 120 km, with max. 32 dB link attenuation.

#### Transmitter

| PARAMETER                | SYMBOL      | MIN. | TYP. | MAX. | UNIT     |
|--------------------------|-------------|------|------|------|----------|
| OPTICAL OUTPUT POWER     | $P_O$       | -6   | -    | 0    | dBm avg. |
| OPTICAL EXTINCTION RATIO | ER          | 8.3  | -    | -    | dB       |
| CENTER WAVELENGTH        | $\lambda_C$ | 1490 | 1550 | 1610 | nm       |

Receiver sensitivity is measured with  $2^{23} - 1$  PRBS pattern within  $BER = 2.5 \times 10^{-10}$

| PARAMETER                  | SYMBOL      | MIN. | TYP. | MAX. | UNIT     |
|----------------------------|-------------|------|------|------|----------|
| OPTICAL INPUT SENSITIVITY  | $P_{IN}$    | -    | -38  | -35  | dBm avg. |
| SATURATION                 | $P_{SAT}$   | -3   | 0    | -    | dBm      |
| CENTER WAVELENGTH          | $\lambda_C$ | 1100 | -    | 1600 | nm       |
| SIGNAL DETECT - ASSERTED   | $P_A$       | -    | -    | -35  | dBm avg. |
| SIGNAL DETECT - DEASSERTED | $P_D$       | -45  | -    | -    | dBm avg. |
| HYSTERESIS                 | $P_{HYS}$   | -    | 3    | -    | dB       |



### 1.2.3.3.2.2. Short haul single mode transceiver

Up to approximately 50 km, with max. 27 dB link attenuation.

#### Transmitter

| PARAMETER                | SYMBOL      | MIN. | TYP. | MAX. | UNIT     |
|--------------------------|-------------|------|------|------|----------|
| OPTICAL OUTPUT POWER     | $P_O$       | -12  | -    | -6   | dBm avg. |
| OPTICAL EXTINCTION RATIO | ER          | 8.3  | -    | -    | dB       |
| CENTER WAVELENGTH        | $\lambda_C$ | 1490 | 1550 | 1610 | nm       |

Receiver sensitivity is measured with  $2^{23} - 1$  PRBS pattern within  $BER = 2.5 \times 10^{-10}$

| PARAMETER                  | SYMBOL    | MIN. | TYP. | MAX. | UNIT     |
|----------------------------|-----------|------|------|------|----------|
| OPTICAL INPUT SENSITIVITY  | $P_{IN}$  | -    | -38  | -35  | dBm avg. |
| SATURATION                 | $P_{SAT}$ | -3   | 0    | -    | dBm      |
| CENTER WAVELENGTH          | $\lambda$ | 1100 | -    | 1600 | nm       |
| SIGNAL DETECT - ASSERTED   | $P_A$     | -    | -    | -35  | dBm avg. |
| SIGNAL DETECT - DEASSERTED | $P_D$     | -45  | -    | -    | dBm avg. |
| HYSTERESIS                 | $P_{HYS}$ | -    | 3    | -    | dB       |



### 1.2.3.3.3. ASIF-O transmitter and receiver

#### 1.2.3.3.3.1. ASIF-O POF

##### Transmitter

| PARAMETER                        | SYMBOL         | MIN.  | TYP. | MAX. | UNIT | JUMPER SETTINGS |
|----------------------------------|----------------|-------|------|------|------|-----------------|
| TRANSMITTER OUTPUT OPTICAL POWER | $P_T$          | -15.3 | -    | -9   | dBm  | JP1 2-3         |
|                                  |                | -23.3 | -    | -17  |      | JP1 1-2         |
| PEAK EMISSION WAVELENGTH         | $\lambda_{PK}$ | -     | 660  | -    | nm   |                 |
| EFFECTIVE DIAMETER               | D              | -     | 1    | -    | mm   |                 |
| NUMERICAL APERTURE               | NA             | -     | 0.5  | -    |      |                 |

##### Receiver

| PARAMETER                         | SYMBOL     | MIN. | TYP. | MAX.  | UNIT |
|-----------------------------------|------------|------|------|-------|------|
| INPUT OPTICAL POWER LEVEL LOGIC 0 | $P_{R(L)}$ | -39  | -    | -13.7 | dBm  |
| INPUT OPTICAL POWER LEVEL LOGIC 1 | $P_{R(H)}$ | -    | -    | -53   | dBm  |
| EFFECTIVE DIAMETER                | D          | -    | 1    | -     | mm   |
| NUMERICAL APERTURE                | NA         | -    | 0.5  | -     |      |

These characteristics are valid for both POF interfaces in CPU+1331 module.

#### 1.2.3.3.3.2. ASIF-O GLASS

##### Transmitter (Output measured out of 1 meter of cable)

| PARAMETER                                     | SYMBOL | MIN.  | TYP.  | MAX.  | UNIT     | JUMPER SETTINGS |
|---|--------|-------|-------|-------|----------|-----------------|
| 50/125 $\mu\text{m}$ FIBER CABLE NA = 0.2     | $P_o$  | -19.4 | -16.4 | -14.4 | dBm peak | JP1 2-3         |
|   |        | -28.9 | -25.9 | -23.9 |          | JP1 1-2         |
| 62.5/125 $\mu\text{m}$ FIBER CABLE NA = 0.275 | $P_o$  | -15.6 | -12.6 | -10.6 | dBm peak | JP1 2-3         |
|   |        | -22.9 | -19.9 | -17.9 |          | JP1 1-2         |

##### Receiver

| PARAMETER  | SYMBOL   | MIN.  | TYP. | MAX. | UNIT     |
|--|----------|-------|------|------|----------|
| PEAK OPTICAL INPUT POWER LOGIC LEVEL HIGH ( $\lambda_P = 820 \text{ nm}$ ) | $P_{RH}$ | -25.4 | -    | -9.2 | dBm peak |
| PEAK OPTICAL INPUT POWER LOGIC LEVEL LOW                                   | $P_{RL}$ | -     | -    | -40  | dBm peak |



### 1.2.3.3.4. ASIF-G transmitter and receiver

The RS422/RS485 interfaces of our CPU+1501, CPU+1511, CPU+1581, CPU+9501 modules provide galvanic interface to support legacy or other serial protocols. For more details see our RS485/422 application note, available on our homepage.

#### Transmitter

| PARAMETER  | SYMBOL    | MIN. | TYP. | MAX. | UNIT |
|--|-----------|------|------|------|------|
| DIFFERENTIAL OUTPUT VOLTAGE (LOADED, $R_L = 100 \Omega$ , RS422) | $V_{OD2}$ | 2    | -    | 3.6  | V    |
| DIFFERENTIAL OUTPUT VOLTAGE (LOADED, $R_L = 54 \Omega$ , RS485)  | $V_{OD2}$ | 1.5  | -    | 3.6  | V    |

#### Receiver

| PARAMETER                            | SYMBOL    | MIN. | TYP. | MAX. | UNIT       |
|--------------------------------------|-----------|------|------|------|------------|
| DIFFERENTIAL INPUT THRESHOLD VOLTAGE | $V_{TH}$  | -200 | -125 | -30  | mV         |
| INPUT VOLTAGE HYSTERESIS             | $V_{HYS}$ | -    | 15   | -    | mV         |
| LINE INPUT RESISTANCE                | $R_{IN}$  | 96   | -    | -    | k $\Omega$ |



### 1.2.3.3.5. G.703 64 kbit/s co-directional interface (E0)

The EuroProt+ device also supports line differential communication via telecom networks using

- 64 kbit/s co-directional interface type through COM+0091. This type of communication is performed via 2 x 2 wire isolated galvanic type interface. The protection device is connected to a multiplexer or gateway which is responsible for protocol/speed conversion.

- Connector type: Weidmüller: Receptacle: S2L 3.50/12/90 F  
Plug: B2L 3.50/12/180 F
- Impedance: 120 Ω
- Cable length: 50 m
- Interface type: G.703.1 64 kbit/s (E0) co-directional, selectable grounding, with optional external clock input

*For further information about the cable assembly of this type of interface please see our G.703 E0 cable assembly guide.*

#### Receiver

| PARAMETER                  | VALUE  |
|----------------------------|--|
| LOSS OF SIGNAL ALARM LEVEL | ± 1.5 dB difference between alarm-on and alarm-off |
| DYNAMIC RANGE              | 10 dB maximum cable loss range                     |

#### Transmitter

| PARAMETER   | VALUE  |
|---|--|
| PAIR FOR EACH DIRECTION                             | ± 1.5 dB difference between alarm-on and alarm-off |
| TEST LOAD IMPEDANCE                                 | 10 dB maximum cable loss range                     |
| NOMINAL PEAK VOLTAGE OF A “MARK” (PULSE)            | One symmetric pair                                 |
| PEAK VOLTAGE OF A “SPACE” (NO PULSE)                | 120 Ω resistive                                    |
| NOMINAL PULSE WIDTH                                 | 1.0 V  |
| RATIO OF THE AMPLITUDES OF POSITIVE AND NEGATIVE    | 0 V ± 0.10 V                                       |
| PULSES AT THE CENTRE OF THE PULSES INTERVAL         | 3.9 ms   |
| RATIO OF THE WIDTHS OF POSITIVE AND NEGATIVE PULSES | 0.95 to 1.05                                       |
| AT THE NOMINAL HALF AMPLITUDE                       | 0.95 to 1.05                                       |
| MAXIMUM PEAK-TO-PEAK JITTER AT THE OUTPUT PORT      | Refer to clause 2/G.823                            |

### 1.2.3.3.5.1. PRP/HSR redundant Ethernet communication interface

The PRP/HSR redundant Ethernet communication interface supports the two new IEC 62439-3 protocols which provide seamless redundancy for Ethernet networking in substations with zero-time recovery in case of a single failure without frame loss:

- PRP – Parallel Redundancy Protocol (IEC 62439-3 Clause 4)
- HSR – High-availability Seamless Redundancy (IEC 62439-3 Clause 5)

This interface uses two MM/LC connectors for double connection to networks as these protocols are based on the duplication of the sent frames.




Figure 2-6 PRP/HSR connectors on a CPU+A001 module

### 1.2.3.3.5.2. Parallel Redundancy Protocol (PRP)

This redundancy protocol implements redundancy in the nodes as they are connected to two independent networks (LAN\_A and LAN\_B) sending a copy of each frame to both directions. The destination node receives and processes the first copy and discards the other copy of the sent frame.




Figure 2-7 Example of a PRP redundant network

*Single attached node (SAN): Network device that connects to a network with only one port.*

*Double attached node implementing PRP (DANP): Network device which connects to a network with two ports implementing PRP redundancy.*

### 1.2.3.3.5.3. High-availability Seamless Redundancy (HSR)

An HSR network provides redundancy with the same safety as PRP does with a lower cost. The principle of this protocol is also based on the duplication of the sent frames but in this solution the nodes are connected to a closed ring. A source node sends two copy of a frame to both direction and the destination node accepts the first received copy and discards the other one. If a frame returns to its source the node does not let it through itself prevent the possibility of an overload of the ring.





Figure 2-8 Example of an HSR redundant network

*Single attached node (SAN): Network device that connects to a network with only one port.*  
*Double attached node implementing HSR (DANH): Network device which connects to a network with two ports implementing HSR redundancy.*



## 1.2.4. Device housings

Three+one versions are available: one is 84 HP wide with 21 module slots, the 42 HP wide, which supports 10 module slots, the double 42 HP wide with 20 module slots, and finally the 24 HP, which supports 6 module slots.

Depending on the installed modules of the configuration, the top and bottom panels of the 84 HP and 42 HP racks can be either solid (default) or perforated by 2 mm holes to prevent overheating. 24 HP housings do not have this feature, as the S24 system is less flexible, their range of the optional modules are narrower.

| RACK CONFIGURATION           | FREE MODULE SLOTS* | BOTTOM AND TOP PANELS | DISPLAY OPTIONS           |
|------------------------------|--------------------|-----------------------|---------------------------|
| 84 HP, SINGLE RACK (3 U)     | 20                 | Solid, Perforated     | 3.5" TFT, 5.7" TFT        |
| 42 HP, SINGLE RACK (3 U)     | 9                  | Solid, Perforated     | 3.5" TFT, 5.7" TFT        |
| 42 HP, DOUBLE RACK (6 U)     | 19                 | Solid, Perforated     | 3.5" TFT                  |
| 24 HP, PANEL INSTRUMENT CASE | 5                  | Solid                 | B/W alphanumeric 3.5" TFT |

*\*CPU module is mandatory, it uses up one fixed position*

Previously, a new rack type has been introduced to the 42HP devices. As of April 2021. this type is introduced to the 84HP devices as well. The depth of the box has been reduced from 242 mm to 223 mm. By default, this reduced-depth housing shall be used for newly manufactured devices. For more information about the previous and new size, see Chapter [22.1](#).

The following images showcase examples of the different types of available device housings with different kinds of front panel HMI. The available front panels are listed in Chapter 4.






|  |  |
|--|--|
| <p>84 HP single rack<br/>(3 U) with<br/>3.5" TFT display<br/>and solid housing</p>             |    |
| <p>84 HP single rack<br/>(3 U) with<br/>5.7" TFT display<br/>and perforated<br/>housing</p>    |    |
| <p>42 HP single rack<br/>(3 U) with<br/>3.5" TFT display<br/>and solid housing</p>             |   |
| <p>42 HP double rack<br/>(6 U) with<br/>3.5" TFT display<br/>and solid housing</p>             |  |
| <p>24 HP panel<br/>instrument case<br/>with<br/>B/W display (left)<br/>TFT display (right)</p> |  |

Figure 3-1 Rack configuration illustrations



## 1.2.5. Human-Machine Interface (HMI) module

The EuroProt+ device HMI consists of the following two main parts:

- Hardware: the HMI module, which is the front panel of the device, this is described here
- Software: the embedded web server and the menu system that is accessible through the HMI module. The web server is accessible via station bus, EOB interface or RJ-45 Ethernet connector. This is described in detail in the [Operating Manual](#) (external document).

### 1.2.5.1. Local HMI modules

| MODULE TYPE                           | DISPLAY  | SERVICE PORT | RACK SIZE    | RACK DEPTH | ILLUSTRATION |
|---------------------------------------|----------|--------------|--------------|------------|--------------|
| HMI+/3505<br>HMI+/3405*               | 3,5" TFT | EOB          | 42 HP        | Reduced    |              |
|                                       |          |              | 84 HP        |            |              |
| HMI+/3506<br>HMI+/3406*<br>HMI+/3404* | 3,5" TFT | RJ-45        | 42 HP        | Reduced    |              |
|                                       |          |              | Double 42HP  |            |              |
|                                       |          |              | 84 HP        |            |              |
| HMI+/5005                             | 5,7" TFT | EOB          | 42 HP        | Reduced    |              |
| HMI+/5006<br>HMI+/5004*               | 5,7" TFT | RJ-45        | 42 HP        | Reduced    |              |
|                                       |          |              | Double 42 HP |            | n/a          |
| HMI+/5706<br>HMI+/5704*               | 5,7" TFT | RJ-45        | 84 HP        | Reduced    |              |

\*new display hardware requires CDSP firmware version 1560-H5 or higher!



The following modules were made for the previous (now obsolete) racks (see Chapter 22.1), so they can be found in numerous devices. These became obsolete as well, **they are not recommended for new designs!**

| MODULE TYPE | DISPLAY  | SERVICE PORT | RACK SIZE | RACK DEPTH | ILLUSTRATION |
|-------------|----------|--------------|-----------|------------|--------------|
| HMI+/3501   | 3,5" TFT | EOB          | 42 HP     | Normal     |              |
|             |          |              | 84 HP     |            |              |
| HMI+/3502   | 3,5" TFT | RJ-45        | 42 HP     | Normal     |              |
|             |          |              | 84 HP     |            |              |
| HMI+/5001   | 5,7" TFT | EOB          | 42 HP     | Normal     |              |
| HMI+/5002   | 5,7" TFT | RJ-45        | 42 HP     | Normal     |              |
| HMI+/5701   | 5,7" TFT | EOB          | 84 HP     | Normal     |              |
| HMI+/5702   | 5,7" TFT | RJ-45        | 84 HP     | Normal     |              |

### 1.2.5.2. Remote HMI

Protecta provides an alternative solution in that case if the IED can be only mounted in a non-practical way for managing the device via usual Human-Machine Interface.

By using a remote HMI (*terminal HMI device*), customers can place the HMI up to 3 meters far from the IED itself (*host device*) and mount the IED in any possible way that is applicable. The connection between the remote HMI and the IED is provided by a custom galvanic interface with DA-15 connector on the remote side.



Figure 4-1 42 HP Remote HMI

Depending on the size of the HMI module you can use any applicable mounting methods that described in the [Mounting methods](#) chapter (Flush mounting, Semi-flush mounting, Rack mounting).



Figure 4-2 Remote HMI module with its host device

| MODULE TYPE | DISPLAY  | SERVICE PORT | RACK SIZE | RACK DEPTH | ILLUSTRATION |
|-------------|----------|--------------|-----------|------------|--------------|
| HMIT+/3505  | 3,5" TFT | EOB          | 42 HP     | Reduced    |              |
|             |          |              | 84 HP     |            |              |
| HMIT+/3506  | 3,5" TFT | RJ-45        | 42 HP     | Reduced    |              |
|             |          |              | 84 HP     |            |              |
| HMIT+/5706  | 5,7" TFT | RJ-45        | 84 HP     | Reduced    |              |



The following modules were made for the previous (now obsolete) racks (see Chapter 22.1), so they can be found in numerous devices. These became obsolete as well, **they are not recommended for new designs!**

| MODULE TYPE | DISPLAY  | SERVICE PORT | RACK SIZE | RACK DEPTH | ILLUSTRATION |
|-------------|----------|--------------|-----------|------------|--------------|
| HMIT+/3501  | 3,5" TFT | EOB          | 42 HP     | Normal     |              |
|             |          |              | 84 HP     |            |              |
| HMIT+/3502  | 3,5" TFT | RJ-45        | 42 HP     | Normal     |              |
|             |          |              | 84 HP     |            |              |
| HMIT+/5702  | 5,7" TFT | RJ-45        | 84 HP     | Normal     |              |

### 1.2.5.3. S24 HMI

The S24 Smart Line devices have a different HMI family:


| MODULE TYPE                            | DISPLAY  | SERVICE PORT | RACK SIZE | MOUNTING | ILLUSTRATION |
|--|----------|--------------|-----------|----------|--------------|
| HMI+/2604*<br>HMI+/2404<br>HMI+/2304** | 3,5" TFT | RJ-45        | 24 HP     | Normal   |              |
| HMI+/2606*<br>HMI+/2406<br>HMI+/2306** | 3,5" TFT | RJ-45        | 24 HP     | DIN-rail |              |
| HMI+/2704*<br>HMI+/2504                | B&W LCD  | RJ-45        | 24 HP     | Normal   |              |
| HMI+/2706*<br>HMI+/2506                | B&W LCD  | RJ-45        | 24 HP     | DIN-rail |              |

*\*for newer, modular-type S24 devices*

*\*\*new display hardware requires CDSP firmware version 1560-H5 or higher!*

The following module is **obsolete, it is not recommended for new designs!**

| MODULE TYPE | DISPLAY  | SERVICE PORT | RACK SIZE | MOUNTING | ILLUSTRATION |
|-------------|----------|--------------|-----------|----------|--------------|
| HMI+/2401*  | 3,5" TFT | EOB          | 24 HP     | Normal   |              |



## 1.2.5.4. Parts of the HMI modules

The EuroProt+ device HMI on the front panel contains the following elements:

| Function                                   | Description   |
|--|---|
| <b>16 PIECES USER LEDs</b>                 | Three-color, 3 mm circular LEDs   |
| <b>COM LED</b>                             | Yellow, 3 mm circular LED indicating EOB/RJ-45 (on the front panel) communication link and activity   |
| <b>CAPACITIVE TOUCH KEY LEDs</b>           | 4 pcs yellow, 3 mm circular LEDs indicating touch key actions   |
| <b>DEVICE STATUS LED</b>                   | 1 piece three-color, 3 mm circular LED<br>Green: normal device operation<br>Yellow: device is in warning state<br>Red: device is in error state   |
| <b>DEVICE KEYS</b><br>(I, O, X, PAGE)      | Capacitive touch keys   |
|  | Tactile push buttons  |
| <b>BUZZER</b>                              | Audible touch key pressure feedback   |
| <b>CHANGEABLE LED DESCRIPTION LABEL</b>    | Describes user LED functionality  |
| <b>DISPLAY</b>                             | 320 × 240 pixel TFT color display with resistive touchscreen interface (3.5" or optional 5.7")  |
|  | 128 × 64 LCD black & white display  |
| <b>OPTICAL INTERFACE FOR FACTORY USAGE</b> | For debugging and software development purposes<br><i>Only for 42 HP and 84 HP devices.</i>   |
| <b>EOB CONNECTOR</b>                       | <p><b>Ethernet Over Board:</b> communication interface accomplishes isolated, non-galvanic Ethernet connection with the help of a magnetically attached EOB device. The EOB device has an RJ-45 type connector supporting Ethernet connection to the user computer. This is a proprietary and patented solution from Protecta Ltd.</p> <p><b>EOB1:</b> Supporting 10Base-T Ethernet connection. Passive device with one RJ45 type connector. Obsolete module.</p> <p><b>EOB2:</b> Supporting 10/100Base-Tx Ethernet connection. An active device that has a USB port in addition to the RJ45 connector for powering up.</p> |
| <b>ETHERNET SERVICE PORT</b>               | <b>IP56</b> rated Ethernet 10/100-Base-T interface with RJ-45 type connector (IP56 only valid if the cap of the service port is closed.)  |




Figure 4–3 HMI signals and controls

#### LCD dot-defect handling policy

The definitions of dot-defect are as below:

- The defect area of the dot must be bigger than half of a dot.
- For bright dot-defect (sparkle mode), showing black pattern, the dot's brightness must be over 30 % brighter than others at black raster.
- For dark dot-defect (black mode), showing white pattern, the dot's brightness must be under 70 % darker than others at R.G.B. raster.

| DOT-DEFECT TYPE             |          | MAXIMUM NUMBER ACCEPTABLE |          |     |
|-----------------------------|----------|---------------------------|----------|-----|
|                             |          | 3.5"                      | 5.7"     |     |
| SPARKLE MODE                | 1 dot    | 4                         | 4        |     |
|                             | 2 dots   | 2 (sets)                  | 1        |     |
|                             | IN TOTAL | 4                         | 5        |     |
| BLACK MODE                  | 1 dot    | 4                         | 5        |     |
|                             | 2 dots   | 2 (sets)                  | 2        |     |
|                             | IN TOTAL | 4                         | 5        |     |
| SPARKLE MODE AND BLACK MODE |          | 2 dots                    | 2 (sets) | n/a |
| IN TOTAL                    |          | 6                         | 10       |     |

For further information please contact our Application Team. ([application@protecta.hu](mailto:application@protecta.hu))





## 1.2.6. Current input module

This is an input module with intermediate current transformers to input the phase currents and the zero-sequence current. The rated current for the phase current and for the zero-sequence current can be selectable by parameter.

Main features:

- Rated frequency: 50 Hz, 60 Hz
- *Electronic* iron-core flux compensation

Connector types:

- *The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.*

| MODULE TYPE                             | CT+/0101                                  |     | CT+/1111*   |      | CT+/1155  |      | CT+/1500                                  |      |
|---|---|-----|---|------|---|------|---|------|
| CHANNEL NUMBER                          | 1 – 4                                     |     | 1 – 4   |      | 1 – 4   |      | 1 – 3                                     |      |
| SELECTABLE RATED CURRENT, $I_N$ [A]     | 0.04                                      | 0.2 | 1   | 5    | 1   | 5    | 1   | 5    |
| MAX. MEASURED CURRENT ( $\pm 10\%$ )    | $8 \times I_N$                            |     | $50 \times I_N$   |      | $12.5 \times I_N$   |      | $2 \times I_N$                            |      |
| POWER CONSUMPTION AT RATED CURRENT [VA] | 0.005                                     | 0.1 | 0.01  | 0.25 | 0.02  | 0.45 | 0.1                                       | 1.55 |
| THERMAL WITHSTAND [A]                   |   |     |   |      |   |      |   |      |
| CONTINUOUSLY                            | 7   |     | 20  |      | 20  |      | 7   |      |
| 10 s                                    | 50  |     | 175   |      | 120   |      | 50  |      |
| 1 s                                     | 150                                       |     | 500   |      | 380   |      | 150                                       |      |
| 10 ms                                   | 330                                       |     | 1200  |      | 850   |      | 330                                       |      |
| CONNECTOR TYPE                          | <u>Default:</u> STVS<br><u>Options:</u> - |     | <u>Default:</u> STVS<br><u>Options:</u> -                         |      | <u>Default:</u> STVS<br><u>Options:</u> -   |      | <u>Default:</u> STVS<br><u>Options:</u> R |      |
| RECOMMENDED APPLICATION                 | DEFL earth fault protection               |     | Special disturbance recorder application in wider frequency range |      | Special protection applications where the overcurrent in the secondary circuit can not exceed $10 \times I_N$ |      | General three-phase measurement           |      |

**\*Obsolete module. These modules are not recommended for new designs!**

| MODULE TYPE                             | CT+/1515*                                 |      | CT+/2500*                                 |      | CT+/5101                                     |      |                   |     |
|---|---|------|---|------|--|------|-------------------|-----|
| CHANNEL NUMBER                          | 1 – 4                                     |      | 1 – 3                                     |      | 1 – 3  |      | 4                 |     |
| SELECTABLE RATED CURRENT, $I_N$ [A]     | 1   | 5    | 1   | 5    | 1  | 5    | 0.2               | 1   |
| MAX. MEASURED CURRENT ( $\pm 10\%$ )    | $2 \times I_N$                            |      | $2 \times I_N$                            |      | $50 \times I_N$                              |      | $12.5 \times I_N$ |     |
| POWER CONSUMPTION AT RATED CURRENT [VA] | 0.1                                       | 1.55 | 0.1                                       | 1.55 | 0.01   | 0.25 | 0.005             | 0.1 |
| THERMAL WITHSTAND [A]                   |   |      |   |      |  |      |                   |     |
| CONTINUOUSLY                            | 7   |      | 7   |      | 20   |      | 7                 |     |
| 10 s                                    | 50  |      | 50  |      | 175  |      | 50                |     |
| 1 s                                     | 150                                       |      | 150                                       |      | 500  |      | 150               |     |
| 10 ms                                   | 330                                       |      | 330                                       |      | 1200   |      | 330               |     |
| CONNECTOR TYPE                          | <u>Default:</u> STVS<br><u>Options:</u> - |      | <u>Default:</u> STVS<br><u>Options:</u> - |      | <u>Default:</u> STVS<br><u>Options:</u> -    |      |                   |     |
| RECOMMENDED APPLICATION                 | Special disturbance recorder application  |      | Generator protections                     |      | Extremely sensitive earth-fault applications |      |                   |     |

**\*Obsolete module. These modules are not recommended for new designs!**

| MODULE TYPE                             | CT+/5102                                  |      |                 |      | CT+/5111*                                 |      |                 |       |
|---|---|------|-----------------|------|---|------|-----------------|-------|
| CHANNEL NUMBER                          | 1 – 3                                     |      | 4               |      | 1 – 3                                     |      | 4               |       |
| SELECTABLE RATED CURRENT, $I_N$ [A]     | 1   | 5    | 0.2             | 1    | 1   | 5    | 0.001           | 0.005 |
| MAX. MEASURED CURRENT ( $\pm 10\%$ )    | $50 \times I_N$                           |      | $50 \times I_N$ |      | $50 \times I_N$                           |      | $50 \times I_N$ |       |
| POWER CONSUMPTION AT RATED CURRENT [VA] | 0.01                                      | 0.25 | 0.001           | 0.01 | 0.01                                      | 0.25 | 0.005           | 0.1   |
| THERMAL WITHSTAND [A]                   |   |      |                 |      |   |      |                 |       |
| CONTINUOUSLY                            | 20  |      | 20              |      | 20  |      | 7               |       |
| 10 s                                    | 175                                       |      | 120             |      | 175                                       |      | 50              |       |
| 1 s                                     | 500                                       |      | 380             |      | 500                                       |      | 150             |       |
| 10 ms                                   | 1200                                      |      | 850             |      | 1200                                      |      | 330             |       |
| CONNECTOR TYPE                          | <u>Default:</u> STVS<br><u>Options:</u> - |      |                 |      | <u>Default:</u> STVS<br><u>Options:</u> R |      |                 |       |
| RECOMMENDED APPLICATION                 | Sensitive earth-fault applications        |      |                 |      | Sensitive earth-fault applications        |      |                 |       |

**\*Obsolete module. These modules are not recommended for new designs!**

| MODULE TYPE                             | CT+5115  |      | CT+5116                                   |      | CT+/5151                                  |      | CT+/5152                                  |      |
|---|--|------|---|------|---|------|---|------|
| CHANNEL NUMBER                          | 1 – 4  |      | 1 – 3                                     |      | 1 – 4                                     |      | 1 – 4                                     |      |
| SELECTABLE RATED CURRENT, $I_N$ [A]     | 1  | 5    | 1   | 5    | 1   | 5    | 1   | 5    |
| MAX. MEASURED CURRENT ( $\pm 10\%$ )    | $50 \times I_N$  |      | $50 \times I_N$                           |      | $50 I_N$                                  |      | $50 I_N$                                  |      |
| POWER CONSUMPTION AT RATED CURRENT [VA] | 0.01   | 0.25 | 0.01                                      | 0.25 | 0.01                                      | 0.25 | 0.01                                      | 0.25 |
| THERMAL WITHSTAND [A]                   |  |      |   |      |   |      |   |      |
| CONTINUOUSLY                            | 20   |      | 20  |      | 20  |      | 20  |      |
| 10 s                                    | 175  |      | 175                                       |      | 175                                       |      | 175                                       |      |
| 1 s                                     | 500  |      | 500                                       |      | 500                                       |      | 500                                       |      |
| 10 ms                                   | 1200   |      | 1200                                      |      | 1200                                      |      | 1200                                      |      |
| CONNECTOR TYPE                          | <u>Default:</u> STVS<br><u>Options:</u> R  |      | <u>Default:</u> STVS<br><u>Options:</u> - |      | <u>Default:</u> STVS<br><u>Options:</u> R |      | <u>Default:</u> STVS<br><u>Options:</u> R |      |
| RECOMMENDED APPLICATION                 | <ul style="list-style-type: none"> <li>General protection applications*</li> <li>Three-phase measurement*</li> </ul> |      | High-impedance differential protection    |      | General protection applications           |      | Busbar protection bay units               |      |

\*The CT+/5115 module handles both applications: it can be connected to the protection and measurement core of the primary CT as well

| MODULE TYPE                             | CT+/5153  |     |     |                 |           | CT+/5154*   |     |     |                 |       |
|---|---|-----|-----|-----------------|-----------|---|-----|-----|-----------------|-------|
| CHANNEL NUMBER                          | 1 – 3   |     | 4   |                 |           | 1 – 3   |     | 4   |                 |       |
| SELECTABLE RATED CURRENT, $I_N$ [A]     | 1   | 5   | 1   | 0.2             | 0.2 sens. | 1   | 5   | 5   | 1               | 0.2   |
| MAX. MEASURED CURRENT ( $\pm 10\%$ )    | $50 \times I_N$   |     |     | $10 \times I_N$ |           | $50 \times I_N$   |     |     | $10 \times I_N$ |       |
| POWER CONSUMPTION AT RATED CURRENT [VA] | 0.06  | 1.3 | 0.6 | 0.004           | 0.0004    | 0.06  | 1.3 | 1.3 | 0.06            | 0.004 |
| THERMAL WITHSTAND [A]                   |   |     |     |                 |           |   |     |     |                 |       |
| CONTINUOUSLY                            | 20  |     | 7   |                 |           | 20  |     |     |                 |       |
| 10 s                                    | 175   |     | 50  |                 |           | 175   |     |     |                 |       |
| 1 s                                     | 500   |     | 150 |                 |           | 500   |     |     |                 |       |
| 10 ms                                   | 1200  |     | 330 |                 |           | 1200  |     |     |                 |       |
| CONNECTOR TYPE                          | <u>Default:</u> STVS<br><u>Options:</u> R, T**  |     |     |                 |           | <u>Default:</u> STVS<br><u>Options:</u> R                                   |     |     |                 |       |
| RECOMMENDED APPLICATION                 | General protection application, extremely sensitive transient earth-fault protections |     |     |                 |           | General protection application, sensitive transient earth-fault protections |     |     |                 |       |


**\*Obsolete module. These modules are not recommended for new designs!**

\*\*The connector remains the same STVS, only the handle of the module becomes narrower and will be made of aluminum

| MODULE TYPE                             | CT+/5155*                                       |     |      |                 |            | CT+/5253**                  |     |      |       |            |
|---|---|-----|------|-----------------|------------|-----------------------------|-----|------|-------|------------|
| CHANNEL NUMBER                          | 1 – 3   |     | 4    |                 |            | 1 – 3                       |     | 4    |       |            |
| SELECTABLE RATED CURRENT, $I_N$ [A]     | 1   | 5   | 0.25 | 0.05            | 0.05 sens. | 5                           | 1   | 0.25 | 0.05  | 0.05 sens. |
| MAX. MEASURED CURRENT ( $\pm 10\%$ )    | $50 \times I_N$                                 |     |      | $10 \times I_N$ |            | $25 \times I_N$             |     |      |       |            |
| POWER CONSUMPTION AT RATED CURRENT [VA] | 0.06  | 1.3 | 0.6  | 0.004           | 0.0004     | 0.06                        | 1.3 | 0.6  | 0.004 | 0.0004     |
| THERMAL WITHSTAND [A]                   |   |     |      |                 |            |                             |     |      |       |            |
| CONTINUOUSLY                            | 20  |     | 7    |                 |            | 20                          |     | 7    |       |            |
| 10 s                                    | 175   |     | 50   |                 |            | 175                         |     | 50   |       |            |
| 1 s                                     | 500   |     | 150  |                 |            | 500                         |     | 150  |       |            |
| 10 ms                                   | 1200  |     | 330  |                 |            | 1200                        |     | 330  |       |            |
| CONNECTOR TYPE                          | Default: STVS<br>Options: -                     |     |      |                 |            | Default: STVS<br>Options: - |     |      |       |            |
| RECOMMENDED APPLICATION                 | DMD<br>Special sensitive earth fault protection |     |      |                 |            | Circuit breaker diagnostics |     |      |       |            |

**\*Obsolete module. These modules are not recommended for new designs!**

**\*\*Special module**







Figure 5-1 CT modules



## 1.2.7. Voltage input module

If the device performs voltage and/or frequency related functions and measurements (voltage protections, directional protections, frequency protections etc.), then this module is needed.

### Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.

| MODULE TYPE                            | VT+/2211   | VT+/2212*  | VT+/2215**   |
|--|--|--|--|
| CHANNEL NUMBER                         | 4  | 4  | 4  |
| SELECTABLE VOLTAGE RANGE               | <u>Type 100:</u><br>$\frac{100}{\sqrt{3}}$ , 100 V<br><u>Type 200:</u><br>$\frac{200}{\sqrt{3}}$ , 200 V | <u>Type 100:</u><br>$\frac{100}{\sqrt{3}}$ , 100 V<br><u>Type 200:</u><br>$\frac{200}{\sqrt{3}}$ , 200 V | <u>Type 100:</u><br>$\frac{100}{\sqrt{3}}$ , 100 V<br><u>Type 200:</u><br>$\frac{200}{\sqrt{3}}$ , 200 V                     |
| CONTINUOUS VOLTAGE WITHSTAND           | 200 V  | 200 V  | 200 V  |
| SHORT TIME OVERLOAD (1 s)              | 275 V (10s)  | 275 V  | 275 V  |
| VOLTAGE MEASURING RANGE ( $\pm 10\%$ ) | 0.05 $U_N$ – 1.3 $U_N$   | 0.05 $U_N$ – 1.3 $U_N$   | 0.05 $U_N$ – 1.3 $U_N$   |
| POWER CONSUMPTION OF VOLTAGE INPUT     | 0.61 VA at 200 V<br>0.2 VA at 100 V  | 0.61 VA at 200 V<br>0.2 VA at 100 V  | <b>ch. 1-3:</b> 0.61 VA at 200 V<br>0.2 VA at 100 V<br><b>ch. 4:</b> 50 mVA at 100 V   |
| CONNECTOR TYPE                         | <u>Default:</u> BLA<br><u>Options:</u> F, T, R   | <u>Default:</u> BLA<br><u>Options:</u> -   | <u>Default:</u> BLA<br><u>Options:</u> -   |
| RECOMMENDED APPLICATION                | General protection applications.   | Special disturbance recorder application in wider frequency range  | Special protection applications with voltage transformers that require low power consumption on the 4 <sup>th</sup> channel. |

**\*Obsolete module. These modules are not recommended for new designs!**

\*\*Special module



| MODULE TYPE                            | VT+/2245   | VT+/2246*  |
|--|--|--|
| CHANNEL NUMBER                         | 4  | 3  |
| SELECTABLE VOLTAGE RANGE               | <b>Type 200:</b><br>$\frac{200}{\sqrt{3}}$ , 200 V<br><b>Type 400:</b><br>$\frac{400}{\sqrt{3}}$ |  |
| CONTINUOUS VOLTAGE WITHSTAND           | 400 V  |  |
| SHORT TIME OVERLOAD (1 s)              | 420 V  | 420 V (10 s)   |
| VOLTAGE MEASURING RANGE ( $\pm 10\%$ ) | 0.05 U <sub>N</sub> – 1.3 U <sub>N</sub>   |  |
| POWER CONSUMPTION OF VOLTAGE INPUT     | 0.21 VA at 200 V<br>0.28 VA at 230 V   |  |
| CONNECTOR TYPE                         | <u>Default:</u> BLA<br><u>Options:</u> T   | <u>Default:</u> BLA<br><u>Options:</u> -   |
| RECOMMENDED APPLICATION                | Protection applications for 400 V AC secondary voltage   | Special protection applications for 400 V AC secondary voltage and increased isolation to 6 kV |

\*Special module





Figure 6-1 VT modules



## 1.2.8. Binary input module

The inputs are galvanic isolated, and the module converts high-voltage signals to the voltage level and format of the internal circuits. The inputs of this module can be also programmed to serve as a PPM input for time synchronization.

### Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.

### Notes for the following tables:

- **Thermal withstand voltage:** continuous with 60 % of the input channels are energized.
- **Clamp voltage:** these are the guaranteed values; the actual ones might differ from those provided here (falling and rising around  $0.66 U_N$  and  $0.77 U_N$ , respectively)

| MODULE TYPE               | O8+/2401                                 | O8+/4801                                 | O8+/1101                                 | O8+/2201                                 |
|---------------------------|--|--|--|--|
| CHANNEL NUMBER            | 8  | 8  | 8  | 8  |
| TIME SYNCHRONIZATION      | configured by EuroCAP                    | configured by EuroCAP                    | configured by EuroCAP                    | configured by EuroCAP                    |
| RATED VOLTAGE             | 24 V                                     | 48 V                                     | 110 V                                    | 220 V                                    |
| THERMAL WITHSTAND VOLTAGE | 72 V                                     | 100 V                                    | 250 V                                    | 320 V                                    |
| CLAMP VOLTAGE             | falling $0.64 U_N$<br>rising $0.8 U_N$   | falling $0.64 U_N$<br>rising $0.8 U_N$   | falling $0.64 U_N$<br>rising $0.8 U_N$   | falling $0.64 U_N$<br>rising $0.8 U_N$   |
| COMMON GROUPS             | independent                              | independent                              | independent                              | independent                              |
| CONNECTOR TYPE            | <u>Default:</u> BLA<br><u>Options:</u> T | <u>Default:</u> BLA<br><u>Options:</u> T | <u>Default:</u> BLA<br><u>Options:</u> T | <u>Default:</u> BLA<br><u>Options:</u> T |

| MODULE TYPE               | O12+/2401                                | O12+/4801                                   | O12+/1101                                   | O12+/2201                                |
|---------------------------|--|---|---|--|
| CHANNEL NUMBER            | 12                                       | 12  | 12  | 12                                       |
| TIME SYNCHRONIZATION      | configured by EuroCAP                    | configured by EuroCAP                       | configured by EuroCAP                       | configured by EuroCAP                    |
| RATED VOLTAGE             | 24 V                                     | 48 V  | 110 V                                       | 220 V                                    |
| THERMAL WITHSTAND VOLTAGE | 72 V                                     | 72 V  | 250 V                                       | 320 V                                    |
| CLAMP VOLTAGE             | falling $0.64 U_N$<br>rising $0.8 U_N$   | falling $0.64 U_N$<br>rising $0.8 U_N$      | falling $0.64 U_N$<br>rising $0.8 U_N$      | falling $0.64 U_N$<br>rising $0.8 U_N$   |
| COMMON GROUPS             | 4 × 3 common                             | 4 × 3 common                                | 4 × 3 common                                | 4 × 3 common                             |
| CONNECTOR TYPE            | <u>Default:</u> BLA<br><u>Options:</u> T | <u>Default:</u> BLA<br><u>Options:</u> F, T | <u>Default:</u> BLA<br><u>Options:</u> F, T | <u>Default:</u> BLA<br><u>Options:</u> T |



| MODULE TYPE               | O12+/4201*  | O12+/2101*  | O15+/4801T   | O15+/1101T   |
|---------------------------|---|---|--|--|
| CHANNEL NUMBER            | 12  | 12  | 15   | 15   |
| TIME SYNCHRONIZATION      | configured by EuroCAP   | configured by EuroCAP   | configured by EuroCAP                                    | configured by EuroCAP                                    |
| RATED VOLTAGE             | 24 V DC / 48 V DC user selectable on channel basis by jumpers | 110 V DC / 220 V DC user selectable on channel basis by jumpers | 48 V   | 110 V  |
| THERMAL WITHSTAND VOLTAGE | 72 V  | 320 V   | 100 V  | 250 V  |
| CLAMP VOLTAGE             | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub>      | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub>        | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub> | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub> |
| COMMON GROUPS             | 4 × 3 common  | 4 × 3 common  | 1 × 15 common  | 1 × 15 common  |
| CONNECTOR TYPE            | <u>Default:</u> BLA<br><u>Options:</u> -                      | <u>Default:</u> BLA<br><u>Options:</u> T                        | BLT  | BLT  |

\* O12+2101 and O12+4201 modules can be used only in demonstration applications! For further information see our [Product availability](#) chapter.

| MODULE TYPE               | O16+/2401*   | O16+/4801*   | O16+/1101*   | O16+/2201*   |
|---------------------------|--|--|--|--|
| CHANNEL NUMBER            | 16   | 16   | 16   | 16   |
| TIME SYNCHRONIZATION      | -  | -  | -  | -  |
| RATED VOLTAGE             | 24 V   | 48 V   | 110 V  | 220 V  |
| THERMAL WITHSTAND VOLTAGE | 72 V   | 100 V  | 250 V  | 320 V  |
| CLAMP VOLTAGE             | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub> | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub> | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub> | falling 0.64 U <sub>N</sub><br>rising 0.8 U <sub>N</sub> |
| COMMON GROUPS             | 2 × 8 common   | 2 × 8 common   | 2 × 8 common   | 2 × 8 common   |
| CONNECTOR TYPE            | <u>Default:</u> BL 3.5<br><u>Options:</u> -              | <u>Default:</u> BL 3.5<br><u>Options:</u> -              | <u>Default:</u> BL 3.5<br><u>Options:</u> -              | <u>Default:</u> BL 3.5<br><u>Options:</u> -              |

\*Obsolete module. These modules are not recommended for new designs! O15+ modules are recommended instead (see above).

Main features:

- Digitally filtered per channel
- Current drain:
  - max. 1.6 mA per channel at 220 V DC
  - max. 1.8 mA per channel at 110 V DC
  - max. 2 mA per channel at 48 V DC
  - max. 3 mA per channel at 24 V DC
- In such applications where the input voltage is 60 V the modules with 48 V rated voltage can be used.
- Input voltage type can be either DC or AC voltage. If AC voltage is used make sure that the type and the parameters of the binary inputs are configured properly in EuroCAP tool.




Figure 7-1 Binary input modules



## 1.2.9. Signaling module


The signaling module has 4, 8, 12 or 16 relay outputs with dry contacts.

### Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.

| MODULE TYPE      | R4+/01                                   | R8+/00                                      | R8+/80                                   | R8+/C0                                   |
|------------------|--|---|--|--|
| RATED VOLTAGE    | 250 V AC/DC                              | 250 V AC/DC                                 | 250 V AC/DC                              | 250 V AC/DC                              |
| CONTINUOUS CARRY | 8 A                                      | 8 A   | 8 A                                      | 8 A                                      |
| CONTACT VERSIONS | 4 CO                                     | 8 NO  | CH8 NC<br>others NO                      | CH7 and CH8<br>NC<br>others NO           |
| GROUP ISOLATION  | 4<br>independent                         | 8<br>independent                            | 8<br>independent                         | 8 independent                            |
| CONNECTOR TYPE   | <u>Default:</u> BLA<br><u>Options:</u> F | <u>Default:</u> BLA<br><u>Options:</u> F, T | <u>Default:</u> BLA<br><u>Options:</u> T | <u>Default:</u> BLA<br><u>Options:</u> T |

| MODULE TYPE      | R8+/FF                                   | R12+/0000                                   | R12+/4000                                   |
|------------------|--|---|---|
| RATED VOLTAGE    | 250 V AC/DC                              | 250 V AC/DC                                 | 250 V AC/DC                                 |
| CONTINUOUS CARRY | 8 A                                      | 8 A   | 8 A   |
| CONTACT VERSIONS | 8 NC                                     | 12 NO                                       | CH12 NC<br>others NO                        |
| GROUP ISOLATION  | 8<br>independent                         | 4 × 3<br>common                             | 4 × 3 common                                |
| CONNECTOR TYPE   | <u>Default:</u> BLA<br><u>Options:</u> - | <u>Default:</u> BLA<br><u>Options:</u> F, T | <u>Default:</u> BLA<br><u>Options:</u> F, T |



| MODULE TYPE      | R16+/0000                                | R16+/8000                                | R16+/8080                                |
|------------------|--|--|--|
| RATED VOLTAGE    | 250 V AC/DC                              | 250 V AC/DC                              | 250 V AC/DC                              |
| CONTINUOUS CARRY | 8 A                                      | 8 A                                      | 8 A                                      |
| CONTACT VERSIONS | 16 NO                                    | CH16 NC<br>others NO                     | CH16 and CH8 NC<br>others NO             |
| GROUP ISOLATION  | 2 × 8 common                             | 2 × 8 common                             | 2 × 8 common                             |
| CONNECTOR TYPE   | <u>Default:</u> BLA<br><u>Options:</u> - | <u>Default:</u> BLA<br><u>Options:</u> - | <u>Default:</u> BLA<br><u>Options:</u> - |

| MODULE TYPE      | R4S+/01*                                 | R4S+/16*                                 | R1T+/0001***                             |
|------------------|--|--|--|
| RATED VOLTAGE    | 250 V AC/DC                              | 250 V AC/DC                              | 320 V AC/DC                              |
| CONTINUOUS CARRY | 8 A<br>120 mA**                          | 120 mA                                   | 32 A                                     |
| CONTACT VERSIONS | 4 CO<br>(1 SSR, 3 normal)                | 4 CO<br>(4 SSR)                          | 1 NO                                     |
| GROUP ISOLATION  | 4 independent                            | 4 independent                            | 1 independent                            |
| CONNECTOR TYPE   | <u>Default:</u> BLA<br><u>Options:</u> - | <u>Default:</u> BLA<br><u>Options:</u> - | <u>Default:</u> BLA<br><u>Options:</u> - |

\*Modules with **solid-state relays (SSR)**

\*\*If the signaling is performed via the solid-state relay the continuous carry value is 120 mA.

\*\*\***Thyristor module.** Can be used only unipolarly. For further information see our [Product availability chapter](#).

Main features (according to IEC 60255-1):

- Maximum switching voltage: 400 V AC
- Breaking capacity: (L/R=40 ms) at 220 V DC: 0.2 A, at 110 V DC: 0.3 A
- Breaking capacity max.: 2000 VA
- Short time carrying capacity: 1 s, 35 A
- Limiting making current, max. 4 s: 15 A (df = 10 %)
- Dielectric strength between open contacts, 1 min: 1000 V<sub>RMS</sub>
- Mechanical endurance: 10 × 10<sup>6</sup> cycles
- Circuit closing capability: typically 10 ms, maximally 22 ms, with SSR 0.5 ms.
- Bounce time: typically 6,5 ms, maximally 10 ms, with SSR 0.5 ms.
- Minimal switching requirement: 5 V
- *The signaling is also performed via a solid-state relay (SSR) channel on R4S+01 and R4S+16 module*




Figure 8-1 Signaling modules

## 1.2.10. Tripping module

The tripping module is a proprietary and patented solution that facilitates direct control of a circuit breaker.

### Connector types:

- The default and optionally available connector types are indicated for each module in the table below. See Chapter 20.2 for details about each type.

| MODULE TYPE               | TRIP+/4201                                  | TRIP+1101*                               | TRIP+/2101                                  | TRIP+/21F1**                             | TRIP+/2201                               |
|---------------------------|---|--|---|--|--|
| CHANNEL NUMBER            | 4   | 4  | 4   | 4  | 4  |
| RATED VOLTAGE             | 24 V DC and 48 V DC                         | 110 V DC                                 | 110 V DC                                    | 110 V DC                                 | 220 V DC                                 |
| THERMAL WITHSTAND VOLTAGE | 72 V DC                                     | 242 V DC                                 | 150 V DC                                    | 150 V DC                                 | 242 V DC                                 |
| CONTINUOUS CARRY          | 8 A   | 8 A                                      | 8 A   | 8 A                                      | 8 A                                      |
| MAKING CAPACITY           | 0.5 s, 30 A                                 | 0.5 s, 30 A                              | 0.5 s, 30 A                                 | 0.5 s, 30 A                              | 0.5 s, 30 A                              |
| BREAKING CAPACITY         | L/R = 40 ms:<br>4 A DC                      | L/R = 40 ms:<br>4 A DC                   | L/R = 40 ms:<br>4 A DC                      | L/R = 40 ms:<br>4 A DC                   | L/R = 40 ms:<br>4 A DC                   |
| CONNECTOR TYPE            | <u>Default:</u> BLA<br><u>Options:</u> F, T | <u>Default:</u> BLA<br><u>Options:</u> - | <u>Default:</u> BLA<br><u>Options:</u> F, T | <u>Default:</u> BLA<br><u>Options:</u> T | <u>Default:</u> BLA<br><u>Options:</u> T |

**\*Obsolete module. These modules are not recommended for new designs!**

**\*\*Without trip circuit supervision.**

Main features:

- High-speed operation: with pre-trip 0.5 ms, without pre-trip typically 10 ms, maximally 22 ms.
- Trip circuit supervision for each trip contact, except TRIP+21F1
- With 2-wire wiring, the tripping output can be *dry* contact type, too




Figure 9-1 Tripping modules

### 1.2.10.1. TRIP+ module wiring

The tripping module provides tripping circuit supervision function (TCS). The wiring of these modules can be 2-wire or 3-wire. (TCS function is active for all wiring methods.)

The voltage of the "No" contact is maximized at 15 V by a Zener-diode. Make sure that the voltage caused by the resistance of the circuit breaker and the injected current from the TRIP+ module does not reach 10 V.

Our TRIP+ modules are improved to switch DC circuits. **Using reversed polarity or AC voltage can cause the damage of the internal circuits. Improper wiring might cause improper operation!**

#### 1.2.10.1.1. 3-wire TRIP+ wiring methods




Figure 9-2 3-wire TRIP+ wiring

It is possible to use parallel connected TRIP+ modules. In this case the negative terminals must be common.




Figure 9-3 3-wire TRIP+ wiring using parallel connected TRIP+ modules

### 1.2.10.1.2. 2-wire TRIP+ wiring methods

If necessary, the TRIP+ modules can be wired using only the “+” and the “No” contacts.




Figure 9-4 2-wire TRIP+ wiring

It is possible to use parallel connected TRIP+ modules.




Figure 9-5 2-wire TRIP+ wiring using parallel connected TRIP+ modules



If the circuit breaker needs two-pole switching TRIP+ modules can be connected series as you can see in Figure 9–6.




Figure 9-6 2-wire TRIP+ wiring using series connected TRIP+ modules


## 1.2.10.2. Trip Circuit Supervision (TCS)

Apart from the TRIP+/21F1, all TRIP modules have TCS. The feature is described in detail (tech. data, instructions, etc.) in a separate document:

[https://www.protecta.hu/downloads/tcs\\_en](https://www.protecta.hu/downloads/tcs_en)

The technical data of the TCS is shown here as well:

|  | MODULE TYPE                                | TRIP+/4201  | TRIP+/2101   | TRIP+/2201                |
|--|--|---|--|---------------------------|
|  | VALUE OF R RESISTOR ( $\pm 10\%$ )         | 10 k $\Omega$   | 73 k $\Omega$  | 130 k $\Omega$            |
|  | INJECTED CURRENT AT "NO" CONTACT           | 2.4 mA @ 24 V DC<br>4.8 mA @ 48 V DC                  | 1.5 mA @ 110 V DC                                      | 1.7 mA @ 220 V DC         |
| <b>MAXIMUM RESISTANCE OF THE TRIP COIL</b> | 3-WIRE WIRING (MAX. 10 V)                  | 11.8 k $\Omega$ @ 24 V DC<br>3.7 k $\Omega$ @ 48 V DC | 9.7 k $\Omega$ @ 110 V DC<br>8.4 k $\Omega$ @ 125 V DC | 8.1 k $\Omega$ @ 220 V DC |
|  | 3-WIRE WIRING WITH IN PARALLEL (MAX. 10 V) | 5.9 k $\Omega$ @ 24 V DC<br>1.8 k $\Omega$ @ 48 V DC  | 4.8 k $\Omega$ @ 110 V DC<br>4.2 k $\Omega$ @ 125 V DC | 4 k $\Omega$ @ 220 V DC   |
|  | 2-WIRE METHOD (1 mA MIN. CURRENT)          | 14 k $\Omega$ @ 24 V DC<br>38 k $\Omega$ @ 48 V DC    | 37 k $\Omega$ @ 110 V DC<br>52 k $\Omega$ @ 125 V DC   | 90 k $\Omega$ @ 220 V DC  |



### **1.2.10.3. Relay output modules of the EuroProt+ system**

#### **1.2.10.3.1. Types of the relay output modules of the EuroProt+ system**

Basically there are two different types of relay output modules in the EuroProt+ devices: TRIP relay output module for high-speed operation of the circuit breakers Signal relay output module

#### **1.2.10.3.2. Operating modes of the relay contacts**

For operation of the relay output modules there are four different modes:

Application of TRIP relays for commands of fast protection functions

User application of the TRIP relays Fast operation of any relay contacts (TRIP relays or signal relays) Control of signal relay outputs.

The procedures of command processing are shown in. This document describes the details using the TRIP relay contacts as an example.

The left side of the Figure shows the available sources of the trip commands:

The functionblocks, configured in the device,

The communication channels to the SCADA system,

Commands generated using the front panel LCD of the device,

Any other binary signals, e.g. signals from the binary inputs of the device.

The right side of the Figure shows one of the TRIP relays symbolically.

The Figure provides a survey of the configured trip command processing methods. In the middle of the Figure, the locations indicated by "User" shows the possibilities for the user to modify the procedures. All other parts are factory programmed.





Figure 1-1 Principle of TRIP command processing



### **1.2.10.3.3. Application of TRIP relays for commands of fast protection functions**

#### **1.2.10.3.3.1. Aim of application of TRIP relays**

The main aim of application of TRIP relays is to bypass the time delay of the mechanical contacts. For this aim there is a „slow” mechanical contact and a „fast” electronic switch in serial connection.

#### **1.2.10.3.3.2. Control of the TRIP relays**

The operation of the TRIP relays is performed in two steps:  
Preparation of the circuit for the trip command  
Trip command generation

##### **1.2.10.3.3.2.1. Preparation of the circuit for the trip command**

At the time when a protection function detects violation of the setting value of the characteristic quantity, the preparation process closes the „slow” mechanical contact, preparing the circuit for command generation.

##### **1.2.10.3.3.2.2. The trip command generation**

At the moment when the fast protection function – after some repeated checks, i.e. the timeout of the internal time counter – decides to generate the trip command then the „fast” electronic switch performs the operation, generating the trip command to the circuit breaker. This command is generated via the „TRC94\_ PhS” or via the simplified „TRC94” trip logic functionblocks.

NOTE: If the TRIP command is not received within the expected time delay, then the command preparation resets after 50 ms. When the device is tested in the laboratory e.g. for measuring the limits of the distance protection characteristic, this can result a cyclic closing and opening of the mechanical contact and rattling can be heard. This does not mean faulty operation of the device!

##### **1.2.10.3.3.3. The factory programming for relay control**

For the trip command of protection functions, where the requirement is the fast operation (distance protection first zone, line differential protection, transformer differential protection, fast overcurrent stage, synchronous switching, etc.) the process of preparation and command generation is programmed in the form of „Fast logic”.


The alignment of the TRIP command is the task of the “TRIP logic functionblock”. All devices operating with TRIP binary output module, has a configured TRC 94 simplified, or a TRC 94\_PhS TRIP logic functionblock. This converts e.g. the trip command due to phase-to-phase fault to a three-phase trip command, or extends the duration of the command according to the parameter setting. All these are described in the dedicated document.

The fast TRIP commands are assigned to the TRIP relay output contacts according to the factory configuration, but the user has a possibility to modify or extend this assignment using the EuroCAP configuration software. The factory assignment is described in the user manual of the given device configuration.

To ensure fast operation, this „Fast logic” is performed in each sampling cycle (1ms).


### 1.2.10.3.3.4. Changing the TRIP command assignment

The user has a possibility to modify or extend the TRIP command assignment using the EuroCAP configuration software. The menu item to be started is shown in *Figure 2-1*.




*Figure 2-1 Menu item for TRIP command assignment*

As *Figure 2-2* shows, the signal of type „TripLogic Output” (this is the command generated by the „TRIP logic functionblock”) can be assigned to a „Trip Contact” type relay output. The dialog window of the EuroCAP software selects these types of signals only; the available signals however can be assigned freely.




*Figure 2-2 Changing the TRIP command assignment*



The assigned signal is the input of an OR gate. As it is described below, several other signals can be directed to this OR gate. Using this method, also other TRIP modules extended by the user can be applied to operate the TRIP coil of the circuit breaker.


### 1.2.10.3.3.5. Fast operation of the relays

If the aim is to operate the contacts by a signal in each sampling cycle (1 ms), then the “Fast L1 contact option is to be applied. This option is provided by the EuroCAP configuration software in the menu „Hardware configuration/ IO signals/ Binary outputs/ Relay contacts/ Fast\_L1 contacts”.



*Figure 2-3 Configuring Fast L1 contacts*

This menu offers the assignment of the appropriate binary signals to the relay contacts. As [Figure 2-4](#) shows, the signal can be of several types.



*Figure 2-4 Fast L1 contact assignment*

The processing of these fast signals is performed in a single step, the possibility for command preparation in the first step and additionally the TRIP command generation in the second step is not offered for the user. To perform this assignment, the application of the EuroCap configuration program in “Master” level is needed.

The selected signal is the input of an OR gate. To this gate additional other signals are connected, as it is described in the previous chapter, or in the description below.

**IMPORTANT NOTE:** The contacts of a TRIP hardware module are configured in the factory as “Fast L1 contacts”, the user does not need to define them additionally!


#### **1.2.10.3.4. User application of the TRIP relays**

The contacts controlling the circuit breaker operation can be programmed also by the user. Additionally to the command of the factory configured protection functions the user can assign signals to the channels of the TRIP hardware module. The two steps for the command generation however, as it is described in the paragraph above, cannot be applied by the user.

In this case, the source of the signals can be:

- Pre-configured TRIP commands
  - Received from the SCADA system via communication channels,
  - Generated by the user, applying the front panel LCD of the device,
- Any additional binary signals, e.g. an external command received by the binary input module of the device.

The pre-configured TRIP commands are aligned by the “CB control functionblock”, the output of which is the “CmdOff” TRIP command. This one and several other



signals can be programmed by the user to the output TRIP contact of the device, using the graphic logic editor of the EuroCAP configuration software.

Additionally the output signals of the „TRC94\_PhS” trip logic or those of the „TRC94” simplified trip logic block can be programmed here. (These function-blocks are described in separate documents.) The output signal of the graphic logic editor is the „BOut\_X” logic variable, where X is the identifier of the relay module and the contact, e.g. BOut\_E02.

### **1.2.10.3.4.1. Graphic editor for the signal logic**

For the protection functions, the operation of which are not required being extreme fast (in the range of one network period), the trip command must be assigned to the trip contacts usually by the user. These logic assignments can be programmed also in the factory, but the user can modify or extend them according to the requirements. To do this, the graphic editor of the EuroCap configuration tool must be applied with „Master” access rights.

### **1.2.10.3.4.2. The process of command generation**

If a “simple” protection function generates a trip command then this logic signal is present on the dedicated output of the functionblock (see the description of the functionblocks).

The operation of the logic connections edited in the graphic editor is performed outside the sampling cycle, consequently, depending on the actual load of the processor a random time delay of additional 2-4 ms can be measured.

The contacts of the TRIP hardware modules are operated by several sources parallel:

The high-speed factory configured fast protection functions,  
The defined Fast L1 signals,  
The graphically edited logic connections (programmed in the factory and editable also by the user).


### **1.2.10.3.5. Control of signal relay outputs**

If there is no special requirement to generate the signal with high speed, i.e. a time delay of 2-4 ms can be tolerated between the intent to generate the signal and the closing of the output contact then it is sufficient to apply normal signal relay contacts. To perform this programming the graphic editor of the EuroCap configuration tool is to be applied. To perform the programming the „Master” access level is needed.



## 1.2.10.4. Examples

### 1.2.10.4.1. Application of the TRIP logic



*Figure 5-1 Example: A simple configuration to trip the circuit breaker*

*Figure 5-1* shows a simple configuration to trip the circuit breaker. In this Figure it is supposed that the fast protection functions operate according to the factory configuration and they control the TRIP contacts applying two steps of the preparation and command generation phases. This part of the program is not visible. (The description of the fast operating protection functions are listed in the configuration description of the devices.)

The outputs of the TRC94\_PhS trip logic block are assigned to the channels of the TRIP hardware module. This assignment, which can be modified also by the user, is made not here but in the “TRIP assignment” menu of the EuroCAP configuration software. Consequently the Figure is complete; related to the outputs, the user needs additional graphic programming only if e.g. the operation is to be visualized also by signal relays.

If the configuration includes protection functions blocks the trip command of which does not need fast contact operation then these commands must be additionally directed to the TRIP relay outputs. To do this, the user collects these commands (with OR connection) and connects them to the dedicated inputs of the TRC94\_PhS functionblock.

This Figure shows the collected signals (E.g. “Trip\_SinglePh”, “Trip\_3Ph”, etc.) only. As an example the „Trip\_3Ph” signal collects the commands of all (not fast operating) protection functions which can generate three-phase trip command. The detailed description of the inputs and operation of the “TRC94\_PhS” trip logic functionblock can be found in another document.

## 1.2.10.4.2. Application of circuit breaker control block





Figure 5-2 Example: Application of circuit breaker control block

Figure 5-2 shows an example for the application of the circuit breaker control block “CB3Pol”. In this Figure it is supposed that the fast protection functions operate according to the factory configuration and they control the TRIP contacts applying two steps of the preparation and command generation phases. This part of the program is not visible. (The description of the fast operating protection functions are listed in the configuration description of the devices.)

The outputs of the TRC94\_PhS trip logic block are assigned to the channels of the TRIP hardware module. This assignment, which can be modified also by the user, is made not here but in the “TRIP assignment” menu of the EuroCAP configuration software. Consequently the Figure is complete; related to the outputs, the user needs additional graphic programming only if e.g. the operation is to be visualized also by signal relays.

If the configuration includes protection functions blocks the trip command of which does not need fast contact operation then these commands must be additionally connected to the TRIP relay outputs. To do this, the user collects these commands (with OR connection) and assigns them to the dedicated inputs of the TRC94\_PhS functionblock.

This Figure shows the collected signals (E.g. “Trip\_SinglePh”, “Trip\_3Ph”, etc.) only. As an example the „Trip\_3ph” signal collects the commands of all (not fast operating) protection functions which can generate three-phase trip command. The detailed description of the inputs and operation of the “TRC94\_PhS” trip logic functionblock can be found in another document.



An extension to the example in *Figure 5-2* is that in this configuration also the „CB3pol” (circuit breaker control block) is applied. This block is needed if e.g. the front panel LCD of the device can display an active control scheme. For this purpose the signals „BIn\_F...” in the Figure are the status signals of the circuit breaker poles, connected to the dedicated binary inputs of the device. The signals „Local”/”Remote” enable the local or remote control of the primary equipment. In the standard factory configurations these signals are programmed in the factory, but they can be modified also by the user.

If there is no synchro-check function activated in the device, connect the input „SynOK” of the “CB3Pol” to logic TRUE state. *Figure 5-2*, the local command issued via LCD of the device or the remote command received from the remote SCADA system is processed by the „CB3pol” functionblock (Output „CmdOff”). This control is programmed in the factory to “BOut\_xx” variables. The user can perform any modification in the graphic programming.

The close command is connected directly to a dedicated “BOut\_xx” variable. (This directs usually the fourth contact of the TRIP hardware module.)

The programming of the interlocking function must be performed by the user.

### 1.2.10.4.3. Automatic reclosing and circuit breaker control





Figure 5-3 Example: Automatic reclosing and circuit breaker control

Figure 5-3 shows an example for the application of the automatic reclosing control block. In this Figure it is supposed that the fast protection functions operate according to the factory configuration and they control the TRIP contacts applying two steps of the preparation and command generation phases. This part of the program is not visible in “Master” level. (The description of the fast operating protection functions are listed in the configuration description of the devices.)

The outputs of the TRC94\_PhS trip logic block are assigned to the output channels of the TRIP hardware module. This assignment, which can be modified also by the user, is made not here but in the “TRIP assignment” menu of the EuroCAP configuration software. Consequently the Figure is complete; related to the outputs, the user needs additional graphic programming only if e.g. the operation is to be visualized also by signal relays.

If the configuration includes protection functions blocks the trip command of which does not need fast contact operation then these commands must be additionally assigned to the TRIP relay outputs. To do this, the user collects these commands (with OR connection) and assigns them to the dedicated inputs of the TRC94\_PhS functionblock.

This Figure shows the collected signals (E.g. “Trip\_SinglePh”, “Trip\_3Ph”, etc.) only. As an example the „Trip\_3ph” signal collects the commands of all (not fast operating) protection functions which can generate three-phase trip command. The detailed description of the inputs and operation of the “TRC94\_PhS” trip logic functionblock can be found in another document.



In this configuration also the „CB3pol” (circuit breaker control block) is applied. This block is needed if e.g. the front panel LCD of the device can display an active control scheme. For this purpose the signals „BIn\_F...” in the Figure are the status signals of the circuit breaker poles, connected to the dedicated binary inputs of the device. The signals „Local”/”Remote” enable the local or remote control of the primary equipment. In the standard factory configurations these signals are programmed in the factory, but they can be modified also by the user.

If there is no synchro-check function activated in the device, connects the input „SynOK” of the “CB3Pol” to logic TRUE state.

According to [Figure 5-3](#), the local command issued via LCD of the device or the remote command received from the remote SCADA system is processed by the „CB3pol” functionblock (Output „CmdOff”). This control is programmed in the factory to “BOut\_xx” variables. The user can perform any modification in the graphic programming.

The close command is connected directly to a dedicated “BOut\_xx” variable. (This directs usually the fourth contact of the TRIP hardware module.)

In [Figure 5-3](#) the close command is connected directly to a dedicated output. (This is usually the fourth contact of the TRIP hardware module.)

The programming of the interlocking function must be performed by the user.

An extension to the example in [Figure 5-2](#) is the application of the „REC79\_HV” automatic reclosing function. The start signal „Trip\_StartAR” can be programmed by the user. The automatic reclosing function is started only if the preceding trip command was performed by the circuit breaker, i.e. for example that the function is not disabled. The AND gate on this Figure performs this checking.

The „REC79\_HV” automatic reclosing function needs the status signal indicating three-phase open state of the circuit breaker, connected to the „3PhTr” input of the „REC79\_HV” functionblock. This signal is generated by the „TRC94\_PhS” functionblock on the output „Tr3Ph”.

If the automatic reclosing is to be disabled after a fault caused by a manual close command, then the „CmdOn” output of the „CB3Pol” module must be connected to the „ManCl” input of the „REC79\_HV” automatic reclosing function.

If there is no synchro-check function configured in the device, connect the „SynRel” input of the „REC79\_HV” automatic reclosing function to logic TRUE state.

The evaluation of the status signals indicating the open state of the circuit breaker poles in OR gate is needed for the operation of the automatic reclosing function. According to the scheme of [Figure 5-3](#) the open state is indicated by at least one pole open state of the circuit breaker. (For simplicity, this Figure shows a realization without checking the FALSE signal of the closed states.)

[Figure 5-3](#) supposes that the CB ready signal is not connected to the device; accordingly the steady TRUE state signal is connected to the „CBRdy” input of the „REC79\_HV” automatic reclosing function. If the real signal is available, the signal must be connected similarly.

The close command of the „REC79\_HV” automatic reclosing function is connected via OR gate to the dedicated close contact.

## 1.2.10.4.4. Closing the circuit breaker with synchro-check





Figure 5-4 Example: closing the circuit breaker with synchro-check

Figure 5-4 shows an example for the application of “SYN25” synchro-check function block. In this Figure it is supposed that the fast protection functions operate according to the factory configuration and they control the TRIP contacts applying two steps of the preparation and command generation phases. This part of the program is not visible in “Master” level. (The description of the fast operating protection functions are listed in the configuration description of the devices.)

The outputs of the TRC94\_PhS trip logic block are assigned to the output channels of the TRIP hardware module. This assignment, which can be modified also by the user, is made not here but in the “TRIP assignment” menu of the EuroCAP configuration software. Consequently the Figure is complete; related to the outputs, the user needs additional graphic programming only if e.g. the operation is to be visualized also by signal relays.

If the configuration includes protection functions blocks the trip command of which does not need fast contact operation then these commands must be additionally assigned to the TRIP relay outputs. To do this, the user collects these commands (with OR connection) and assigns them to the dedicated inputs of the TRC94\_PhS function block.

This Figure shows the collected signals (E.g. “Trip\_SinglePh”, “Trip\_3Ph”, etc.) only. As an example the „Trip\_3ph” signal collects the commands of all (not fast operating) protection functions which can generate three-phase trip command. The detailed description of the inputs and operation of the “TRC94\_PhS” trip logic function block can be found in another document.



In this configuration also the „CB3pol” (circuit breaker control block) is applied. This block is needed if e.g. the front panel LCD of the device can display an active control scheme. For this purpose the signals „BIn\_F...” in the Figure are the status signals of the circuit breaker poles, connected to the dedicated binary inputs of the device. The signals „Local”/„Remote” enable the local or remote control of the primary equipment. In the standard factory configurations these signals are programmed in the factory, but they can be modified also by the user.

According to *Figure 5-4*, the local command issued via LCD of the device or the remote command received from the remote SCADA system is processed by the „CB3pol” functionblock (Output „CmdOff”). This control is programmed in the factory to “BOut\_xx” variables. The user can perform any modification in the graphic programming.

The close command is connected directly to a dedicated “BOut\_xx” variable. (This directs usually the fourth contact of the TRIP hardware module.)

In *Figure 5-4* the close command is connected directly to a dedicated output. (This is usually the fourth contact of the TRIP hardware module.)

The programming of the interlocking function must be performed by the user.

*Figure 5-4* includes the application of the „REC79\_HV” automatic reclosing function. The start signal „Trip\_StartAR” can be programmed by the user. The automatic reclosing function is started only if the preceding trip command was performed by the circuit breaker, i.e. for example that the function is not disabled. The AND gate on this Figure performs this checking.

The „REC79\_HV” automatic reclosing function needs the status signal indicating three-phase open state of the circuit breaker, connected to the „3PhTr” input of the „REC79\_HV” functionblock. This signal is generated by the „TRC94\_PhS” functionblock on the output „Tr3Ph”.

If the automatic reclosing is to be disabled after a fault caused by a manual close command, then the „CmdOn” output of the „CB3Pol” module must be connected to the „ManCl” input of the „REC79\_HV” automatic reclosing function.

The evaluation of the status signals indicating the open state of the circuit breaker poles in OR gate is needed for the operation of the automatic reclosing function. According to the scheme of *Figure 5-4* the open state is indicated by at least one pole open state of the circuit breaker. (For simplicity, this Figure shows a realization without checking the FALSE signal of the closed states.)

*Figure 5-4* supposes that the CB ready signal is not connected to the device; accordingly the steady TRUE state signal is connected to the „CBRdy” input of the „REC79\_HV” automatic reclosing function. If the real signal is available, the signal must be connected similarly.

The close command of the „REC79\_HV” automatic reclosing function is connected via OR gate to the dedicated close contact.

An extension to the example in *Figure 5-3* is the close command to the circuit breaker is generated by synchro-check. The enabling signal for the close command is generated by the „SYN25” software module. This module is described in details in a separate document. The needed input signals indicating the state of the voltage transformers („VTSBIk” and „Bus1VTSBIk”), must be programmed graphically.

The output signal „RelA” of the „SYN25” software module enables the closing operation of the „REC79\_HV” automatic reclosing function via its „SynRel” input.

For manual close commands the output signal „RelM” of the „SYN25” software module enables the closing operation of the „CB3pol” via its „SynOK” input.



## 1.2.10.4.5. Closing the circuit breaker with synchro-check and synchro-switch





Figure 5-5 Example: closing the circuit breaker with synchro-check and synchro- switch

Figure 5-5 shows an example for the application of “SYN25” cynchro-check functionblock with synchro switch extension. In this Figure it is supposed that the fast protection functions operate according to the factory configuration and they control the TRIP contacts applying two steps of the preparation and command generation phases. This part of the program is not visible in “Master” level. (The description of the fast operating protection functions are listed in the configuration description of the devices.)

The outputs of the TRC94\_PhS trip logic block are assigned to the output channels of the TRIP hardware module. This assignment, which can be modified also by the user, is made not here but in the “TRIP assignment” menu of the EuroCAP configuration software. Consequently the Figure is complete; related to the outputs, the user needs additional graphic programming only if e.g. the operation is to be visualized also by signal relays.

If the configuration includes protection functions blocks the trip command of which does not need fast contact operation then these commands must be additionally assigned to the TRIP relay outputs. To do this, the user collects these commands





(with OR connection) and assigns them to the dedicated inputs of the TRC94\_PhS functionblock.

This Figure shows the collected signals (E.g. “Trip\_SinglePh”, “Trip\_3Ph”, etc.) only. As an example the „Trip\_3ph” signal collects the commands of all (not fast operating) protection functions which can generate three-phase trip command. The detailed description of the inputs and operation of the “TRC94\_PhS” trip logic functionblock can be found in another document.

In this configuration also the „CB3pol” (circuit breaker control block) is applied. This block is needed if e.g. the front panel LCD of the device can display an active control scheme. For this purpose the signals „BIn\_F...” in the Figure are the status signals of the circuit breaker poles, connected to the dedicated binary inputs of the device. The signals „Local”/”Remote” enable the local or remote control of the primary equipment. In the standard factory configurations these signals are programmed in the factory, but they can be modified also by the user.

According to *Figure 5-5*, the local command issued via LCD of the device or the remote command received from the remote SCADA system is processed by the „CB3pol” functionblock (Output „CmdOff”). This control is programmed in the factory to “BOut\_xx” variables. The user can perform any modification in the graphic programming.

The close command is connected directly to a dedicated “BOut\_xx” variable. (This directs usually the fourth contact of the TRIP hardware module.)

In *Figure 5-5* the close command is connected directly to a dedicated output. (This is usually the fourth contact of the TRIP hardware module.)

The programming of the interlocking function must be performed by the user.

*Figure 5-5* includes the application of the „REC79\_HV” automatic reclosing function. The start signal „Trip\_StartAR” can be programmed by the user. The automatic reclosing function is started only if the preceding trip command was performed by the circuit breaker, i.e. for example that the function is not disabled. The AND gate on this Figure performs this checking.

The „REC79\_HV” automatic reclosing function needs the status signal indicating three-phase open state of the circuit breaker, connected to the „3PhTr” input of the „REC79\_HV” functionblock. This signal is generated by the „TRC94\_PhS” functionblock on the output „Tr3Ph”.

If the automatic reclosing is to be disabled after a fault caused by a manual close command, then the „CmdOn” output of the „CB3Pol” module must be connected to the „ManCl” input of the „REC79\_HV” automatic reclosing function.


If there is no synchro-check function configured in the device, then connect the „SynRel” input of the „REC79\_HV” automatic reclosing function to logic TRUE state.

The evaluation of the status signals indicating the open state of the circuit breaker poles in OR gate is needed for the operation of the automatic reclosing function. According to the scheme of *Figure 5-5* the open state is indicated by at least one pole open state of the circuit breaker. (For simplicity, this Figure shows a realization without checking the FALSE signal of the closed states.)

*Figure 5-5* supposes that the CB ready signal is not connected to the device; accordingly the steady TRUE state signal is connected to the „CBRdy” input of the „REC79\_HV” automatic reclosing function. If the real signal is available, the signal must be connected similarly.

The close command of the „REC79\_HV” automatic reclosing function is connected via OR gate to the dedicated close contact.

In this application the close command to the circuit breaker is generated by synchro-check. The enabling signal for the close command is generated by the „SYN25” software module. This module is described in details in a separate document. The



needed input signals indicating the state of the voltage transformers („VTSBik” and „Bus1VTSBik”), must be programmed graphically.

The output signal „RelA” of the „SYN25” software module enables the closing operation of the „REC79\_HV” automatic reclosing function via its „SynRel” input.

For manual close commands the output signal „RelM” of the „SYN25” software module enables the closing operation of the „CB3pol” via its „SynOK” input.

An extension to the example in *Figure 5-4* is the following: If there is no continuous synchron state because the frequency at one side of the circuit breaker is different to that of the other side, then the voltage vector of one side rotates continuously as compared to the other one. In this case a synchronous switching is attempted to restore the normal operation of the network.

The manual synchron switching mode is started by the signal on the „StSwM” input of the SYN25 functionblock. To do this the the „StartSW” output of the „CB3Pol” functionblock must be connected here.

For automatic synchron switching mode the „CIReq” output of the „Rec79HV” module must be connected to the „SwStA” input of the „SYN25” software module.

**IMPORTANT NOTE:** the close command is generated for both manual and automatic

switching at the output „SynSW” of the „SYN25” software module. It is advised not to connect this output using the „slow” graphic programming, but the contact assigned to the close command („BOutClose”) must be handled as fast operating „L1 contact”. The „SynSW” signal must be programmed to this contact. This assignment is performed using the EuroCap configuration tool in the menu „Hardware configuration/Binary outputs/Relay contacts/Fast\_L1 contacts”.

## 1.2.11. RTD input module

The RTD+1100 module is used to measure the temperature through the variation of resistance of temperature detectors. RTD+0200 and RTD+1200 are special modules for Petersen coil controllers (DRL) measuring the resistance of the potentiometer.

Connector types:

- The default and optionally available connector types are indicated for each module in the table below. See Chapter 20.2 for details about each type.

| MODULE TYPE             | RTD+/0200*                               | RTD+/1100  | RTD+/1200*                               |
|-------------------------|--|--|--|
| CHANNEL NUMBER          | 1  | 4  | 1  |
| MEASUREMENT METHOD      | 3 wire configuration                     | 2, 3 or 4 wire configuration   | 3 wire configuration                     |
| ACCURACY                | ± 0.5 % ± 1 digit                        | ± 0.5 % ± 1 digit  | ± 0.5 % ± 1 digit                        |
| SENSOR TYPE             | Service-Ohm                              | Pt100/Ni100<br>Ni120/Ni120US<br>Pt250/Ni250<br>Pt1000/Ni1000<br>Cu10<br>Service-Ohm<br>(60 Ω ... 1.6 kΩ) | Service-Ohm                              |
| MEASUREMENT RANGES      | 2 Ω ... 200 Ω                            | - 50 °C – +150 °C  | 10 Ω ... 1000 Ω                          |
| CONNECTOR TYPE          | <u>Default:</u> BLA<br><u>Options:</u> - | <u>Default:</u> BLA<br><u>Options:</u> T   | <u>Default:</u> BLA<br><u>Options:</u> - |
| RECOMMENDED APPLICATION | Arc suppression coil controller          | General resistance-based temperature measurement   | Arc suppression coil controller          |

\*Special module




Figure 10-1 RTD input modules

### 1.2.11.1. RTD module wiring

If 2-wire wiring is used you have to make sure that the value of RA and RD resistors are set correctly in the “parameters” menu of the web server.




Figure 10-2 2-wire RTD wiring




Figure 10-3 3-wire RTD wiring




Figure 10-4 4-wire RTD wiring




Figure 10-5 4-wire RTD wiring of potentiometer

## 1.2.12. Analog input module (AI)

The analog input module accepts transducers' current outputs. The AIC module can measure unipolar and bipolar current values in wide ranges.

Connector types:

- The default and optionally available connector types are indicated for each module in the table below. See Chapter 20.2 for details about each type.

| MODULE TYPE        | AIC+/0200*   | AIC+/0201*   | AIC+/0202  |
|--------------------|--|--|--|
| CHANNEL NUMBER     | 4  | 4  | 4  |
| MEASUREMENT METHOD | 2 wire inputs  | 2 wire inputs with optional 12 V excitation                      | 2 wire inputs  |
| RELATIVE ACCURACY  | $\pm 0.5 \% \pm 1$ digit   | $\pm 0.5 \% \pm 1$ digit   | $\pm 0.5 \% \pm 1$ digit   |
| MEASUREMENT RANGES | $\pm 20$ mA<br>(typical 0-20, 4-20 mA)<br>$R_{LOAD} = 56 \Omega$ | $\pm 20$ mA<br>(typical 0-20, 4-20 mA)<br>$R_{LOAD} = 56 \Omega$ | $\pm 20$ mA<br>(typical 0-20, 4-20 mA)<br>$R_{LOAD} = 56 \Omega$ |
| CONNECTOR TYPE     | Default: BLA<br>Options: -                                       | Default: BLA<br>Options: -                                       | Default: BLA<br>Options: F, T                                    |

**\*Obsolete module. These modules are not recommended for new designs!**




Figure 11-1 Analog input modules



### 1.2.12.1. AI module wiring

The following wiring method can be applied.




Figure 11-2 AI wiring

### 1.2.13. Analog output module (ATO)

The analog output module transmits current or voltage signals. The ATO module can be used in wide ranges in unipolar and bipolar mode.

Connector types:

- The default and optionally available connector types are indicated for each module in the table below. See Chapter 20.2 for details about each type.

| MODULE TYPE  | ATO+/0002                             | ATO+/0004                             |
|--|---------------------------------------|---------------------------------------|
| CHANNEL NUMBER   | 2                                     | 4                                     |
| OUTPUT MODE  | 2 wire output                         | 2 wire output                         |
| MAXIMUM LOAD<br>( $R_{\text{CABLE}} + R_{\text{RECEIVER}}$ ) | 500 $\Omega$                          | 500 $\Omega$                          |
| OUTPUT RANGES  | $\pm 20$ mA<br>0 - 20 mA<br>4 - 20 mA | $\pm 20$ mA<br>0 - 20 mA<br>4 - 20 mA |
| CONNECTOR TYPE   | Default: BLA<br>Options: T            | Default: BLA<br>Options: -            |





Figure 12-1 Analog output modules

### 1.2.13.1. ATO module wiring

The analog output module should be connected according to the following wiring diagram.



*Figure 12-2 Analog output module wiring diagram*



## 1.2.14. Sensor input module

The sensor modules receive low-level signals of current and voltage sensors (low-power instrument transformers).

### Connector types:

- The default and optionally available connector types are indicated for each module in the table below. See Chapter 20.2 for details about each type.

| MODULE TYPE                        | CVS+/0001   |                            | CVSR+/0001  |                             | VS+/0031***  |
|------------------------------------|---|----------------------------|---|-----------------------------|--|
| CHANNEL NUMBER                     | 4 U   | 4 I                        | 4 U   | 4 I                         | 4 U  |
| NOMINAL VALUES                     | 3.25 V  | 0.225 V*                   | 1.27 V  | 0.150 V**                   | 3.25 V   |
| CONTINUOUS VOLTAGE WITHSTAND       | 35 V DC   |                            | 35 V DC   |                             | 35 V DC  |
| SHORT TIME OVERLOAD (1 s)          | 40 V AC / 56 V DC                                       |                            | 40 V AC / 56 V DC                                       |                             | 40 V AC / 56 V DC  |
| MAX. MEASURED VALUE ( $\pm 10\%$ ) | 1.8 U <sub>N</sub>                                      | 50 I <sub>N</sub>          | 2.1 U <sub>N</sub>                                      | 50 I <sub>N</sub>           | 1.6 U <sub>N</sub>   |
| ACCURACY                           | $\leq 0.5\%$ (0.1 U <sub>N</sub> – 1.2 U <sub>N</sub> ) |                            | $\leq 0.5\%$ (0.1 U <sub>N</sub> – 1.2 U <sub>N</sub> ) |                             | $\leq 0.5\%$ (0.1 U <sub>N</sub> – 1.2 U <sub>N</sub> )  |
| FREQUENCY RANGE                    | DC – 1 kHz  |                            | DC – 1 kHz  |                             | DC – 1 kHz   |
| INPUT RESISTANCE                   | 200 k $\Omega$<br>$\pm 1\%$                             | 21 k $\Omega$<br>$\pm 1\%$ | 10 M $\Omega$<br>$\pm 1\%$                              | 1.1 M $\Omega$<br>$\pm 1\%$ | 200 k $\Omega$<br>$\pm 1\%$  |
| INPUT CAPACITANCE                  | 300 pF<br>(1 kHz)                                       | 300 pF<br>(1 kHz)          | 300 pF<br>(1 kHz)                                       | 300 pF<br>(1 kHz)           | 300 pF (1 kHz)   |
| CONNECTOR TYPE                     | RJ45 – 8 pole, shielded connector, isolated shielding   |                            | RJ45 – 8 pole, shielded connector, grounded shielding   |                             | M8 3-pin connector<br>Receptacle:<br>Hirschmann ELST 3308 RV FM 8 05<br>Plug: Binder 768 99-3360-00-03 |

\*Voltage proportional to current

\*\*Voltage proportional to current change (Rogowski coil)

\*\*\***Obsolete module. These modules are not recommended for new designs!**

For more information about more available nominal values please contact our Application Team. ([application@protecta.hu](mailto:application@protecta.hu))




Figure 13-1 Voltage sensor modules





Figure 13-2 M8 connector pinout



- 1.: S1
- 2.: S2
- 3.: “a”
- 6.: “n”

Figure 13-3 CVS module connector pinout



- 4.: S1
- 5.: S2
- 8.: “n”
- 7.: “a”

Figure 13-4 CVSR module connector pinout

### 1.2.15. INJ module

Complex module for controlling the Petersen coil, which contains an injector function for the measurements, an enabling and a blocking input, and a fault relay indicating if there is any fault in the injection circuit.

Connector types:

- The default and optionally available connector types are indicated for each module in the table below. See Chapter 20.2 for details about each type.

| MODULE TYPE                             | INJ+/0005                           | INJ+/0015*   |
|---|-------------------------------------|--|
| INJECTED CURRENT                        | 2 A                                 | 4 A  |
| ENABLING INPUT CLAMP VOLTAGE            | 85 V AC                             | Not available function   |
| BLOCKING INPUT CLAMP VOLTAGE            | 200 V AC                            | 200 V AC   |
| ADDITIONAL RESISTANCE FOR VOLTAGE INPUT | Not available function              | 265 kΩ ± 1%  |
| CONNECTOR TYPE                          | Default: STVS6, BLA10<br>Options: - |  |
| RECOMMENDED APPLICATION                 | Arc suppression coil controller     | Network compensation level measurement on resonant grounded networks |

\*Special module




Figure 14-1 INJ modules

## 1.2.16. Generator protection modules

Special generator protection modules whose system measures and produces the necessary analog signals.

### Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.

| MODULE TYPE                                 | RAI+/01  | RAI+/11  | RINJ+/21   |
|---|--|--|--|
| NOMINAL VOLTAGE                             | -  | -  | 110 V / 220 V  |
| INPUT VOLTAGE RANGE                         | -  | -  | 88 - 264 V DC<br>80 - 250 V AC                               |
| OUTPUT VOLTAGE                              | -  | -  | 100V DC $\pm$ 2 %  |
| MEASUREMENT RANGE                           | $\pm$ 20 mA  | $\pm$ 20 mA  | -  |
| THERMAL WITHSTAND<br>CONTINUOUS:<br>30 SEC: | 15 mA<br>20 mA   | 10 mA<br>20 mA   | 20 mA  |
| CONNECTOR TYPE                              | <u>Default:</u> STVS8<br><u>Options:</u> -             | <u>Default:</u> STVS8<br><u>Options:</u> T*                  | <u>Default:</u> STVS8<br><u>Options:</u> T*                  |
| RECOMMENDED APPLICATION                     | Rotor earth-fault protection of middle-grounded rotors | Rotor earth-fault protection of ungrounded (isolated) rotors | Rotor earth-fault protection of ungrounded (isolated) rotors |

\*By choosing this option, the connector remains the same, only the handle is changed




Figure 15-1 Generator protection modules

### 1.2.16.1. Auxiliary boxes for rotor earth fault protection

These DIN-rail mounted external boxes serve as couplings between the rotor (exciter circuit) of the generator and the corresponding RAI module of the protection device.

Note: the data about the resistances and capacitors provided here does not tell the actual time constants of the measured values, as those can be determined on-site only, when the rotor earth fault protection is being tested on the actual generator itself.

| MODULE TYPE                | RAI+01 BOX                   | RAI+11 BOX BASE              | RAI+11 BOX EXTENSION*        |
|----------------------------|------------------------------|------------------------------|------------------------------|
| MAXIMUM INPUT VOLTAGE      | 200 V, 300 V, 400 V, 500 V** | 600 V                        | 1200 V                       |
| SERIES RESISTANCE ON SIDES | 10 kΩ, 15 kΩ, 20 kΩ, 25 kΩ** | 35 kΩ                        | 30 kΩ                        |
| FILTER CAPACITORS          | 4x10 μF                      | 2x1 μF                       | -                            |
| CONNECTOR TYPE             | Default: STVS6<br>Options: - | Default: STVS6<br>Options: - | Default: STVS6<br>Options: - |
| RECOMMENDED APPLICATION    | Middle-grounded rotors       | Ungrounded (isolated) rotors | Ungrounded (isolated) rotors |

\*This extension module can only be used together with RAI+11 BOX BASE module

\*\*According to the chosen wiring

#### 1.2.16.1.1. Use of auxiliary boxes

- Ungrounded (isolated) rotors:**

If the excitation voltage is lower than 600 V, then it is enough to use the RAI+11 BOX BASE auxiliary box. If the excitation voltage is higher than 600 V, the RAI+11 BOX EXTENSION auxiliary box shall be used *additionally*, so the protection can connect to up to 1200 V excitation voltage.

- Middle-grounded rotors**

Front drawings near the connectors on the box itself indicate the available maximum voltages. The choice from these shall be made according to the excitation voltage. Wiring shall be done according to the chosen voltage.




Figure 15-2 Size of the auxiliary boxes

## 1.2.16.2. Wiring of the rotor earth fault protection modules




Figure 15-3 Wiring for ungrounded (isolated) rotors





Figure 15-4 Wiring for middle-grounded rotors



## 1.2.17. Power supply module

The power supply module converts primary AC and/or DC voltage to required system voltages. In most applications, one power supply module is sufficient to provide the required power to the system. Redundant power supply modules extend system availability in case of the outage of any power source.

### IMPORTANT

Depending on the hardware configuration, the power consumption of the devices can be different. We reserve the right to make the decision about which PS+ module must be used.

For most applications where the power consumption does not reach 20 W, a 4 HP wide PS+ module shall be installed.

### Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter [20.2](#) for details about each type.

| MODULE TYPE  | PS+/4201<br>(4 HP wide)                  | PS+/2101<br>(4 HP wide)                     |
|--|--|---|
| RATED VOLTAGE  | 24 V DC /<br>48 V DC / 60 V<br>DC        | 110 V DC /<br>220 V DC                      |
| INPUT VOLTAGE<br>OPERATIVE RANGE   | 19.2 - 72 V DC                           | 88 - 264 V DC<br>80 - 250 V AC              |
| NOMINAL POWER  | 20 W                                     | 20 W  |
| VOLTAGE DIP<br>WITHSTAND AT<br>80% UN → 0% INPUT<br>VOLTAGE CHANGE<br>(IEC 60255-26) | 50 ms                                    | 100 ms                                      |
| INTERNAL FUSE  | 3.15A/250V                               | 3.15A/250V                                  |
| CONNECTOR TYPE   | <u>Default:</u> BLA<br><u>Options:</u> T | <u>Default:</u> BLA<br><u>Options:</u> F, T |

**IMPORTANT**

Devices with 20W or higher power consumption shall be equipped with an 8 HP wide PS module.

| MODULE TYPE  | PS+/1301                                     | PS+/1303**                                   | PS+/2301                                     | PS+/2303**                                   | PS+/1030*                                    |
|--|--|--|--|--|--|
| RATED VOLTAGE  | 110 V DC                                     | 110 V DC                                     | 220 V DC                                     | 220 V DC                                     | 110 V DC / 220 V DC                          |
| INPUT VOLTAGE OPERATIVE RANGE  | 88 - 132 V DC<br>85 - 130 V AC               | 88 - 150 V DC<br>85 - 130 V AC               | 176 - 264 V DC<br>160 - 250 V AC             | 176 - 264 V DC<br>160 - 250 V AC             | 88 - 264 V DC<br>85 - 250 V AC               |
| MAX. CONTINUOUS POWER OUTPUT   | 30 W   | 30 W   | 30 W   | 30 W   | 25 W   |
| VOLTAGE DIP WITHSTAND AT 80% UN → 0% INPUT VOLTAGE CHANGE (IEC 60255-26) | <b>50 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>50 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>50 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>50 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>20 ms</b><br><b>100 ms</b> at 100%Un → 0% |
| INTERNAL FUSE  | 2.5A/250V                                    | 2.5A/250V                                    | 2.5A/250V                                    | 2.5A/250V                                    | 2.5A/250V                                    |
| CONNECTOR TYPE   | <u>Default: BLA</u><br><u>Options: -</u>     | <u>Default: BLA</u><br><u>Options: -</u>     | <u>Default: BLA</u><br><u>Options: -</u>     | <u>Default: BLA</u><br><u>Options: -</u>     | <u>Default: BLA</u><br><u>Options: F, T</u>  |

\*Special module, available only in custom configurations.

\*\*Can be connected in parallel.

| MODULE TYPE  | PS+/1060*                                    | PS+/1601                                     | PS+/1602*                                    | PS+/2601                                     | PS+/4301***                                 |
|--|--|--|--|--|---|
| RATED VOLTAGE  | 110 V DC / 220 V DC                          | 110 V DC                                     | 110 V DC                                     | 220 V DC                                     | 48 V DC                                     |
| INPUT VOLTAGE OPERATIVE RANGE  | 88 - 264 V DC                                | 88 - 132 V DC<br>95 - 130 V AC               | 88 - 132 V DC<br>95 - 130 V AC               | 176 - 264 V DC<br>160 - 250 V AC             | 38.4 - 57.6 V DC                            |
| MAX. CONTINUOUS POWER OUTPUT   | 60 W   | 60 W   | 60 W   | 60 W   | 25 W  |
| VOLTAGE DIP WITHSTAND AT 80% UN → 0% INPUT VOLTAGE CHANGE (IEC 60255-26) | <b>20 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>50 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>50 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>50 ms</b><br><b>100 ms</b> at 100%Un → 0% | <b>20 ms</b><br><b>30 ms</b> at 100%Un → 0% |
| INTERNAL FUSE  | 3.15A/250V                                   | 2.5A/250V                                    | 2.5A/250V                                    | 2.5A/250V                                    | 3.15A/250V                                  |
| CONNECTOR TYPE   | <u>Default: BLA</u><br><u>Options: F, T</u>  | <u>Default: BLA</u><br><u>Options: -</u>     | <u>Default: BLA</u><br><u>Options: F</u>     | <u>Default: BLA</u><br><u>Options: T</u>     | <u>Default: BLA</u><br><u>Options: -</u>    |

\*Special module, available only in custom configurations. PS+1602 supports **auxiliary voltage measurement**. The module is calibrated to DC voltage measurement.

\*\*\*Obsolete module. These modules are not recommended for new designs!



| MODULE TYPE  | PS+/2161*                  | PS+/2164**                 | PS+/4261*                         | PS+/4264**                        |
|--|----------------------------|----------------------------|-----------------------------------|-----------------------------------|
| RATED VOLTAGE  | 110 V DC /<br>220 V DC     | 110 V DC /<br>220 V DC     | 24 V DC /<br>48 V DC / 60<br>V DC | 24 V DC /<br>48 V DC / 60<br>V DC |
| INPUT VOLTAGE OPERATIVE RANGE  | 88 - 264 V DC              | 88 - 264 V DC              | 19.2 - 72 V DC                    | 19.2 - 72 V DC                    |
| MAX. CONTINUOUS POWER OUTPUT   | 60 W                       | 60 W                       | 60 W                              | 60 W                              |
| VOLTAGE DIP WITHSTAND AT 80% UN → 0% INPUT VOLTAGE CHANGE (IEC 60255-26) | 40 ms                      | 40 ms                      | 40 ms                             | 40 ms                             |
| INTERNAL FUSE  | 3.15A/250V                 | 3.15A/250V                 | 8A/250V                           | 8A/250V                           |
| CONNECTOR TYPE   | Default: BLT<br>Options: - | Default: BLT<br>Options: - | Default: BLT<br>Options: -        | Default: BLT<br>Options: -        |

\*Can be connected in parallel.\*\*Can be connected in parallel and supports auxiliary voltage measurement.

| MODULE TYPE  | PS+/4401**                          | PS3F+/1001*                       |
|--|-------------------------------------|-----------------------------------|
| RATED VOLTAGE  | 48 V DC /<br>60 V DC                | 3x100 V AC (line voltage)         |
| INPUT VOLTAGE OPERATIVE RANGE  | 38.4 - 72 V DC                      | 80 - 120 V AC                     |
| MAX. CONTINUOUS POWER OUTPUT   | 30 W                                | 20 W                              |
| VOLTAGE DIP WITHSTAND AT 80% UN → 0% INPUT VOLTAGE CHANGE (IEC 60255-26) | 20 ms<br>30 ms at 100%Un<br>→<br>0% | 50 ms<br>100 ms at 100%Un →<br>0% |
| INTERNAL FUSE  | 3.15A/250V                          | 2.5A/250V                         |
| CONNECTOR TYPE   | Default: BLA<br>Options: F, T       | Default: BLA<br>Options: -        |

\*Special module. At least 2 healthy phase voltages are needed for the operation of the PS3F+1001 module. LEDs on the front of the module indicate the presence of healthy phase voltages. For the correct internal signals connect the common point of the supplying 3 phase voltage to the 4<sup>th</sup> connector ("N").

\*\*Can be connected in parallel.

Main features:

- Fault relay contacts (NC and NO): device fault contact and also assignable to user functions. All the three relay contact points are accessible to users.
- Redundant applications (nominal power and reliability can be increased by using parallel power supplies)
- On-board self-supervisory circuits: temperature and voltage monitors
- Short-circuit-protected outputs
- Efficiency: > 70 %, power consumption = nominal power / efficiency
- Passive heatsink

- Early power failure indication signals to the CPU for the possibility of power outage, thus the CPU has enough time to save the necessary data to non-volatile memory
- Inrush current (until 0.1 s): < 10 A for all types excluding PS+4401 which has < 21 A inrush current.
- Common features for internal fuses:
  - 5 mm x 20 mm (0.20" x 0.79")
  - TT characteristics (very inverse time-lag)
  - 35 A @ 250 V AC rated breaking capacity
- Recommended external protection: miniature circuit breaker, 6 A (C char.)




Figure 16-1 Power supply modules

## 1.2.18. Sampling synchronization module

The IED sampling system is synchronized via this module to an external source (IRIG-B) in PMU (Phasor Measurement Unit) applications. The PLL of the module handles the setting of the phase and frequency if valid IRIG-B signal is received. Note that the sampling signal is generated even if the IRIG-B signal is not present, however in that case, it runs independently.

| MODULE TYPE                              | TSYNC+/0071                       |
|--|-----------------------------------|
| IRIG-B TYPE                              | B000<br>(unmodulated)             |
| INPUT TYPE                               | BNC (coaxial)                     |
| SIGNAL THRESHOLD                         | 5 VDC CMOS<br>max. 5.5 VDC        |
| MAX. CABLE LENGTH                        | 50 m                              |
| CLAMP VOLTAGES                           | falling 1.7 VDC<br>rising 3.1 VDC |
| SAMPLING ACCURACY*                       | < 100 ns                          |
| IRIG SYNCH. TIME                         | max. 1 minute                     |
| HOLDOVER TIME**                          | 30 s                              |
| SAMPLING FREQUENCY                       | 2 kHz @ 50 Hz<br>2.4 kHz @ 60 Hz  |
| SAMPLING ACCURACY IN INDEPENDENT MODE*** | < 1 ppm                           |

\*max. time difference between synchronized systems connecting to different GNSS (e.g. GPS)

\*\*the sampling accuracy stays below the given value during this time if the IRIG-B signal is lost

\*\*\*the accuracy of the 2/2.4 kHz sampling signal if an IRIG-B signal is not present






Figure 17-1 Sampling synchronization module



## 1.2.19. Mixed function modules

### 1.2.19.1. PSTP+ module

#### IMPORTANT

PSTP+ modules can be used only if the power consumption of the device does not reach 20 W and maximum 2 TRIP contacts are needed. If the application does not meet any of these two requirements, it is not allowed to use these cards. In this case separate PS+ (Chapter 16) and TRIP+ (Chapter 9) modules must be used.

#### Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.


Note for the following tables:

- Thermal withstand voltage:** continuous with 60 % of the input channels are energized.

| MODULE TYPE   | PSTP+/2101  | PSTP+/2102*   | PSTP+/2131**  |
|---|---|---|---|
| POWER SUPPLY CHARACTERISTICS                                      |   |   |   |
| <b>RATED VOLTAGE</b>  | 110 V / 220 V   | 110 V / 220 V   | 110 V / 220 V   |
| <b>INPUT VOLTAGE OPERATIVE RANGE</b>                              | 88 - 264 V DC<br>80 - 250 V AC                          | 88 - 264 V DC<br>80 - 250 V AC                          | 88 - 264 V DC<br>80 - 250 V AC                          |
| <b>MAXIMUM CONTINUOUS POWER OUTPUT</b>                            | 20 W  | 20 W  | 20 W  |
| <b>VOLTAGE DIP DURATION AT 0% RESIDUAL VOLTAGE (IEC 60255-26)</b> | <b>min. 100 ms</b> in the specified input voltage range | <b>min. 100 ms</b> in the specified input voltage range | <b>min. 100 ms</b> in the specified input voltage range |
| <b>INTERNAL FUSE</b>  | 3.15A/250V  | 3.15A/250V  | 3.15A/250V  |
| <b>CONNECTOR TYPE</b>   | <u>Default:</u> BLA<br><u>Options:</u> F, T             | <u>Default:</u> BLA<br><u>Options:</u> F, T             | <u>Default:</u> BLA<br><u>Options:</u> T                |
| TRIPPING CHARACTERISTICS  |   |   |   |
| <b>CHANNEL NUMBER</b>   | 2   | 2   | 2   |
| <b>RATED VOLTAGE</b>  | 110 V DC and 220 V DC or dry contacts                   | 110 V DC and 220 V DC or dry contacts                   | 110 V DC and 220 V DC or dry contacts                   |
| <b>THERMAL WITHSTAND VOLTAGE</b>                                  | 242 V DC  | 242 V DC  | 242 V DC  |
| <b>CONTINUOUS CARRY</b>   | 8 A   | 8 A   | 8 A   |
| <b>MAKING CAPACITY</b>  | 0.5 s, 30 A   | 0.5 s, 30 A   | 0.5 s, 30 A   |
| <b>BREAKING CAPACITY</b>  | L/R = 40 ms: 4 A DC                                     | L/R = 40 ms: 4 A DC                                     | L/R = 40 ms: 4 A DC                                     |
| <b>CONNECTOR TYPE</b>   | <u>Default:</u> BLA<br><u>Options:</u> F, T             | <u>Default:</u> BLA<br><u>Options:</u> F, T             | <u>Default:</u> BLA<br><u>Options:</u> T                |

\*Special module that supports **auxiliary voltage measurement**. The module is calibrated to DC voltage measurement.

\*\*Without trip circuit supervision



| MODULE TYPE   | PSTP+/4201   | PSTP+/4202*  |
|---|--|--|
| <b>POWER SUPPLY CHARACTERISTICS</b>                               |  |  |
| <b>RATED VOLTAGE</b>  | 24 V / 48 V / 60 V   | 24 V / 48 V / 60 V   |
| <b>INPUT VOLTAGE OPERATIVE RANGE</b>                              | 19.2 - 72 V DC   | 19.2 - 72 V DC   |
| <b>MAXIMUM CONTINUOUS POWER OUTPUT</b>                            | 20 W   | 20 W   |
| <b>VOLTAGE DIP DURATION AT 0% RESIDUAL VOLTAGE (IEC 60255-26)</b> | <b>50 ms</b> at nominal input voltages<br>min. <b>40 ms</b> in the specified input voltage range | <b>50 ms</b> at nominal input voltages<br>min. <b>40 ms</b> in the specified input voltage range |
| <b>INTERNAL FUSE</b>  | 3.15A/250V   | 3.15A/250V   |
| <b>CONNECTOR TYPE</b>   | <u>Default:</u> BLA<br><u>Options:</u> T   | <u>Default:</u> BLA<br><u>Options:</u> T   |
| <b>TRIPPING CHARACTERISTICS</b>                                   |  |  |
| <b>CHANNEL NUMBER</b>   | 2  | 2  |
| <b>RATED VOLTAGE</b>  | 24 V DC and 48 V DC or dry contacts  | 24 V DC and 48 V DC or dry contacts  |
| <b>THERMAL WITHSTAND VOLTAGE</b>                                  | 72 V DC  | 72 V DC  |
| <b>CONTINUOUS CARRY</b>   | 8 A  | 8 A  |
| <b>MAKING CAPACITY</b>  | 0.5 s, 30 A  | 0.5 s, 30 A  |
| <b>BREAKING CAPACITY</b>  | L/R = 40 ms: 4 A DC  | L/R = 40 ms: 4 A DC  |
| <b>CONNECTOR TYPE</b>   | <u>Default:</u> BLA<br><u>Options:</u> T   | <u>Default:</u> BLA<br><u>Options:</u> T   |

**\*Special module** that supports **auxiliary voltage measurement**. The module is calibrated to DC voltage measurement.

Main features:

- High-speed operation: with pre-trip 0.5 ms, without pre-trip typically 10 ms, maximally 22 ms.
- Trip circuit supervision for each trip contact
- 1 unit wide (4 HP) modules
- Inrush current (until 0.1 s): < 10 A
- Common features for internal fuses:
  - 5 mm x 20 mm (0.20" x 0.79")
  - TT characteristics (very inverse time-lag)
  - 35 A @ 250 V AC rated breaking capacity
- Recommended external protection: miniature circuit breaker, 6 A (C char.)




Figure 18-1 Power supply with 2 Ch. TRIP modules

### 1.2.19.1.1. Trip Circuit Supervision (TCS) in PSTP modules

Apart from the PSTP+/2131, all PSTP modules have TCS.

The technical data of the TCS in PSTP modules:

|                                     | MODULE TYPE                       | PSTP+/4201<br>PSTP+/4202                              | PSTP+/2101<br>PSTP+/2102               |
|-------------------------------------|-----------------------------------|---|--|
|                                     | INJECTED CURRENT AT "NO" CONTACT  | 1.5 mA  | 1.5 mA                                 |
| MAXIMUM RESISTANCE OF THE TRIP COIL | 3-WIRE WIRING (1 mA CURRENT)      | 8 kΩ (max. 8 V)                                       | 13 kΩ (max. 13 V)                      |
|                                     | 3-WIRE WIRING IN PARALLEL         | 4 kΩ (max. 8 V)                                       | 6.5 kΩ (max. 13 V)                     |
|                                     | 2-WIRE METHOD (1 mA MIN. CURRENT) | 24 kΩ @ 24 V DC<br>48 kΩ @ 48 V DC<br>60 kΩ @ 60 V DC | 110 kΩ @ 110 V DC<br>220 kΩ @ 220 V DC |

**IMPORTANT**

PSR2+ modules can be used only if the power consumption of the device does not reach 20 W and maximum 2 contacts are needed. If the application does not meet any of these two requirements it is not allowed to use these cards. In this case separate PS+ (Chapter 16) and Signaling (Chapter 8) modules must be used.

**1.2.19.2. PSR2+ module**


Connector types:

- The default and optionally available connector types are indicated for each module in the table below. See Chapter 20.2 for details about each type.

| MODULE TYPE   | PSR2+/2101  |
|---|---|
| <b>POWER SUPPLY CHARACTERISTICS</b>                               |   |
| <b>RATED VOLTAGE</b>  | 110 V / 220 V   |
| <b>INPUT VOLTAGE OPERATIVE RANGE</b>                              | 88 - 264 V DC<br>80 - 250 V AC                          |
| <b>MAXIMUM CONTINUOUS POWER OUTPUT</b>                            | 20 W  |
| <b>VOLTAGE DIP DURATION AT 0% RESIDUAL VOLTAGE (IEC 60255-26)</b> | <b>min. 100 ms</b> in the specified input voltage range |
| <b>INTERNAL FUSE</b>  | 3.15A/250V  |
| <b>CONNECTOR TYPE</b>   | <u>Default:</u> BLA<br><u>Options:</u> T                |
| <b>SIGNALING RELAY CHARACTERISTICS</b>                            |   |
| <b>CHANNEL NUMBER</b>   | 2   |
| <b>RATED VOLTAGE</b>  | 250 V AC/DC   |
| <b>CONTINUOUS CARRY</b>   | 8 A   |
| <b>MAKING CAPACITY</b>  | 0.5 s, 30 A   |
| <b>CONNECTOR TYPE</b>   | <u>Default:</u> BLA<br><u>Options:</u> T                |

Main features (according to IEC 60255-26):

- Maximum switching voltage: 400 V AC
- Breaking capacity: (L/R=40 ms) at 220 V DC: 0.2 A, at 110 V DC: 0.3 A
- Breaking capacity max.: 2000 VA
- Short time carrying capacity: 1 s, 35 A
- Limiting making current, max. 4 s: 15 A (df = 10 %)
- Dielectric strength between open contacts, 1 min: 1000 V<sub>RMS</sub>
- Mechanical endurance: 10 × 10<sup>6</sup> cycles
- Circuit closing capability: typically 10 ms, maximally 22 ms.
- Bounce time: typically 6,5 ms, maximally 10 ms.
- Minimal switching requirement: 5 V



*Figure 18-2 Power supply with 2 Ch. signaling modules*



### 1.2.19.3. O6R5+ module

The O6R5+ module contains 6 binary input channels in one grounding group, and 5 relay outputs with 2 × 2 NO contacts and one CO contact.

Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.

Notes for the following table:

- **Thermal withstand voltage:** continuous with 60 % of the input channels are energized.
- **Clamp voltage:** these are the guaranteed values; the actual ones might differ from those provided here (falling and rising around 0.66  $U_N$  and 0.77  $U_N$ , respectively)

| MODULE TYPE   | O6R5+/2101   | O6R5+/4201   |
|---|--|--|
| <b>BINARY INPUT CHARACTERISTICS</b>                   |  |  |
| CHANNEL NUMBER  | 6  | 6  |
| RATED VOLTAGE   | 110 V / 220 V<br>user selectable on channel basis by jumpers | 24 V / 48 V<br>user selectable on channel basis by jumpers |
| TIME SYNCHRONIZATION                                  | configured by EuroCAP  | configured by EuroCAP                                      |
| THERMAL WITHSTAND VOLTAGE                             | 320 V  | 72 V   |
| CLAMP VOLTAGE   | falling 0.64 $U_N$<br>rising 0.8 $U_N$                       | falling 0.64 $U_N$<br>rising 0.8 $U_N$                     |
| COMMON GROUPS   | 1 × 6 common   | 1 × 6 common   |
| <b>RELAY OUTPUT CHARACTERISTICS</b>                   |  |  |
| RATED VOLTAGE   | 250 V AC/DC  | 250 V AC/DC  |
| CONTINUOUS CARRY                                      | 8 A  | 8 A  |
| CONTACT VERSIONS                                      | 4 NO, 1 CO   | 4 NO, 1 CO   |
| GROUP ISOLATION                                       | 2 × 2 common, 1 independent                                  | 2 × 2 common, 1 independent                                |
| CONNECTOR TYPE FOR BOTH BINARY INPUT AND RELAY OUTPUT | <u>Default:</u> BLA<br><u>Options:</u> T                     | <u>Default:</u> BLA<br><u>Options:</u> T                   |

Main features for binary inputs:

- Digitally filtered per channel
- Current drain:
  - max. 1.6 mA per channel at 220 V DC
  - max. 1.8 mA per channel at 110 V DC
  - max. 2 mA per channel at 48 V DC
  - max. 3 mA per channel at 24 V DC
- In such applications where the input voltage is 60 V the modules with 48 V rated voltage can be used.
- Input voltage type can be either DC or AC voltage. If AC voltage is used make sure that the type and the parameters of the binary inputs are configured properly in EuroCap tool.

Main features for signaling outputs:

- Maximum switching voltage: 400 V AC
- Breaking capacity, (L/R=40 ms) at 220 V DC: 0.1 A, at 110 V DC: 0.2 A
- Breaking capacity max.: 2000 VA
- Short time carrying capacity: 1 s, 35 A
- Limiting making current, max. 4 s: 15 A (df = 10 %)
- Initial dielectric strength between open contacts, 1 min: 1000 V<sub>RMS</sub>
- Circuit closing capability: typically 10 ms, maximally 22 ms.
- Bounce time: typically 6,5 ms, maximally 10 ms.
- Mechanical endurance: 10 × 10<sup>6</sup> cycles
- Circuit closing capability




Figure 18-3 Binary input/output modules

## 1.2.19.4. Binary input module with time synchronization

The inputs are galvanically isolated and the module converts high-voltage signals to the voltage level and format of the internal circuits. This module is also used as an external IRIG-B synchronization (**IRIG-B000, unmodulated**), PPM or PPS input. Dedicated synchronization input is used for this purpose.


### Connector types:

- The default and optionally available connector types are indicated for each module in the tables below. See Chapter [20.2](#) for details about each type.

Notes for the following table:

- **Thermal withstand voltage:** continuous with 60 % of the input channels are energized.
- **Clamp voltage:** these are the guaranteed values; the actual ones might differ from those provided here (falling and rising around  $0.66 U_N$  and  $0.77 U_N$ , respectively)

| MODULE TYPE                       | O9S+/2111                                      | O9S+/2121                                      | O9S+/4221                                    |
|-----------------------------------|--|--|--|
| CHANNEL NUMBER                    | 9  | 9  | 9  |
| SYNCHRON CHANNEL TYPE AND NUMBER  | 1 isolated BNC connector                       | 1 850 nm multimode fiber with ST connector     | 1 850 nm multimode fiber with ST connector   |
| RATED VOLTAGE                     | 110 V DC / 220 V DC user selectable by jumpers | 110 V DC / 220 V DC user selectable by jumpers | 24 V DC / 48 V DC user selectable by jumpers |
| THERMAL WITHSTAND VOLTAGE         | 320 V  | 320 V  | 72 V   |
| WITHSTAND VOLTAGE FOR SYNC. INPUT | 35 V <sub>PEAK</sub>                           | -  | -  |
| CLAMP VOLTAGE                     | falling $0.64 U_N$<br>rising $0.8 U_N$         | falling $0.64 U_N$<br>rising $0.8 U_N$         | falling $0.64 U_N$<br>rising $0.8 U_N$       |
| COMMON GROUPS                     | 9 (3 × 3 common)                               | 9 (3 × 3 common)                               | 9 (3 × 3 common)                             |
| CONNECTOR TYPE                    | <u>Default:</u> BLA<br><u>Options:</u> T       | <u>Default:</u> BLA<br><u>Options:</u> F, T    | <u>Default:</u> -<br><u>Options:</u> F, T    |



*Figure 18-4 Binary input modules with time synchronization*

## 1.2.19.5. Externally driven trip module

The R4MC+01 is a special TRIP module, which can be operated from the connector side. It also has two diode inputs with cathodes which are connected and led to the connector side.

### Connector types:


- The default and optionally available connector types are indicated for each module in the tables below. See Chapter 20.2 for details about each type.

| Module type               | R4MC+/01*                                |
|---------------------------|--|
| CHANNEL NUMBER            | 2  |
| RATED VOLTAGE             | 110 V DC                                 |
| THERMAL WITHSTAND VOLTAGE | 132 V DC                                 |
| CONTINUOUS CARRY          | 8 A                                      |
| MAKING CAPACITY           | 0.5 s, 30 A                              |
| BREAKING CAPACITY         | L/R = 40 ms: 4 A DC                      |
| DIODE PROPERTIES          | 1 A, 1000 V DC                           |
| CONNECTOR TYPE            | <u>Default:</u> BLA<br><u>Options:</u> F |

\*Special module




Figure 18-5 Externally driven TRIP module



### 1.2.20. General data

- Storage temperature: - 40 °C ... + 70 °C
- Operation temperature: - 20 °C ... + 55 °C
- Humidity: 10 % ... 93 %
- Altitude: up to 2000 m
- Atmospheric pressure: 86 ... 106 kPa



## 1.2.20.1. Standard conformance


- Electrostatic discharge immunity (ESD), IEC-EN 60255-26:2013, Level 4
  - Test voltages: 15 kV air discharge, 8 kV contact discharge
- Radiated, radio-frequency, electromagnetic field immunity, IEC-EN 60255-26:2013 Level 3
  - Test field strength: 10 V/m
- Electrical fast transient/burst immunity (EFT/B), IEC-EN 60255-26:2013, Level 4
  - Test voltage: 4 kV
- Surge immunity test, IEC-EN 60255-26:2013
  - Test voltages: 4 kV line-to-earth, 2 kV line-to-line
- Immunity to conducted disturbances, induced by radio-frequency fields, IEC-EN 60255-26:2013, Level 3
  - Test voltage: 10 V
- Damped oscillatory wave immunity test, IEC-EN 60255-26:2013
  - Test frequency: 1 MHz
  - Test voltage: 2.5 kV in common mode, 1 kV in differential mode
- Voltage dips, short interruptions and voltage variations immunity, IEC-EN 60255-26:2013
  - Voltage dips: 40 % (200 ms), 70 % (500 ms), 80 % (5000 ms)
- Ripple on d.c. input power port immunity, IEC-EN 60255-26:2013
  - Level 4, 15 % of rated d.c. value
- Power frequency magnetic field immunity test, IEC-EN 60255-26:2013, Level 5
  - Test field strength: 100 A/m continuous, 1000 A/m for 3 s
- Power frequency immunity test on the binary inputs, IEC-EN 60255-26:2013, Class A
  - Test voltages: 300 V in common mode, 150 V in differential mode
- Insulation tests, IEC-EN 60255-27:2013
  - Impulse voltage test
    - Test levels: 5 kV (1 kV for transducer and temperature measuring inputs)
  - Dielectric test
    - Test levels: 2 kV AC 50 Hz (0.705 kV DC for transducer inputs)
  - Insulation resistance
    - Insulation resistance > 15 GΩ
- Radiated emission, IEC-EN 60255-26:2013
 

Limits:

  - 30 MHz to 230 MHz: 50 dB(μV/m) quasi peak, 3 m
  - 230 MHz to 1 000 MHz: 57 dB(μV/m) quasi peak, 3 m
  - 1 GHz to 3 GHz: 76 dB(μV/m) peak, 3 m
  - 3 GHz to 6 GHz: 80 dB(μV/m) peak, 3 m
- Conducted emission, IEC-EN 60255-26:2013
 

Limits:

  - 0,15 MHz to 0,50 MHz: 79 dB(μV) quasi peak, 66 dB(μV) average
  - 0,5 MHz - 30 MHz: 73 dB(μV) quasi peak, 60 dB(μV) average
- Vibration, shock, bump and seismic tests on measuring relays and protection equipment
  - Vibration tests (sinusoidal), Class I, IEC 60255-21-1:1988
  - Shock and bump tests, Class I, IEC 60255-21-2:1988
  - Seismic tests, Class I, IEC 60255-21-3:1993



## 1.2.21. Mechanical data

### 1.2.21.1. General mechanical data

- Construction: chromate aluminum surface with built-in EMC accessories
  - If the power consumption of a 84 HP or 42 HP device does not exceed 30 W (84 HP) or 14 W (42 HP), the construction will be built with solid top and bottom cover panels.
  - If the power consumption exceeds 30 W (84 HP) or 14 W (42 HP), the construction will be built with (honeycomb) perforated top and bottom cover panels.
- EMC rack protects against electromagnetic environmental influences and protects the environment from radiation from the interior
- IP protection:
  - 24 HP panel instrument case: IP4x; optionally IP54 (front)
  - 84 HP and 42 HP (including double) rack: IP4x from front side, IP2x from rear side; optionally IP54 (front)
- Size:
  - 19" (84 HP), 3 U, single rack
  - ½ 19" (42 HP), 3 U, single rack
  - ½ 19" (42 HP), 6 U, double rack
  - 24 HP, panel instrument case
- Weight:
  - 84 HP: max. 8 kg
  - 42 HP, 3 U: max. 4.5 kg
  - 42 HP, 6 U: max. 8 kg
  - 24 HP: max. 3 kg



## 1.2.21.2. Connectors

Optionally, certain modules can be equipped with different terminals for different connectors. The available choices are listed among each module's technical data with their *short ID* (see the first column of the table below).

The type of the used terminal is indicated on the module's label with its *short ID* (see the following example). The actual type of the connector is chosen according to the number of the available pins of the module.

**Example:** the *VT+/2211* module may have four types of connectors. In its description (Chapter 6), these are indicated with their ID:

- The default terminal is indicated with nothing attached (*VT+/2211*), only its name (BLA) is mentioned. Since it has 8 pins, the type is BLA 8/180
- The flanged terminal's *short ID* is **F**, so the module's label will be "*VT+/2211F*", if it is equipped with this terminal (BLA 8B/180)
- Top-screw terminal: **T**, the label becomes "*VT+/2211T*" (BLT 5.08HC/08/180F)
- Ring-lug terminal: **R**, so the module's label shall be "*VT+/2211R*"

| CONNECTOR NAME (SHORT ID) | CONNECTOR TYPES   | STRIP LENGTH [MM] | CONDUCTOR AREA [MM <sup>2</sup> ] | CONDUCTOR DIAMETER [MM]       | TIGHTENING TORQUE [Nm] | MINIMUM BEND RADIUS* |
|---------------------------|---|-------------------|-----------------------------------|-------------------------------|------------------------|----------------------|
| <b>BLA (-)</b>            | Weidmüller<br>BLA 2/180,<br>BLA 3/180,<br>BLA 4/180,<br>BLA 6/180,<br>BLA 8/180,<br>BLA 10/180,<br>BLA 12/180,<br>BLA 13/180,<br>BLA 16/180 | 7                 | 0.2 – 1.5<br>solid: 0.2 – 2.5     | 0.5 – 1.4<br>solid: 0.5 – 1.8 | 0.4 – 0.5              | 3 × OD**             |
| <b>BL 3.5 (-)</b>         | Weidmüller<br>BL 3.5/05/180<br>BL 3.5/09/180  | 6                 | 0.2 – 1.5                         | 0.5 – 1.4                     | 0.2 – 0.25             | 3 × OD**             |
| <b>FLANGED (F)</b>        | Weidmüller<br>BLA 2B/180,<br>BLA 3B/180,<br>BLA 4B/180,<br>BLA 6B/180,<br>BLA 8B/180,<br>BLA 10B/180,<br>BLA 12B/180,<br>BLA 16B/180        | 7                 | 0.2 – 1.5<br>solid: 0.2 – 2.5     | 0.5 – 1.4<br>solid: 0.5 – 1.8 | 0.4 – 0.5              | 3 × OD**             |
| <b>TOP-SCREW (T)</b>      | Weidmüller<br>BLT 5.08HC/06/180F,<br>BLT 5.08HC/08/180F,<br>BLT 5.08HC/12/180F,<br>BLT 5.08HC/16/180F                                       | 13                | 0.2 – 1.5<br>solid: 0.2 – 2.5     | 0.5 – 1.4<br>solid: 0.5 – 1.8 | 0.4 – 0.5              | 3 × OD**             |
| <b>RING-LUG (R)</b>       | TE Connectivity<br>BC6-Q308-08  | -                 | 0.33 – 3.31                       | 0.65 – 2.05                   | 0.79                   | 3 × OD**             |

\* Bend radius is measured along the inside curve of the wire or wire bundles.

\*\* OD is the outer diameter of the wire or cable, including insulation.



| CONNECTOR NAME (SHORT ID) | CONNECTOR TYPES                 | STRIP LENGTH [MM] | CONDUCTOR AREA [MM <sup>2</sup> ] | CONDUCTOR DIAMETER [MM] | TIGHTENING TORQUE [Nm]   | MINIMUM BEND RADIUS* |
|---------------------------|---------------------------------|-------------------|-----------------------------------|-------------------------|--------------------------|----------------------|
| <b>STVS (-)</b>           | Weidmüller STVS 6 SB, STVS 8 SB | 9                 | 0.5 – 4                           | 0.8 – 2.3               | 0.5 – 0.6                | 3 × OD**             |
| <b>B2L 3.5</b>            | Weidmüller B2L 3.5              | 7                 | 0.2 – 1                           | 0.5 – 1.1               | tension clamp connection | 3 × OD**             |
| <b>ST/FC/LC</b>           | Bayonet/Screw/Snap Fiber Optic  | -                 | -                                 | -                       | -                        | 30 mm                |
| <b>PE FASTON TERMINAL</b> | TE Connectivity 6.3x0.8         | 7                 | min. 4                            | min. 2.3                | -                        | 3 × OD**             |

\* Bend radius is measured along the inside curve of the wire or wire bundles.

\*\* OD is the outer diameter of the wire or cable, including insulation.

The tightening torque of the screw for protective earth connection and the wall mounting must be approx. 5 Nm.

The tightening torque of the screw for fastening the STVS connector must be approx. 1 Nm.

The minimum distance between an EP+ device and its wire channel must be at least 3 cm.

The minimum distance between two EP+ devices must be at least 10 cm.

During the installation make sure that the shortest possible length for PE (Protective Earth) cable routing is applied.

## 1.2.22. Mounting methods

- Flush mounting
  - 84 HP single rack
  - 42 HP single rack
  - 42 HP double rack
  - 24 HP panel instrument case
  - Remote HMI
- Rack mounting
  - 84 HP single rack
  - 42 HP single rack
  - Remote HMI
- Semi-flush mounting
  - 84 HP single rack
  - 42 HP single rack
  - 24 HP panel instrument case
  - Remote HMI
- Wall mounting (with terminals)
  - 84 HP single rack
  - 42 HP single rack
- Din rail mounting
  - 24 HP panel instrument case
- IP54 rated mounting
  - 84 HP single rack
  - 42 HP single rack
  - 24 HP panel instrument case (original frame with additional gasket)
- Fold-down mounting (with optional terminals)
  - 84 HP single rack
  - 42 HP single rack
- No mounting
  - 84 HP single rack
  - 42 HP single rack

| MOUNTING METHOD                | 84 HP SINGLE RACK | 42 HP SINGLE RACK | 42 HP DOUBLE RACK | 24 HP PANEL INSTRUMENT CASE | REMOTE HMI |
|--------------------------------|-------------------|-------------------|-------------------|-----------------------------|------------|
| FLUSH MOUNTING                 | X                 | X                 | X                 | X                           | X          |
| RACK MOUNTING                  | X                 | X                 |                   |                             | X          |
| SEMI-FLUSH MOUNTING            | X                 | X                 |                   | X                           | X          |
| WALL MOUNTING (WITH TERMINALS) | X                 | X                 |                   |                             |            |
| DIN RAIL MOUNTING              |                   |                   |                   | X                           |            |
| IP54 RATED MOUNTING            | X                 | X                 |                   | X*                          |            |
| FOLD-DOWN MOUNTING             | X                 | X                 |                   |                             |            |

\*additional gasket inserted into the original front panel frame




It is recommended to leave at least 80 mm free space for the wiring at the back of the IED in case of Flush mounting, Rack mounting, and Semi-flush mounting.

## 1.2.22.1. Flush mounting

Flush mounting can be used for all size of racks (84 HP, 42 HP, double 42 HP) including the 24 HP panel instrument case and the remote HMI devices. When this type of mounting alternative is used the 84 HP, 42 HP, double 42 HP and remote HMI devices have got a cover profile fit on and the 24 HP devices have got a mounting frame fit on.

The dimensions of the cut-outs for the 84 HP and 42 HP devices are also applicable for the same sized remote HMI devices.

### 1.2.22.1.1. Flush mounting of 84 HP and 42 HP single rack



#### PANEL CUT-OUT




Figure 21-1 Dimensions for flush mounting of 84 HP and 42 HP single rack




Figure 21-2 3D illustration for flush mounting of 84 HP and 42 HP devices

### 1.2.22.1.2. Flush mounting of 42 HP double rack




Figure 21-3 Dimensions for flush mounting of 42 HP double rack



Figure 21-4 42 HP wide cover profile

### 1.2.22.1.3. Flush mounting of 24 HP panel instrument case




Figure 21-5 Dimensions for flush mounting of 24 HP panel instrument case with 3D illustration

## 1.2.22.2. Rack mounting

When rack mounting is used, the devices do not have a cover profile fit on, so it is possible to mount them in a 19" rack.

### 1.2.22.2.1. Rack mounting of 84 HP and 42 HP single rack




Figure 21-6 Dimensions for rack mounting of 84 HP and 42 HP single rack

Note that rack mounting type devices can also be mounted in a cut-out (e.g. on a switchgear door). It is possible to mount them from the front or from the back of the cut-out. The dimensions for rack mounting cut-outs are in the figure below. Dimensions in brackets are applicable in case of mounting from the back.






Figure 21-7 Dimensions of rack mounting cut-outs





*Figure 21-8 3D illustration for rack mounting of 42 HP device  
(a - from the front; b - from the back)*



*Figure 21-9 3D illustration for rack mounting of 84 HP device  
(a - from the front; b - from the back)*



## 1.2.22.2. Rack mounting of 42 HP double rack




Figure 21-10 Dimensions for rack mounting of 42 HP double rack

### 1.2.22.3. Semi-flush mounting

Semi-flush mounting can be used for 84 HP and 42 HP single racks, for 24 HP panel instrument cases and for remote HMI devices. The purpose of this type of mounting alternative is to reduce the depth of the devices in the switchgear/rack if there is not enough space in that direction. To achieve this, a special mounting collar must be fit on the rack type devices. The default color of the mounting collar is grey (RAL 7035).

The dimensions of the special mounting collars and the cut-outs for the 84 HP and 42 HP devices are also applicable for the same sized remote HMI devices.

#### 1.2.22.3.1. Semi-flush mounting of 84 HP single rack




Figure 21-11 Dimensions for semi-flush mounting of 84 HP single rack with 3D illustration

### 1.2.22.3.2. Semi-flush mounting of 42 HP single rack





Figure 21-12 Dimensions for semi-flush mounting of 42 HP single rack with 3D illustration




### 1.2.22.4. Wall mounting of 42 HP and 84 HP devices

Depending on the amount of the terminal contacts, it is possible to use both upper and lower terminals.



It is possible to open the rack from left to right and vice versa.

Figure 21-14 Dimensions for wall mounting of 42 HP devices (upper and lower terminals)



IED-EP+  
42TE  
WALL-MOUNTING  
DIMENSIONS

Figure 21-15 Dimensions for wall mounting of 42 HP devices (lower terminal only)




Figure 21-16 Dimensions for wall mounting of 84 HP devices (upper and lower terminals)




Figure 21-17 Dimensions for wall mounting of 84 HP devices (lower terminals only)

### 1.2.22.5. Din rail mounting of 24 HP panel instrument case

Note that the IP54 front panel option cannot be utilized with this type of mounting.





Figure 21-18 Dimensions for din rail mounting of 24 HP panel instrument case



### 1.2.22.6. IP54 rated mounting kit

The IP frame seen below provides IP54 protection from front side for 84HP and 42HP devices.



*Figure 21-19 84 HP IP frame front view*




*Figure 21-20 42 HP IP frame front view*


#### **S24 devices**

The S24 devices' front panel *does not differ from the normal front panel on the outside*, as there is IP54 gasket applied within the frame itself. Devices ordered with this option must be mounted by *flush mounting*; with other types of mountings (e.g. semi-flush), the IP54 protection is not guaranteed!





*Figure 21-21: 84 HP IP frame dimensions*



*Figure 21-22 42 HP IP frame dimensions*

## 1.2.22.7. Fold-down mounting

### 1.2.22.7.1. Fold-down mounting without terminals






Figure 21-23 84 HP fold-down mounting





Figure 21-24 42 HP fold-down mounting

## 1.2.22.7.2. Fold-down mounting with terminals




Figure 21-25 Fold-down mounting with terminals for 84HP devices

\*fastening points are customized





Figure 21-26 Fold-down mounting with terminals for 42HP devices



## 1.2.22.8. No mounting

“No mounting” means that the 84 HP and 42 HP devices do not have any mounting accessories on them.

This mounting method is only applicable if the device is for demonstration application.

For more information about this topic please contact our Application Team.  
([application@protecta.hu](mailto:application@protecta.hu))

**IMPORTANT**  
 The dimensions of the cut-outs applicable for the remote HMI are depending on which previously mentioned mounting method is used (flush mounting, semi-flush mounting or rack mounting).

### 1.2.22.9. Remote HMI devices




Figure 21-27 Dimensions for 42 HP wide remote HMI



Figure 21-28 Dimensions for 84 HP wide remote HMI

## 1.2.23. Product availability (special and obsolete modules)

In this chapter you can read a list of the modules that have not regular availability for any reason (being obsolete or being used only in special configurations).

### **Special modules:**

*These modules can be ordered in case of special applications which are indicated for each module at its description in the previous chapters.*

For more information about these devices please contact our Application Team. ([application@protecta.hu](mailto:application@protecta.hu))

### **Optional connectors:**


*The optional connectors are indicated at each module's description in the previous chapters. If a module is to be shipped with an optional connector, the issue must be discussed during ordering.*

| MODULE TYPE | COMMENT   | DATE       |
|-------------|---|------------|
| CPU+/0001   | Legacy CPU card, not recommended for new configurations.<br>Replacement: CPU+1211 | 2013-06-12 |
| CPU+/0002   | Legacy CPU card, not recommended for new configurations.<br>Replacement: CPU+1111 | 2013-06-12 |
| CPU+/0003   | Legacy CPU card, not recommended for new configurations.<br>Replacement: CPU+1101 | 2013-06-12 |
| CPU+/0004   | Legacy CPU card, not recommended for new configurations.<br>Replacement: CPU+1201 | 2013-06-12 |
| CPU+/0005   | Legacy CPU card, not recommended for new configurations.<br>Replacement: CPU+1281 | 2013-06-12 |
| CPU+/0006   | Legacy CPU card, not recommended for new configurations.<br>Replacement: CPU+1381 | 2013-06-12 |
| CT+/1155    | Available only for special configurations.  | 2013-06-12 |
| CT+/5152    | Available only for OGYD bay unit configurations.                                  | 2013-06-12 |
| VT+/2215    | Available only for special configurations.  | 2013-06-12 |
| O12+/2101   | Available only for demonstration applications.                                    | 2013-06-12 |
| O12+/4201   | Available only for demonstration applications.                                    | 2013-06-12 |
| R4S+/01     | Available only for special configurations.  | 2013-06-12 |
| R4S+/16     | Available only for special configurations.  | 2013-06-12 |
| TRIP+/1101  | Obsolete module. Not recommended for new designs.                                 | 2013-06-12 |
| PS+/1602    | Available only for special configurations.  | 2013-06-12 |
| HMI+/2401   | Obsolete module. Not recommended for new designs.                                 | 2014-10-06 |

|                   |  |            |
|-------------------|--|------------|
| <b>HMI+/2404</b>  | Smart Line S24 special selection modules.                                    | 2014-10-06 |
| <b>HMI+/2504</b>  | Smart Line S24 special selection modules.                                    | 2014-10-06 |
| <b>COM+/8882</b>  | Available only for special configurations.                                   | 2014-10-06 |
| <b>CT+/1111</b>   | Available only for special configurations.                                   | 2014-10-06 |
| <b>CT+/2500</b>   | Available only for special configurations.                                   | 2014-10-06 |
| <b>CT+/5153</b>   | Available only for special configurations.                                   | 2014-10-06 |
| <b>VT+/2212</b>   | Available only for special configurations.                                   | 2014-10-06 |
| <b>R8+/01</b>     | Available only for special configurations.                                   | 2014-10-06 |
| <b>R8+/A1</b>     | Available only for special configurations.                                   | 2014-10-06 |
| <b>R8+/C0</b>     | Available only for special configurations.                                   | 2014-10-06 |
| <b>R8+/FF</b>     | Available only for special configurations.                                   | 2014-10-06 |
| <b>R12+/4400</b>  | Available only for special configurations.                                   | 2014-10-06 |
| <b>R16+/0101</b>  | Available only for special configurations.                                   | 2014-10-06 |
| <b>R16+/0001</b>  | Available only for special configurations.                                   | 2014-10-06 |
| <b>R16+/A001</b>  | Available only for special configurations.                                   | 2014-10-06 |
| <b>PS+/4401</b>   | Available only for special configurations.                                   | 2014-10-06 |
| <b>CT+/2500</b>   | Obsolete module. Not recommended for new designs.<br>Replacement: CT+1500.   | 2015-02-13 |
| <b>PSTP+/2102</b> | Available only for special configurations.                                   | 2015-06-23 |
| <b>PSTP+/4202</b> | Available only for special configurations.                                   | 2015-06-23 |
| <b>CT+/5111</b>   | Available only for special configurations.                                   | 2015-12-08 |
| <b>CT+/0101</b>   | Available only for special configurations. DEFL earth fault protection only. | 2018-03-19 |
| <b>INJ+/0015</b>  | Available only for special configurations.                                   | 2018-03-19 |
| <b>CT+/5155</b>   | Available only for special configurations.                                   | 2018-03-26 |
| <b>VT+/2246</b>   | Available only for special configurations.                                   | 2018-03-26 |
| <b>AIC+/0201</b>  | Obsolete module. Not recommended for new designs.                            | 2018-03-26 |
| <b>CT+/5111</b>   | Obsolete module. Not recommended for new designs.                            | 2018-03-27 |
| <b>VS+/0031</b>   | Obsolete module. Not recommended for new designs.                            | 2018-05-25 |



|                             |   |            |
|-----------------------------|---|------------|
| <b>R1T+/0001</b>            | Available only for special configurations. DMD.   | 2018-10-05 |
| <b>CT+/5253</b>             | Available only for special configurations.  | 2018-10-05 |
| <b>42 HP housing</b>        | The length of the 42 HP box has been reduced from 242 mm to 223 mm. For more information about the previous size of the 42 HP box please see the Figure 22-1. | 2018-12-18 |
| <b>AIC+/0200</b>            | Obsolete module. Not recommended for new designs.   | 2019-04-08 |
| <b>PS+/1030</b>             | Available only for special configurations.  | 2020-05-07 |
| <b>PS+/1060</b>             | Available only for special configurations.  | 2020-05-07 |
| <b>HMI+/5001</b>            | Obsolete module. Not recommended for new designs.   | 2020-06-04 |
| <b>HMI+/5002</b>            | Obsolete module. Not recommended for new designs.   | 2020-06-04 |
| <b>HMI+/3502 (for 42HP)</b> | Obsolete module. Not recommended for new designs.   | 2020-06-04 |
| <b>CT+/1515</b>             | Available only for special configurations.  | 2020-06-04 |
| <b>CT+/5115</b>             | Available only for special configurations.  | 2020-06-04 |
| <b>CT+/5116</b>             | Available only for special configurations.  | 2020-06-04 |
| <b>CT+/5154</b>             | Available only for special configurations.  | 2020-06-04 |
| <b>PSF+/1001</b>            | Available only for special configurations.  | 2020-06-04 |
| <b>RTD+/0200</b>            | Available only for special configurations.  | 2020-06-04 |
| <b>RTD+/1200</b>            | Available only for special configurations.  | 2020-06-04 |
| <b>R4MC+/01</b>             | Available only for special configurations.  | 2020-06-04 |
| <b>PS+/4301</b>             | Obsolete module. Not recommended for new designs.   | 2020-06-04 |
| <b>84 HP housing</b>        | The depth of the 84 HP box has been reduced from 242 mm to 223 mm. For more information about the previous size of the 84 HP box, see the Figure 22-1.        | 2021-04-01 |
| <b>HMI+/3501</b>            | Obsolete module. Not recommended for new designs.   | 2021-04-20 |
| <b>HMI+/3502</b>            | Obsolete module. Not recommended for new designs.   | 2021-04-20 |
| <b>HMI+/5701</b>            | Obsolete module. Not recommended for new designs.   | 2021-04-20 |
| <b>HMI+/5702</b>            | Obsolete module. Not recommended for new designs.   | 2021-04-20 |
| <b>COM+/1202</b>            | Obsolete module. Not recommended for new designs.   | 2021-04-20 |
| <b>COM+/1324</b>            | Obsolete module. Not recommended for new designs.   | 2021-04-29 |
| <b>VT+/2212</b>             | Obsolete module. Not recommended for new designs.   | 2021-05-06 |
| <b>CT+/5154</b>             | Obsolete module. Not recommended for new designs.   | 2021-05-06 |
| <b>O16+/2401</b>            | Obsolete module. Not recommended for new designs.   | 2022-03-22 |
| <b>O16+/4801</b>            | Obsolete module. Not recommended for new designs.   | 2022-03-22 |



|                  |   |            |
|------------------|---|------------|
| <b>O16+/1101</b> | Obsolete module. Not recommended for new designs. | 2022-03-22 |
| <b>O16+/2201</b> | Obsolete module. Not recommended for new designs. | 2022-03-22 |

### 1.2.23.1. Previous 42HP and 84HP device housings

As of 2021. Q2, not only the 42HP, but the 84HP devices are shipped with shorter racks as well. Note that this is the only difference between the new and old housings. The new racks are shorter by 19 mm from the front, thus their depth is 223 mm instead of 242 mm.

The mounting methods described in Chapter 21 are valid for the previous racks as well, keeping in mind that the depth of the device is 19 mm bigger than that of the drawings. As an example, see the previous drawing of the flush mounting for 42HP and 84HP devices in Figure 22-1. As a comparison, the new, shorter rack is also drawn in light blue.




Figure 22-1 Dimensions for flush mounting of the previous 84HP and 42HP single rack, including the new (shorter) rack dimensions as well.

## 1.3. Remote I/O (RIO) server description

### 1.3.1.1. Introduction

Remote I/O (RIO) server is an IED, which provides remote binary inputs and outputs far from an EuroProt+ protection device.



Figure 1-1 Remote I/O device



Figure 1-2 Front view and rear view with fastening for mounting rail




Figure 1-3 Remote I/O dimensions

## 1.3.1.2. Application

### 1.3.1.2.1. Connectors, LEDs

The connectors of the device are illustrated in the following figure.




Figure 2-1 Connectors of the device

The RIO server has three LED indicators:

- **LINK:** located at the Ethernet connector; it shows active communication (green color)
- **POWER:** located above the power connector; it lights up if the device is operating (green color)
- **STATUS:** located also above the power connector. The behavior and color of this LED shows different situations:
  - Blinking **red**: there are no clients connected
  - Blinking alternatively **red-green**: the server has one client connected
  - Blinking **green**: two or more clients are connected

### 1.3.1.2.2. Wiring, usage

The device communicates with the EP+ device using the MODBUS/TCP protocol, via either of the COM+/1202, COM+/1324, COM+/1335, COM+/6603 or COM+/6663 modules.




Figure 2-2 Wiring of the Remote I/O-s

The RIO inputs and outputs appear among the other binary inputs and outputs of the EuroProt+ device, and they can be utilized the same way.

### 1.3.1.3. Sub-modules

The RIO server consists of two mixed function modules:

- SCPU/PS: combination of a CPU and power supply module
- SO12/R2: binary I/O module with 12 inputs and 2 relay outputs

#### 1.3.1.3.1. SCPU/PS sub-module

The SCPU/PS module contains all the control, communication and the power supply functions of the device.

##### 1.3.1.3.1.1. CPU

*Table 3-1 Technical data of the RIO CPU*

| CPU TYPE  | ETHERNET INTERFACE  | SERVICE PORT |
|-----------|---|--------------|
| SCPU+0011 | MM/LC 1300 nm,<br>50/62,5/125 µm connector,<br>100Base-FX | RS232*       |

*\*The service port labeled "CONFIG" is only for factory usage*

##### 1.3.1.3.1.2. Power supply, external MCB

*Table 3-2 Technical data of the RIO power supply*

| PS TYPE | INPUT VOLTAGE                    | NOMINAL POWER | INPUT VOLTAGE INTERRUPTION TIME         | INRUSH CURRENT (< 0.1 s) | CONNECTOR TYPE       |
|---------|----------------------------------|---------------|---|--------------------------|----------------------|
| PS+1101 | 65-180 V DC                      | 9 W           | min. 140 ms @<br>110 V DC input voltage | < 10 A                   | Weidmüller BLA 2/180 |
| PS+2301 | 176 – 264 V DC<br>160 – 250 V AC | 9 W           | min. 50 ms @<br>230 V AC input voltage  | < 10 A                   | Weidmüller BLA 2/180 |

The power supply must be protected by an **external midget circuit breaker**. Note that it is not part of the RIO device:

- Characteristics: **6A C**



### 1.3.1.3.2. SO12/R2 sub-module

The SO12/R2 module contains 12 binary inputs in one grounding group, and 2 relay outputs with dry contacts.

#### 1.3.1.3.2.1. Binary inputs

Main features:

- Digitally filtered per channel
- Current drain approx.: 2 mA per channel

*Table 3-3 Technical data of the binary inputs*

| BI TYPE   | CHANNEL NUMBER | TIME SYNC. | RATED VOLTAGE | THERMAL WITHSTAND VOLTAGE | CLAMP VOLTAGE   | CONNECTOR TYPE              |
|-----------|----------------|------------|---------------|---------------------------|---|-----------------------------|
| SO12+4801 | 12             | -          | 48 V          | 72 V                      | falling 0.71 U <sub>N</sub><br>rising 0.76 U <sub>N</sub> | Weidmüller<br>BL 3.5/13/180 |
| SO12+1101 | 12             | -          | 110 V         | 250 V                     | falling 0.7 U <sub>N</sub><br>rising 0.73 U <sub>N</sub>  | Weidmüller<br>BL 3.5/13/180 |

*Thermal withstand voltage: continuous with 60 % of the input channels energized.*


#### 1.3.1.3.2.2. Binary outputs

Main features:

- Breaking capacity, (L/R = 40 ms) at 220 V DC: 0.2 A
- Breaking capacity, (L/R = 40 ms) at 110 V DC: 0.3 A

*Table 3-4 Technical data of the relay outputs*

| BO TYPE | RATED VOLTAGE  | CONTINUOUS CARRY | CONTACT VERSIONS | GROUP ISOLATION | CONNECTOR TYPE             |
|---------|----------------|------------------|------------------|-----------------|----------------------------|
| R2+0001 | 250 V<br>AC/DC | 6 A              | CO               | 2 independent   | Weidmüller<br>BL 3.5/6/180 |



### 1.3.1.4. General data

- Storage temperature: - 40 °C ... + 70 °C
- Operation temperature: - 20 °C ... + 55 °C
- Humidity: 10 % ... 93 %
- Altitude: up to 2000 m
- Atmospheric pressure: 86 ... 106 kPa

### 1.3.1.4.1. Standard conformance


- Electrostatic discharge immunity (ESD), IEC-EN 60255-26:2013, Level 4
  - Test voltages: 15 kV air discharge, 8 kV contact discharge
- Radiated, radio-frequency, electromagnetic field immunity, IEC-EN 60255-26:2013 Level 3
  - Test field strength: 10 V/m
- Electrical fast transient/burst immunity (EFT/B), IEC-EN 60255-26:2013, Level 4
  - Test voltage: 4 kV
- Surge immunity test, IEC-EN 60255-26:2013
  - Test voltages: 2 kV line-to-earth, 1 kV line-to-line
- Immunity to conducted disturbances, induced by radio-frequency fields, IEC-EN 60255-26:2013, Level 3
  - Test voltage: 10 V
- Damped oscillatory wave immunity test, IEC-EN 60255-26:2013
  - Test frequency: 1 MHz
  - Test voltage: 2.5 kV in common mode, 1 kV in differential mode
- Voltage dips, short interruptions and voltage variations immunity, IEC-EN 60255-26:2013
  - Voltage dips: 40 % (200 ms), 70 % (500 ms), 80 % (5000 ms)
- Ripple on d.c. input power port immunity, IEC-EN 60255-26:2013
  - Level 4, 15 % of rated d.c. value
- Power frequency magnetic field immunity test, IEC-EN 60255-26:2013, Level 5
  - Test field strength: 100 A/m continuous, 1000 A/m for 3 s
- Power frequency immunity test on the binary inputs, IEC-EN 60255-26:2013, Class A
  - Test voltages: 300 V in common mode, 150 V in differential mode
- Insulation tests, IEC-EN 60255-27:2013
  - Impulse voltage test
    - Test levels: 5 kV (1 kV for transducer and temperature measuring inputs)
  - Dielectric test
    - Test levels: 2 kV AC 50 Hz (0.705 kV DC for transducer inputs)
  - Insulation resistance
    - Insulation resistance > 15 GΩ
- Radiated emission, IEC-EN 60255-26:2013
 

Limits:

  - 30 MHz to 230 MHz: 50 dB(μV/m) quasi peak, 3 m
  - 230 MHz to 1 000 MHz: 57 dB(μV/m) quasi peak, 3 m
  - 1 GHz to 3 GHz: 76 dB(μV/m) peak, 3 m
  - 3 GHz to 6 GHz: 80 dB(μV/m) peak, 3 m
- Conducted emission, IEC-EN 60255-26:2013
 

Limits:

  - 0,15 MHz to 0,50 MHz: 79 dB(μV) quasi peak, 66 dB(μV) average
  - 0,5 MHz - 30 MHz: 73 dB(μV) quasi peak, 60 dB(μV) average
- Vibration, shock, bump and seismic tests on measuring relays and protection equipment
  - Vibration tests (sinusoidal), Class I, IEC 60255-21-1:1988
  - Shock and bump tests, Class I, IEC 60255-21-2:1988
  - Seismic tests, Class I, IEC 60255-21-3:1993



### 1.3.1.5. Mechanical data

#### 1.3.1.5.1. General mechanical data

- Construction
  - Painted steel surface
- IP protection:
  - IP2x
- Size:
  - See Figure 1-3 for the device dimensions
- Weight:
  - 0.7 kg

#### 1.3.1.5.2. Connectors

Table 5-1 Connectors on the RIO

| CONNECTOR NAME            | CONNECTOR TYPE                                 | STRIP LENGTH [MM] | CONDUCTOR AREA [MM <sup>2</sup> ] | CONDUCTOR DIAMETER [MM]       | TIGHTENING TORQUE [Nm] | MINIMUM BEND RADIUS* |
|---------------------------|--|-------------------|-----------------------------------|-------------------------------|------------------------|----------------------|
| <b>BLA</b>                | Weidmüller<br>BLA 2/180                        | 7                 | 0.2 – 1.5<br>solid: 0.2 – 2.5     | 0.5 – 1.4<br>solid: 0.5 – 1.8 | 0.4 – 0.5              | 3 × OD**             |
| <b>BL 3.5</b>             | Weidmüller<br>BL 3.5/6/180<br>BL<br>3.5/13/180 | 6                 | 0.2 – 1.5                         | 0.5 – 1.4                     | 0.2 – 0.25             | 3 × OD**             |
| <b>PE FASTON TERMINAL</b> | TE Connectivity<br>6.3x0.8                     | 7                 | min. 4                            | min. 2.3                      | -                      | 3 × OD**             |

\* Bend radius is measured along the inside curve of the wire or wire bundles.

\*\* OD is the outer diameter of the wire or cable, including insulation.

The tightening torque of the screw for protective earth connection must be approx. 5 Nm.

During the installation, make sure that the shortest possible length for PE (Protective Earth) cable.

The minimum distance between the device and its wire channel must be at least 3 cm.


## 1.3.2. Technical notes on EOB interoperability

### 1.3.2.1. Description

We experienced some interoperability issues regarding front panel communication with EP+ devices. The link establishment procedure of the ethernet communication become unstable with certain type of NICs (Network Interface Card) of network devices. Network devices with 10/100Base-T speed support has no limitation but devices with 1000Base-T (called gigabit) may cause this link establishment failure. In this case the operating system periodically signals that interface is connected, then disconnected, then connected etc.

### 1.3.2.2. EOB Troubleshooting


- force NIC speed and mode to 10Base-T Full-duplex (setting method may depend on Your PC hardware configuration) on Your PC. Local Area Network settings can be found at:
  - WindowsXP: Control Panel/Network Connections/Local Area Connection
  - Windows 7: Control Panel\All Control Panel Items\Network and Sharing Center




### 1.3.2.3. Workaround

- using station bus interface connector at the front panel of the CPU card
  - if the device equipped with 100Base-Fx station bus interface then You can connect Your computer via a third-party media converter unit
  - if the device equipped with 10/100Base-Tx station bus interface (RJ45) then connect Your computer directly to the EP+ via a crossed CATx cable

#### Service computer



- using EOB at the HMI:
  - in case of unstable link with Your PC apply a third-party external 10/100Base-T switch with one port connected via EOB to the EP+ and other port connected to Your PC via a CATx cable.



### 1.3.2.4. Further details

For getting started guide and IP configuration download: [http://www.protecta.hu/epp-prelim/QuickStart/Quick\\_Start\\_Guide\\_V1.0.pdf](http://www.protecta.hu/epp-prelim/QuickStart/Quick_Start_Guide_V1.0.pdf)

### 1.3.3. EP+ Installation manual

#### USED SYMBOLS

Symbols on devices:



Test voltage: 2 kV




Protective conductor terminal



Do not dispose of this device

Symbols in this document:



Caution, risk of electric shock



Caution, hot surface




Caution, refer to the documentation



Do not dispose of this device





### **1.3.3.1. Introduction**

This manual is intended to provide instruction for proper device installation, which includes mechanical mounting and electrical wiring. Furthermore, the information provided here will strongly support commissioning, maintenance, and deinstallation work as well. This document's targeted user groups are skilled electrical professionals executing installation works and commissioning with EuroProt+ devices.

Given that the EuroProt+ product family has a modular design, the instructions provided here can cover all configurations. Therefore, this manual shall be used in conjunction with the "EuroProt+ Hardware description" document, which includes essential information about all hardware components of the product.

### **1.3.3.2. Equipment handling**

#### **1.3.3.2.1. Unpacking**

Inspect the package for transport damages. Carefully remove the packing material without applying excessive force.

### 1.3.3.2.2. Visual inspection

Identify the product by reading the order code. This can be found on the device nameplate located mostly on the right side of the device in the top right corner and shall be identical to your order.

Picture 2-2 Device nameplate



The protection device may have loose items packed in a different box based on the configuration. Check, that these items are also included in the shipment.

Visually inspect all unpacked items for damages, water ingress, or any sign of external impact. If you discover any transport damage, please notify Protecta Ltd. first and do not start any further work on the equipment.

### 1.3.3.2.3. Storage

If temporary storage is required before installation, please store the device in its original packing in a dry and clean place. The required environmental conditions can be found in the “General data” section of the “EuroProt+ Hardware description” document.

### 1.3.3.3. Mounting

#### 1.3.3.3.1. Tools for mounting

The tools and screws necessary for mounting depend on the method of the mounting, see the “Mounting methods” section of the “EuroProt+ Hardware description” document.

Assuming the panel or cubicle is ready for installation of the device, screwdrivers matching the screws used, pliers, wrenches, etc. are necessary. For safety aspects, mechanical protective gloves shall be used to avoid injuries.

#### 1.3.3.3.2. Environmental conditions

Make sure, that the mounting location fulfils environment requirements stated in the “General data” section of the “EuroProt+ Hardware description” document. The IP protection class of the device shall fit the surrounding environment at the place of installation. It is also important to have space around the device to support conventional cooling (See 3.3).

#### 1.3.3.3.3. Mounting location

Before mounting the device make sure, that suitable space is available in the location of installation. Cutouts shall fit the device rack dimensions and it is recommended to leave 80mm free space behind the IED for the wiring.

The minimum distance between an EP+ device and its wire channel must be at least 3 cm. The minimum distance between two EP+ devices must be at least 10 cm.

### 1.3.3.3.4. Mounting the device

The EuroProt+ product line utilizes different rack sizes and depending on that different mounting methods. An overview of the rack sizes with dimensions and mounting methods can be found in the “Mounting methods” section of the “EuroProt+ Hardware description” document.

During the installation make sure that the shortest possible length for PE (Protective Earth) cable routing is applied.


### 1.3.3.3.5. Safety aspects

#### 1.3.3.3.5.1. Earth connections

##### 1.3.3.3.5.1.1. Protective earth

The device shall be connected to the station earth system with a minimum of 2,5 mm<sup>2</sup> cross-section solid or stranded wire. A 6,3 mm (1/4 inch) female flat connector (according to IEC 61210) shall be used crimped to the earthing wire. During the installation make sure that the shortest possible length for PE (Protective Earth) cable routing is applied.

The earth connection of the device is situated at all kinds of Power supply modules. In the case of more Power supply modules, all of them shall be earthed.



The protective earth connections should not be removed when the equipment is energized.

*Picture 3-5-1-1 Earth connection point of the device at the Power supply module*



##### 1.3.3.3.5.1.2. Stranded wires

Soft soldering of stranded wires is not allowed due to the cold flow of the solder material.



Loose strands of stranded wires can cause fire risk or electric shock. Insulated crimp terminals shall be used.

### 1.3.3.3.5.1.3. Cable screen connection

The screen of the telecommunication cables connected directly to the device shall be terminated to the earthing connection point of the corresponding module.

Picture 3-5-1-3 An example of the cable screen connection



### 1.3.3.3.5.1.4. CT and VT circuits




The CT and VT circuits to be connected to the device shall be connected to the station earth system.

### 1.3.3.3.5.2. Connections of the device

Before connecting the wires, make sure that all voltage levels correspond to the device ratings. It is particularly important by the power supply, trip and binary input, CT and VT module

Use only the connectors provided to the device or identical ones.



The CT connectors shall be fixed with screws provided. During the operation of the device, the CT connectors can be disconnected only after the CT circuits having short-circuited.


### 1.3.3.3.5.3. Optical ports



Take adequate measures to protect your eyes and do not view directly into optical ports.

The fiber optics cables are vulnerable. Sharp bending can damage them. The minimum bending radius can be between 15 cm and 25 cm approximately, depending on the type and the material of the cable. For details see the datasheets of the fiber optics cables to be installed. The fiber shall not be twisted or bent. When connecting or disconnecting the cable always hold the connector, not the cable.

### 1.3.3.3.5.4. Removing and changing modules



Before removing and changing modules first the power supply voltage of the device shall be disconnected. Then all the energizing quantities connected to each module of the device shall be disconnected. Before removing the connectors of the CT modules, the CT circuits shall be short-circuited and disconnected.

The protective earth connection can be disconnected last if it is necessary (e.g. when removing a Power supply module).



The devices contain components that are sensitive to electrostatic discharges. ESD wrist strap shall be worn during any operations with modules.



Some of the modules can operate at high internal temperatures. Remove these modules carefully to avoid any burn injury. Take care of the possible high temperature at each module.



The modules have got sharp edges. Remove them carefully to avoid injury.


After changing a module, it shall be fixed with the screws provided with a torque of 0,5 Nm. Use Philips 2 screwdriver.

### 1.3.3.4. Wiring

#### 1.3.3.4.1. Tools for connecting

Screwdrivers for the connectors: blade 0,6/3,5 mm, 0,4/2,5 mm.

Cutter, stripper, crimper tools to prepare the connecting end of the wires.



### 1.3.3.4.2. Connectors

The “Connectors” section of the “EuroProt+ Hardware description” provides information about the required conductor dimensions and connecting methods. The “Connectors” table shall be used together with the other sections describing the different modules.

### 1.3.3.5. Deinstallation and Repair

#### 1.3.3.5.1. Deinstallation



Before removing the device make sure, that all incoming power supply and control voltages are switched off. The earth connection of the device shall be disconnected last.

#### 1.3.3.5.2. Repair



Thanks to its modular design, many hardware problems can be fixed by replacing single modules. By executing this procedure note, that the printed board’s surface may get hot during normal operation.



In addition, attention shall be paid to the sharp edges of the modules to avoid minor injuries on the hand.

#### 1.3.3.5.3. Disposal




Removed IEDs shall be handed over to a local electronic waste handler for proper disposal and recycling.



*Table 5-3 Disposal of the components and parts*

| <b>IED</b>         | <b>PARTS</b>                       | <b>MATERIAL</b>                      | <b>METHOD OF DISPOSAL</b> |
|--------------------|------------------------------------|--------------------------------------|---------------------------|
| <b>Enclosure</b>   | Metal sheets, fastening elements   | Aluminum, steel                      | Separation and recycling  |
| <b>Modules</b>     | Metallic parts, fastening elements | Aluminum, steel                      | Separation and recycling  |
|                    | Mounted PC boards                  | Plastic, various electronic elements | Separation and recycling  |
|                    | Connectors                         | Plastic, various metals              | Separation and recycling  |
|                    | Transformers, coils                | Iron, copper, plastic, paper         | Separation and recycling  |
|                    | Relays                             | Iron, copper, plastic, other metals  | Separation and recycling  |
| <b>Package</b>     | Box                                | Cardboard                            | Recycling                 |
| <b>Attachments</b> | Manuals, certificates              | Paper                                | Recycling                 |



## 2. Function and I/O listing

The functions listed in [Table 2-1](#) on the next page are the ones that are present most commonly in the configurations, thus they can be considered as factory default arrangements. The hardware information corresponds to the maximum available number of digital I/O, and the default number of analog inputs.

For short descriptions for each function please refer to [Chapter 3](#). Detailed information is available in their respective stand-alone descriptions on the Protecta website after logging in.

\*The 'INST.' column contains the numbers of the pre-configured function blocks in the factory configuration. These numbers may be different in order to meet the user's requirements.



| Distributed feeder protection, control & automation |  |                      |      |           |     |     |     |     |      |     |     |     |     |     |
|---|--|----------------------|------|-----------|-----|-----|-----|-----|------|-----|-----|-----|-----|-----|
| HARDWARE  | FAMILY   |                      |      | EuroProt+ |     |     |     |     |      |     |     |     |     |     |
|   | TYPE   |                      |      | DTIVA     |     |     |     |     |      |     |     |     |     |     |
|   | CONFIGURATION                                    |                      |      | E1        | E2  | E3  | E4  | E5  | E6   | E7  | E8  | E9  | E10 |     |
|   | CT inputs  | 4                    | 4    | 4         | 4   | 4   | 4   | 4   | 4    | 4   |     | 4   | 4   |     |
|   | VT inputs  |                      | 4    | 4         | 4   | 4   | 4   | 4   | 4    | 4   | 4   | 4   | 4   |     |
|   | Digital inputs (max)                             | 136                  | 128  | 128       | 128 | 128 | 128 | 128 | 128  | 136 | 136 | 128 | 128 |     |
|   | Signaling relay outputs (max)                    | 60                   | 60   | 60        | 60  | 60  | 60  | 60  | 60   | 60  | 60  | 60  | 60  |     |
|   | Fast Trip outputs (max)                          | 12                   | 12   | 12        | 12  | 12  | 12  | 12  | 12   | 12  | 12  | 12  | 12  |     |
| FUNCTIONALITY                                       | Function name                                    | IEC                  | ANSI | *INST.    | E1  | E2  | E3  | E4  | E5   | E6  | E7  | E8  | E9  | E10 |
|   | Distance protection MV                           | Z <, FL              | 21   | 1         |     |     |     | ✓   |      | ✓   |     |     |     |     |
|   | Teleprotection                                   |                      | 85   | 1         |     |     |     |     |      | ✓   |     |     |     |     |
|   | Switch onto fault preparation function           |                      |      | 1         |     |     | ✓   | ✓   |      | ✓   |     |     |     |     |
|   | Overexcitation                                   | V/Hz                 | 24   | 1         |     |     |     |     |      |     | ✓   |     |     |     |
|   | Synchrocheck                                     | SYNC                 | 25   | 1         |     |     | ✓   | ✓   |      | ✓   |     | ✓   |     |     |
|   | Definite time undervoltage protection            | U <, U <<            | 27   | 2         |     | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | Op. |
|   | Positive sequence undervoltage protection        | U1 <                 | 27D  | 1         |     |     |     |     |      |     | ✓   |     |     |     |
|   | Directional overpower                            | P >                  | 32   | 1         |     | ✓   | ✓   | ✓   |      | ✓   |     |     | ✓   |     |
|   | Directional underpower                           | P <                  | 37   | 1         |     | ✓   | ✓   | ✓   |      | ✓   |     |     | ✓   |     |
|   | Loss of load (undercurrent) protection           | I <                  | 37   | 1         |     |     |     |     |      |     | ✓   |     |     | ✓   |
|   | Negative sequence overcurrent protection         | I2 >                 | 46   | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   |     |     | ✓   |
|   | Negative sequence overvoltage protection         | U2 >                 | 47   | 1         |     | ✓   | ✓   | ✓   |      | ✓   | ✓   |     |     | ✓   |
|   | Motor startup supervision                        | I <sup>2</sup> start | 48   | 1         |     |     |     |     |      |     | ✓   |     |     |     |
|   | Thermal protection line                          | T >                  | 49   | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   |     |     |     | ✓   |
|   | Thermal protection motor                         | T >                  | 49   | 1         |     |     |     |     |      |     | ✓   |     |     |     |
|   | Three-phase instantaneous overcurrent protection | I >>>                | 50   | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   |     |     | ✓   |
|   | Residual instantaneous overcurrent protection    | Io >>>               | 50N  | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   |     |     | ✓   |
|   | Breaker failure protection                       | CBFP                 | 50BF | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   |     |     | ✓   |
|   | Three-phase time overcurrent protection          | I >, I >>            | 51   | 2         | ✓   | ✓   | ✓   | ✓   | ✓    | Op. | ✓   |     | ✓   | ✓   |
|   | Residual time overcurrent protection             | Io >, Io >>          | 51N  | 2         | ✓   | ✓   | ✓   | ✓   | ✓    | Op. | ✓   |     | ✓   | ✓   |
|   | Definite time overvoltage protection             | U >, U >>            | 59   | 2         |     | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | Op. |
|   | Residual overvoltage protection                  | Uo >, Uo >>          | 59N  | 2         |     | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | Op. |
|   | Starts per hour                                  | I <sup>2</sup> t     | 66   | 1         |     |     |     |     |      |     | ✓   |     |     |     |
|   | Three-phase directional overcurrent protection   | I Dir >, I Dir >>    | 67   | 2         |     |     | ✓   | ✓   | ✓    | ✓   |     |     |     |     |
|   | Residual directional overcurrent protection      | Io Dir >, Io Dir >>  | 67N  | 2         |     | ✓   | ✓   | ✓   | ✓    | ✓   |     |     |     |     |
|   | Inrush detection and blocking                    | I2h >                | 68   | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   |     |     |     |
|   | Out-of-step                                      | ΔZ/Δt                | 78   | 1         |     |     |     | ✓   |      | ✓   |     |     |     |     |
|   | Auto-reclose MV                                  | 0 - > 1              | 79   | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   |     |     |     |     |
|   | Overfrequency protection                         | f >, f >>            | 81O  | 2         |     |     | ✓   | ✓   |      | ✓   |     | ✓   | ✓   |     |
|   | Underfrequency protection                        | f <, f <<            | 81U  | 2         |     |     | ✓   | ✓   |      | ✓   |     | ✓   | ✓   |     |
|   | Rate of change of frequency protection           | df/dt                | 81R  | 1         |     |     | ✓   | ✓   |      | ✓   |     | ✓   | ✓   |     |
|   | Vector jump                                      | ΔφU >                |      | 1         |     |     |     |     |      |     |     |     |     | ✓   |
|   | Line differential                                | 3IdL >               | 87L  | 1         |     |     |     |     | ✓    | ✓   |     |     |     |     |
|   | Motor differential                               | 3IdM >               | 87M  | 1         |     |     |     |     |      |     | ✓   |     |     |     |
|   | Restricted earth fault                           | REF                  | 87N  | 1         |     |     |     |     | Op.* |     |     |     |     |     |
|   | Transformer differential                         | 3IdT >               | 87T  | 1         |     |     |     |     | Op.* |     |     |     |     |     |
|   | Trip Logic                                       |                      | 94   | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |
|   | Lockout Trip Logic                               |                      | 86   | 1         | Op. | Op. | Op. | Op. | Op.  | Op. | Op. | Op. | Op. | Op. |
|   | Busbar sub-unit                                  |                      |      |           | Op. | Op. | Op. |     |      |     |     |     |     |     |
|   | Bay control                                      |                      |      |           | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |
|   | Circuit breaker wear                             |                      |      |           | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |
|   | Circuit breaker control                          |                      |      |           | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |
|   | Disconnecter control                             |                      |      |           | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |
|   | Ethernet Links                                   |                      |      |           | Op. | Op. | Op. | Op. | Op.  | Op. | Op. | Op. | Op. | Op. |
|   | Trip Circuit Supervision                         |                      | 74TC |           | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |
|   | Fuse failure (VTS)                               |                      | 60   | 1         |     |     |     | ✓   |      | ✓   |     |     |     | Op. |
|   | Current unbalance protection                     |                      | 60   | 1         | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   |     |     | ✓   | ✓   |
|   | Current input                                    |                      |      |           |     |     |     | ✓   |      | ✓   | ✓   |     |     | Op. |
|   | Voltage input                                    |                      |      |           | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |
|   | Line measurement                                 |                      |      |           | ✓   | ✓   | ✓   | ✓   | ✓    | ✓   | ✓   | ✓   | ✓   | ✓   |

Table 2-1 Basic functionality and I/O

### 3. Software configuration

#### 3.1. Protection functions

##### 3.1.1. Definite time undervoltage protection function

###### 3.1.1.1. Application

The definite time undervoltage protection function measures three voltages. If any of them is below the level defined by parameter setting value (and above the defined minimum level), then a start signal is generated for the phases individually.

###### 3.1.1.2. Mode of operation

The function generates start signals for the phases individually. The general start signal is set if the voltage in any of the three measured voltages is below the preset parameter setting value (and above the defined minimum level).

Note that in medium voltage applications the function uses the phase-to-phase voltages by default.

The function generates a trip command only if the time delay has expired and the parameter selection requires a trip command as well.

###### 3.1.1.3. Operating characteristics

$$t(G) = t_{OP} \text{ when } G_{min} < G < G_s$$




Figure 1-1 Undervoltage independent time characteristic

|                    |  |
|--------------------|--|
| where              |  |
| $t_{OP}$ (seconds) | theoretical operating time if $G_{min} < G < G_s$ , fix, according to parameter setting value,                           |
| $G$                | measured value of the characteristic quantity, Fourier base harmonic of the phase voltages (or phase-to-phase voltages), |
| $G_s$              | setting value of the characteristic quantity.  |

### 3.1.1.4. Structure of the definite time undervoltage protection algorithm

Fig.1-2 shows the structure of the definite time undervoltage protection (TUV27) algorithm.




Figure 1-2 Structure of the definite time undervoltage protection algorithm

The **inputs** are

- the RMS values of the fundamental Fourier component of three phase (or phase-to-phase) voltages,
- parameters,
- status signals.

The **outputs** are

- the binary output status signals.

The **software modules** of the differential protection function:

#### **Fourier calculations**

These modules calculate the basic Fourier components of the phase voltages individually (not part of the TUV27 function). In medium voltage applications these are changed to phase-to-phase voltages.

#### **Characteristics**

This module calculates the required time delay based on the Fourier components of the phase (or phase-to-phase) voltages.


#### **Decision logic**

The decision logic module combines the status signals to generate the trip command of the function.

The following description explains the details of the individual components.

### 3.1.1.5. The Fourier calculation (Fourier)

These modules calculate the basic Fourier components of the phase voltages individually. They are not part of the TUV27 function; they belong to the preparatory phase.



*Figure 1-3 Schema of the Fourier calculation*

The **inputs** are the sampled values of the three phase voltages (UL1, UL2, UL3)

The **outputs** are the basic Fourier components of the analyzed voltages (UL1Four, UL2Four, UL3Four).

The phase-to-phase voltages (if used) are also calculated here.

### 3.1.1.6. The definite time characteristics (Characteristics)

This module decides the stating of the function based on the Fourier components of the phase voltages and it counts the time delay. The time delay is defined by the parameter setting, if the voltages are below the setting value.

The **inputs** are the basic Fourier components of the phase (or the calculated phase-to-phase) voltages (UL1Four, UL2Four, UL3Four) and parameters.

The **outputs** are the status signals of the three phases individually. These indicate the started state and the generated trip command if the time delay determined by the setting is expired.




Figure 1-4 Schema of the definite time characteristic calculation

#### Enumerated parameter

| Parameter name   | Title     | Selection range                  | Default |
|--|-----------|----------------------------------|---------|
| Enabling or disabling the undervoltage protection function |           |                                  |         |
| TUV27_Oper_EPar_   | Operation | Off, 1 out of 3, 2 out of 3, All | Off     |

Table 1-1 The enumerated parameter of the undervoltage protection function

#### Integer parameters

| Parameter name   | Title         | Unit | Min | Max | Step | Default |
|--|---------------|------|-----|-----|------|---------|
| Starting voltage level setting. If the measured voltage is below the setting value, the function generates a start signal. |               |      |     |     |      |         |
| TUV27_StVol_IPar_  | Start Voltage | %    | 30  | 130 | 1    | 90      |
| Blocking voltage level setting. If the measured voltage is below the setting value, the function blocks the start signal.  |               |      |     |     |      |         |
| TUV27_BlkVol_IPar_   | Block Voltage | %    | 0   | 20  | 1    | 10      |

Table 1-2 Integer parameters of the undervoltage protection function

#### Floating point parameter

| Parameter name   | Title       | Unit | Min | Max | Step | Default |
|--|-------------|------|-----|-----|------|---------|
| Starting voltage level setting. If the measured voltage is below the setting value, the function generates a start signal. |             |      |     |     |      |         |
| TUV27_ResetRatio_FPar_   | Reset Ratio | %    | 1   | 10  | 1    | 5       |

Table 1-3 Floating point parameter of the undervoltage protection function

**Boolean parameter**

| Parameter name     | Title             | Default | Explanation  |
|--------------------|-------------------|---------|--|
| TUV27_StOnly_BPar_ | Start Signal Only | 0       | Selection if starting and trip signal or starting signal only is to be generated. Set 0 for trip command generation. |

*Table 1-4 The Boolean parameter of the undervoltage protection function*

**Timer parameter**

| Parameter name                                      | Title      | Unit | Min | Max   | Step | Default |
|---|------------|------|-----|-------|------|---------|
| Time delay of the undervoltage protection function. |            |      |     |       |      |         |
| TUV27_Delay_TPar_                                   | Time Delay | ms   | 50  | 60000 | 1    | 100     |

*Table 1-5 Timer parameter of the undervoltage protection function*

The **binary output status signals** of the three-phase definite time undervoltage protection function are listed in *Table 1-6*.

| Binary output signals | Signal title | Explanation                               |
|-----------------------|--------------|---|
| TUV27_StL1_Grl_       | StL1         | Starting of the function in phase L1*     |
| TUV27_TrL1_Grl_       | TrL1**       | Trip command of the function in phase L1* |
| TUV27_StL2_Grl_       | StL2         | Starting of the function in phase L2*     |
| TUV27_TrL2_Grl_       | TrL2**       | Trip command of the function in phase L2* |
| TUV27_StL3_Grl_       | StL3         | Starting of the function in phase L3*     |
| TUV27_TrL3_Grl_       | TrL3**       | Trip command of the function in phase L3* |

\*In case of phase-to-phase voltages, these are changed to L12, L23, L31 respectively.

\*\*The trip signals are not published for the phases individually

*Table 1-6 The binary output status signals of the definite time undervoltage protection function*

### 3.1.1.7. The decision logic (Decision logic)

The decision logic module combines the status signals, binary and enumerated parameters to generate the trip command of the function.




Figure 1-5 The logic scheme of the definite time undervoltage protection function

| Binary input signals | Signal title | Explanation                               |
|----------------------|--------------|---|
| TUV27_StL1_Grl_      | StL1         | Starting of the function in phase L1*     |
| TUV27_TrL1_Grl_      | TrL1**       | Trip command of the function in phase L1* |
| TUV27_StL2_Grl_      | StL2         | Starting of the function in phase L2*     |
| TUV27_TrL2_Grl_      | TrL2**       | Trip command of the function in phase L2* |
| TUV27_StL3_Grl_      | StL3         | Starting of the function in phase L3*     |
| TUV27_TrL3_Grl_      | TrL3**       | Trip command of the function in phase L3* |

\*In case of phase-to-phase voltages, these are changed to L12, L23, L31 respectively.


\*\*The trip signals are not published for the phases individually

Table 1-7 The binary input signals of the definite time undervoltage protection function

#### Boolean parameter

| Parameter name              | Title             | Default |
|-----------------------------|-------------------|---------|
| Enabling start signal only: |                   |         |
| TUV27_StOnly_BPar_          | Start Signal Only | FALSE   |

Table 1-8 The Boolean parameter of the definite time undervoltage protection function



### Binary status signals

The undervoltage protection function has a binary input signal, which serves the purpose of disabling the function. The conditions of disabling are defined by the user, applying the graphic equation editor.

| Binary input status signal | Signal title | Explanation  |
|----------------------------|--------------|--|
| TUV27_BlK_GrO_             | Blk          | Output status of a graphic equation defined by the user to disable the definite time undervoltage protection function. |

Table 1-9 The binary input status signal of the definite time undervoltage protection function

| Binary output status signal | Signal title | Explanation                          |
|-----------------------------|--------------|--------------------------------------|
| TUV27_GenSt_Grl_            | GenSt        | General starting of the function     |
| TUV27_GenTr_Grl_            | GenTr        | General trip command of the function |

Table 1-10 The binary output status signals of the definite time undervoltage protection function

## 3.1.1.8. Technical summary

### 3.1.1.8.1. Technical data

| Function                  | Value | Accuracy              |
|---------------------------|-------|-----------------------|
| Pick-up starting accuracy |       | $< \pm 0,5 \%$        |
| Blocking voltage          |       | $< \pm 1,5 \%$        |
| Reset time                |       |                       |
| $U > \rightarrow U_n$     | 50 ms |                       |
| $U > \rightarrow 0$       | 40 ms |                       |
| Operate time accuracy     |       | $< \pm 20 \text{ ms}$ |
| Minimum operate time      | 50 ms |                       |

Table 1-11 Technical data of the undervoltage protection function

#### 3.1.1.8.1.1. The parameters

The parameters are summarized in Chapters 3.1.2.5 and 3.1.2.6



### 3.1.1.8.2. Binary output status signals

The **binary output status signals** of undervoltage protection function are listed in [Table 1-12](#)

| Binary output status signal | Title | Explanation          |
|-----------------------------|-------|----------------------|
| TUV27_StL1_Grl_             | StL1  | Start in phase L1*   |
| TUV27_StL2_Grl_             | StL2  | Start in phase L2*   |
| TUV27_StL3_Grl_             | StL3  | Start in phase L3*   |
| TUV27_GenSt_Grl_            | GenSt | General start signal |
| TUV27_GenTr_Grl_            | GenTr | General trip command |

\*In case of phase-to-phase voltages, these are changed to L12, L23, L31 respectively.

*Table 1-12 The binary output status signals of the undervoltage protection function*

### 3.1.1.8.3. Binary input status signals

#### Binary input signals


The undervoltage protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Title | Explanation                                      |
|----------------------|-------|--|
| TUV27_BlK_GrO_       | Blk   | Blocking of the undervoltage protection function |

*Table 1-13 The binary input signal of undervoltage protection function*

### 3.1.1.8.4. The function block

The function block of undervoltage protection function is shown in [Figure 1-6](#). This block shows all binary input and output status signals that are applicable in the graphic equation editor.



*Figure 1-6 The function block of undervoltage protection function*

## 3.1.2. Directional over-power protection function

### 3.1.2.1. Application

The directional over-power protection function can be applied to protect any elements of the electric power system mainly generators if the active and/or reactive power has to be limited.

### 3.1.2.2. Mode of operation

The inputs of the function are the Fourier basic harmonic components of the three phase currents and those of the three phase voltages.

Based on the measured voltages and currents, the block calculates the three-phase active and reactive power (point S in Figure 1-1) and compares the P-Q coordinates with the defined characteristics on the power plane. The characteristic is defined as a line laying on the point S<sub>s</sub> and perpendicular to the direction of S<sub>s</sub>. The S<sub>s</sub> point is defined by the “Start power” magnitude and the “Direction angle”. The over-power function operates if the angle of the S-S<sub>s</sub> vector related to the directional line is below 90 degrees and above -90 degrees.

At operation, the “Start power” value is decreased by a hysteresis value.




Figure 1-1 The directional over-power decision

### 3.1.2.3. Structure of the directional over-power protection algorithm

Figure 1-2 shows the structure of the directional over-power protection (DOP32) algorithm.




Figure 1-2 Structure of the directional over-power protection algorithm

The **inputs** are

- the RMS value of the fundamental Fourier component of the three phase currents (IL1, IL2, IL3),
- the RMS value of the fundamental Fourier component of the three phase voltages (UL1, UL2, UL3),
- parameters, status signals

The function can be enabled or disabled (Blk). The status signal of the VTS (voltage transformer supervision) function can also disable the directional operation.

The **outputs** are

- the binary output status signals.

The **software modules** of the directional over-power protection function are described in the following chapter.

#### 3.1.2.3.1. P-Q calculation

Based on the RMS values of the fundamental Fourier component of the three phase currents and of the three phase voltages, this module calculates the three-phase active and reactive power values.

The **input signals** are the RMS values of the fundamental Fourier components of the three phase currents and three phase voltages.

The **internal output signals** are the calculated three-phase active and reactive power values.



### 3.1.2.3.2. Directional decision

This module decides if, on the power plane, the calculated complex power is farther from the origin than the corresponding point of the characteristic line. The operation of this function is explained in Figure 1-1.

The **internal input signals** are the calculated active and reactive power values.

The **internal output signal** is the start signal of the function.

### 3.1.2.3.3. The decision logic

This part of the function block combines status signals to make a decision to start. Additionally to the directional decision, for the operation, the function must not be blocked by the general “Block” signal, and may not be blocked by the signal “Block for VTS” of the voltage transformer supervision function.

If the parameter setting requires also a trip signal (Start Signal Only = 0), then the measurement of the definite time delay is started. The expiry of this timer results in a trip command.

### 3.1.2.4. Directional over-power protection function overview

The function block of the directional over-power protection function is shown on the figure below. This block shows all binary input and output status signals that are applicable in the graphic equation editor.




Figure 2-1 The function block of the directional over-power protection function

### 3.1.2.5. Settings

#### 3.1.2.5.1. Parameters

Table 2-1 Parameters of the over-power protection function

| TITLE             | DIM  | RANGE       | STEP | DEFAULT | EXPLANATION  |
|-------------------|------|-------------|------|---------|--|
| Operation         | -    | Off, On     | -    | Off     | Enabling the function  |
| Start Signal Only | -    | FALSE, TRUE | -    | FALSE   | Selection: start signal only or both start signal and trip command |
| Direction Angle   | deg  | -179 – 180  | 1    | 0       | Angle which belongs to Start power                                 |
| Start Power       | %    | 1.0 – 200.0 | 0.1  | 10.0    | Start power of the function  |
| Time Delay        | msec | 200 – 60000 | 1    | 200     | Definite time delay of the trip command                            |

### 3.1.2.6. Function I/O


This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.1.2.6.1. Binary output signals (graphed input statuses)

The binary output status signals of the over-power protection function can be found in the following table. **Parts** written in **bold** are seen on the function block in the logic editor.

Table 2-2 The binary output status signals of the directional over-power protection function

| BINARY STATUS SIGNAL      | TITLE         | EXPLANATION                          |
|---------------------------|---------------|--------------------------------------|
| DOP32_ <b>GenSt</b> _Grl_ | General Start | General start signal of the function |
| DOP32_ <b>GenTr</b> _Grl_ | General Trip  | Trip command of the function         |



### 3.1.2.6.2. Binary input signals (graphed output statuses)

The directional over-power protection function has binary input status signals. **The conditions are defined by the user, applying the graphic equation editor.**

*Table 2-3 The binary input status signals of the directional over-power protection function*

| BINARY STATUS SIGNAL | TITLE          | EXPLANATION   |
|----------------------|----------------|---|
| DOP32_VTS_GrO_       | Block from VTS | Blocking signal from the voltage transformer supervision function |
| DOP32_Blk_GrO_       | Block          | General blocking signal   |

### 3.1.2.6.3. On-line data

Visible values on the on-line data page:

*Table 2-4 On-line data of the directional over-power protection function*

| SIGNAL TITLE  | DIMENSION | EXPLANATION                          |
|---------------|-----------|--------------------------------------|
| General Start | -         | General start of the function        |
| General Trip  | -         | General trip command of the function |

### 3.1.2.6.4. Events

The following events are generated in the event list, as well as sent to SCADA according to the configuration.

*Table 2-5 Events of the directional over-power protection function*

| EVENT         | VALUE   | EXPLANATION                          |
|---------------|---------|--------------------------------------|
| General Start | off, on | General start of the function        |
| General Trip  | off, on | General trip command of the function |

### 3.1.2.7. Technical data

Table 2-6 Technical data of the directional over-power protection function

| FUNCTION                     | VALUE                                       | ACCURACY          |
|------------------------------|---|-------------------|
| P, Q measurement             | $I > 10\% I_n^*$                            | < 5%              |
| P, Q measurement with CT1500 | $I > 5\% I_n^*$                             | < 5%              |
| Direction angle              | $-179 - + 180^\circ^*$                      | < 5%              |
|                              | * = Angle btw. U&I: $-70^\circ - +70^\circ$ |                   |
| Reset ratio                  | 0,95  |                   |
| Reset time                   | < 100 ms                                    |                   |
| Operating time               | < 125 ms                                    |                   |
| Time delay                   | 0.2 – 60 s                                  | 1% or $\pm 25$ ms |

#### 3.1.2.7.1. Notes for testing

Normally in the EuroProt+ devices the trip contacts are assigned to the Trip Logic function block, and not to the protection function blocks. Because of this, the testing personnel must make sure that the Trip Logic is switched on ('Operation' parameter is set to other than 'Off') before starting the testing, otherwise there will be no physical trip on the relay.

The function is based on the power measurement of the Line Measurement function block. This must be taken into consideration when the device has a separate CT for measurements, because with it, the over-power protection function will use that CT as well.

### 3.1.3. Directional under-power protection function

#### 3.1.3.1. Application

The directional under-power protection function can be applied mainly to protect any elements of the electric power system, mainly generators, if the active and/or reactive power has to be limited in respect of the allowed minimum power.

#### 3.1.3.2. Mode of operation

The inputs of the function are the Fourier basic harmonic components of the three phase currents and those of the three phase voltages.

Based on the measured voltages and currents, the block calculates the three-phase active and reactive power (point S in Figure 1-1) and compares the P-Q coordinates with the defined characteristics on the power plane. The characteristic is defined as a line laying on the point  $S_s$  and perpendicular to the direction of  $S_s$ . The  $S_s$  point is defined by the “Start power” magnitude and the “Direction angle”. The under-power function operates if the angle of the S- $S_s$  vector related to the directional line is above 90 degrees or below -90 degrees, i.e. if the point S is on the “Operate” side of the P-Q plane.

At operation, the “Start power” value is increased by a hysteresis value.




Figure 1-1 The directional under-power decision



### 3.1.3.3. Structure of the directional under-power protection algorithm

Figure 1-2 shows the structure of the directional under-power protection (DUP32) algorithm.




Figure 1-2 Structure of the directional under-power protection algorithm

The **inputs** are

- the RMS value of the fundamental Fourier component of the three phase currents (IL1, IL2, IL3),
- the RMS value of the fundamental Fourier component of the three phase voltages (UL1, UL2, UL3),
- parameters,
- status signals.

The function can be enabled or disabled (BLK input signal). The status signal of the VTS (voltage transformer supervision) function can also disable the directional operation.

The **outputs** are

- the binary output status signals.


The **software modules** of the directional under-power protection function are described in the following chapters.

#### 3.1.3.3.1. P-Q calculation

Based on the RMS values of the fundamental Fourier component of the three phase currents and of the three phase voltages, this module calculates the three-phase active and reactive power values.

The **input signals** are the RMS values of the fundamental Fourier components of the three phase currents and three phase voltages.

The **internal output signals** are the calculated three-phase active and reactive power values.



### 3.1.3.3.2. Directional decision

This module decides if, on the power plane, the calculated complex power is closer to the origin than the corresponding point of the characteristic line, i.e. if the point S is on the “Operate” side of the P-Q plane. The operation of this function is explained in Figure 1-1.

The **internal input signals** are the calculated active and reactive power values.

The **internal output signal** is the start signal of the function.

### 3.1.3.3.3. The decision logic

This part of the function block combines status signals to make a decision to start. Additionally to the directional decision, for the operation, the function must not be blocked by the general “Block” signal, and may not be blocked by the signal “Block for VTS” of the voltage transformer supervision function.

If the parameter setting requires also a trip signal (Start Signal Only = 0), then the measurement of the definite time delay is started. The expiry of this timer results in a trip command.

### 3.1.3.4. Directional under-power protection function overview

The function block of the directional under-power protection function is shown on the figure below. This block shows all binary input and output status signals that are applicable in the graphic equation editor.




Figure 2-1 The function block of the directional under-power protection function

#### 3.1.3.4.1. Settings

##### 3.1.3.4.1.1. Parameters

Table 2-1 Parameters of the under-power protection function

| TITLE             | DIM  | RANGE       | STEP | DEFAULT | EXPLANATION  |
|-------------------|------|-------------|------|---------|--|
| Operation         | -    | Off, On     | -    | Off     | Enabling the function  |
| Start Signal Only | -    | FALSE, TRUE | -    | FALSE   | Selection: start signal only or both start signal and trip command |
| Direction Angle   | deg  | -179 – 180  | 1    | 0       | Angle which belongs to Start power                                 |
| Start Power       | %    | 1.0 – 200.0 | 0.1  | 10.0    | Start power of the function  |
| Time Delay        | msec | 200 – 60000 | 1    | 200     | Definite time delay of the trip command                            |

#### 3.1.3.4.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

##### 3.1.3.4.2.1. Binary output signals (graphed input statuses)

The binary output status signals of the under-power protection function can be found in the following table. **Parts** written in **bold** are seen on the function block in the logic editor.

Table 2-2 The binary output status signals of the directional under-power protection function

| <b>BINARY STATUS SIGNAL</b> | <b>TITLE</b>  | <b>EXPLANATION</b>                   |
|-----------------------------|---------------|--------------------------------------|
| DUP32_ <b>GenSt</b> _GrI_   | General Start | General start signal of the function |
| DUP32_ <b>GenTr</b> _GrI_   | General Trip  | Trip command of the function         |



### 3.1.3.4.2.2. Binary input signals (graphed output statuses)

The directional under-power protection function has binary input status signals. **The conditions are defined by the user, applying the graphic equation editor.**

*Table 2-3 The binary input status signals of the directional under-power protection function*

| BINARY STATUS SIGNAL | TITLE          | EXPLANATION   |
|----------------------|----------------|---|
| DUP32_VTS_GrO_       | Block from VTS | Blocking signal from the voltage transformer supervision function |
| DUP32_Blk_GrO_       | Block          | General blocking signal   |

### 3.1.3.4.2.3. On-line data

Visible values on the on-line data page:

*Table 2-4 On-line data of the directional under-power protection function*


| SIGNAL TITLE  | DIMENSION | EXPLANATION                          |
|---------------|-----------|--------------------------------------|
| General Start | -         | General start of the function        |
| General Trip  | -         | General trip command of the function |

### 3.1.3.4.2.4. Events

The following events are generated in the event list, as well as sent to SCADA according to the configuration.

*Table 2-5 Events of the directional under-power protection function*

| EVENT         | VALUE   | EXPLANATION                          |
|---------------|---------|--------------------------------------|
| General Start | off, on | General start of the function        |
| General Trip  | off, on | General trip command of the function |



### 3.1.3.4.3. Technical data

Table 2-6 Technical data of the directional under-power protection function

| FUNCTION             | VALUE                                       | ACCURACY          |
|----------------------|---|-------------------|
| P,Q measurement      | $I > 10\% I_n^*$                            | < 5%              |
| P,Q meas with CT1500 | $I > 5\% I_n^*$                             | < 5%              |
| Direction angle      | $-179 - + 180^\circ^*$                      | < 5%              |
|                      | * = Angle btw. U&I: $-70^\circ - +70^\circ$ |                   |
| Reset ratio          | 1.05  |                   |
| Reset time           | < 100 ms                                    |                   |
| Operating time       | < 125 ms                                    |                   |
| Time delay           | 0.2 – 60 s                                  | 1% or $\pm 25$ ms |

#### 3.1.3.4.3.1. Notes for testing

Normally in the EuroProt+ devices the trip contacts are assigned to the Trip Logic function block, and not to the protection function blocks. Because of this, the testing personnel must make sure that the Trip Logic is switched on ('Operation' parameter is set to other than 'Off') before starting the testing, otherwise there will be no physical trip on the relay.

The function is based on the power measurement of the Line Measurement function block. This must be taken into consideration when the device has a separate CT for measurements, because with it, the under-power protection function will use that CT as well.

### 3.1.4. Broken conductor protection

#### 3.1.4.1. Application

The broken conductor protection function can be applied to detect a power lines and cables broken conductor condition or a single-pole breaker malfunction condition.

##### 3.1.4.1.1. Mode of operation

By measuring the phase current input signals and compares the ratio of negative phase sequence current ( $I_2$ ) to positive phase sequence current ( $I_1$ ).

If the  $I_2/I_1$  ratio is above the setting limit, the function generates a start signal. It is a necessary precondition of start signal generation that the *positive phase sequence current ( $I_1$ ) must be between 6.67% and 100% of the rated current.*

The function can be disabled by parameter setting, and by an input signal programmed by the user with the graphic programming tool.

The trip command is generated after the defined time delay if trip command is enabled by parameter setting.

##### 3.1.4.1.2. Operation principles

Figure 1-1 shows the structure of the broken conductor protection algorithm.




Figure 1-1 Structure of the broken conductor protection algorithm

The **inputs** of the preparatory phase are

- the three phase currents,

The **outputs** of the preparatory phase are

- positive phase sequence current ( $I_1$ ) and negative phase sequence current ( $I_2$ ) values of the fundamental Fourier component of three phase currents.
- the RMS value of the fundamental Fourier components of positive phase sequence current ( $I_1$ ) and negative phase sequence current ( $I_2$ ).

The **inputs** of the broken conductor function are

- the RMS value of the fundamental Fourier component of the positive phase sequence current ( $I_1$ ) and negative phase sequence current ( $I_2$ ),
- parameters,
- status signals.

The **outputs** are

- the binary output status signals.

The **software modules** of the broken conductor function:

**Fourier calculations**

These modules calculate the RMS values of the basic Fourier current components of the phase currents individually (not part of the PBC46 function).

**Positive and negative sequence**

This module calculates the basic Fourier current components of the positive and negative sequence currents, based on the Fourier components of the phase currents (not part of the PBC46 function).

**Analogue signal processing**

This module processes the positive and negative phase sequence current components to prepare the signals for the decision.


**Decision logic**

The decision logic module combines the status signals to generate the starting signal and the trip command of the function.

The following description explains the details of the individual components.

**3.1.4.1.3. The Fourier calculation (Fourier)**

These modules calculate the RMS values of the fundamental Fourier components of the phase currents individually. They are not part of the PBC46 function; they belong to the preparatory phase.



*Figure 1-2 Principal scheme of the Fourier calculation*

The **inputs** are the sampled values of the three phase currents (IL1, IL2, IL3)

The **outputs** are the RMS values of the fundamental Fourier components of the phase currents (IL1Four, IL2Four, IL3Four).

### 3.1.4.1.4. The positive and negative phase sequence calculation (Positive and negative sequence)

This module calculates the positive and negative phase sequence components based on the Fourier components of the phase currents. This module belongs to the preparatory phase.

The **inputs** are the basic Fourier components of the phase currents (IL1Four, IL2Four, IL3Four).

The **outputs** are the basic Fourier components of the positive (IPosFour) and negative sequence current component (INegFour).




Figure 1-3 Schema of the sequence component calculation

### 3.1.4.1.5. The Analogue signal processing

This module processes the Fourier components of the phase currents to prepare the signals for the decision.





Figure 1-4 Principal scheme of the analogue signal processing





The **inputs** are the basic Fourier component of the positive (IPosFour) and negative sequence currents (INegFour) and parameters.

The **outputs** are internal binary signals:

- $I2/I1 >$  the ratio of negative sequence current (I2) to positive sequence current (I1) as a percentage is above the limit defined by the preset parameter PBC46\_StCurr\_IPar\_ (Start current);
- $I1 > 0.1/3I_n$  the positive phase sequence current (I1) value of the fundamental Fourier components of the phase currents is sufficient for evaluation;
- $I1 < 1.0I_n$  the positive phase sequence current (I1) value of the fundamental Fourier components of the phase currents is sufficient for evaluation.

### 3.1.4.1.6. The decision logic (Decision logic)

The decision logic module combines the status signals, binary and enumerated parameters to generate the trip command of the function.




Figure 1-5 The logic scheme of the broken conductor function

The **inputs** are internal binary signals:

- $I2/I1 >$  the ratio of positive phase sequence current (I1) to negative phase sequence current (I2) as a percentage is above the limit defined by the preset parameter "Start current";
- $I1 > 0.1/3I_n$  the positive phase sequence current (I1) value of the fundamental Fourier components of the phase currents is sufficient for evaluation;
- $I1 < 1.0I_n$  the positive phase sequence current (I1) value of the fundamental Fourier components of the phase currents is sufficient for evaluation.

### 3.1.4.2. Broken conductor protection function overview

The graphic appearance of the function block of the broken conductor protection function is shown below. The block shows all binary input and output status signals which are applicable in the graphic equation editor.




Figure 2-1 Graphic appearance of the function block of the broken conductor protection function

### 3.1.4.3. Settings

#### 3.1.4.3.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

Table 2-1 Parameters of the broken conductor protection function

| TITLE             | DIM  | RANGE       | STEP | DEFAULT | EXPLANATION   |
|-------------------|------|-------------|------|---------|---|
| Operation         | -    | Off, On     | -    | Off     | Enabling the function   |
| Start Signal Only | -    | FALSE, TRUE | -    | FALSE   | When checked, the function provides start signal, but no trip signal.           |
| Start Current     | %    | 10 – 90     | 1    | 50      | I2/I1 ratio setting   |
| Time Delay        | msec | 100 – 60000 | 1    | 1000    | Time delay (including the algorithm time, see Chapter 2.4 for more explanation) |

### 3.1.4.4. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.1.4.4.1. Analogue inputs

The function uses the sampled values of a current input. This is defined in the configuration.

#### 3.1.4.4.2. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the Logic editor.

*Table 2-2 The binary input signal of the broken conductor protection function*

| BINARY OUTPUT SIGNAL    | EXPLANATION                    |
|-------------------------|--------------------------------|
| PBC46_ <b>Bik</b> _GrO_ | Blocking input of the function |

#### 3.1.4.4.3. Binary output signals (graphed input statuses)

These signals can be used in EuroCAP to assign to LED, user LCD object etc. Parts written in **bold** are seen on the right side of the function block in the *Logic Editor*.

*Table 2-3 The binary output signals of the broken conductor protection function*

| BINARY OUTPUT SIGNAL      | SIGNAL TITLE  | EXPLANATION                          |
|---------------------------|---------------|--------------------------------------|
| PBC46_ <b>GenSt</b> _Grl_ | General Start | General start signal of the function |
| PBC46_ <b>GenTr</b> _Grl_ | General Trip  | General trip command of the function |

#### 3.1.4.4.4. Online data

Visible values on the *online data* page.

*Table 2-4 Online displayed data of the broken conductor protection function*


| SIGNAL TITLE  | DIMENSION | EXPLANATION                          |
|---------------|-----------|--------------------------------------|
| General Start | -         | General start signal of the function |
| General Trip  | -         | General trip command of the function |

#### 3.1.4.4.5. Events

The following events are generated in the event list, as well as sent to the SCADA according to the configuration.

*Table 2-5 Generated events of the broken conductor protection function*

| EVENT         | VALUE   | EXPLANATION                          |
|---------------|---------|--------------------------------------|
| General Start | off, on | General start of the function        |
| General Trip  | off, on | General trip command of the function |



### 3.1.4.5. Technical data

Table 2-6 Technical data of the broken conductor protection function


| FUNCTION                  | VALUE | ACCURACY |
|---------------------------|-------|----------|
| Pick-up starting accuracy |       | < 2 %    |
| Reset ratio               | 0,95  |          |
| Min. operate time         | 70 ms |          |

### 3.1.4.6. Notes for testing

Normally in the EuroProt+ devices the trip contacts are assigned to the Trip Logic function block, and not to the protection function blocks. Because of this, the testing personnel must make sure that the Trip Logic is switched on ('Operation' parameter is set to other than 'Off') before starting the tests, otherwise there will be no physical trip on the relay.

Note that the time delay parameter incorporates the algorithm time as well, so the time delay *does not mean the time difference between the appearance of the start and trip signals* of the function. In other words: it is not the delay between the detection of the fault and the trip that follows it. This should be taken into consideration when checking the disturbance records.

Instead the time delay parameter defines the elapsed time from the appearance of the faulty state to the trip. Because of this, while testing, the delay measurement should start *from the moment of the fault injection* until the trip signal.



## 3.1.5. Breaker failure protection

### 3.1.5.1. Application

After a protection function generates a trip command, it is expected that the circuit breaker opens and the fault current drops below the pre-defined normal level.

If not, then an additional trip command must be generated for all backup circuit breakers to clear the fault. At the same time, if required, a repeated trip command can be generated to the circuit breaker(s) which are expected to open.

The breaker failure protection function can be applied to perform this task.

In EuroProt+ product family two versions of breaker failure protection function can be applied:

#### “BRF50” – Breaker Failure:

This version of the breaker failure protection can be applied to perform the task to give command to the backup circuit breakers. It can be applied if only common-phase handling is sufficient, and phase selectivity is not required.

BRF50SP

#### “BRF50SP” - Single-pole Breaker Failure:

*If repeated trip command (retrip) is needed besides the backup trip, this version of breaker failure protection function must be used.*

Both versions of breaker failure protection function receive the trip requirements of the protective functions implemented in the device and combines the binary signals and parameters to the outputs of the device.

### 3.1.5.1.1. Mode of operation


The starting signal of the breaker failure protection function is usually the trip command of any other protection function. The user has the task to define these starting signals using the graphic equation editor as the “General Start” (BRF50\_**GenSt**\_GrO\_), or if the operation of the individual phases is needed, then the start signals for the phases individually.

The phase start signals are: “Start L1” (BRF50\_**StL1**\_GrO\_), “Start L2” (BRF50\_**StL2**\_GrO\_) and “Start L3” (BRF50\_**StL3**\_GrO\_).

Dedicated timers start at the rising edge of the start signals, one for the backup trip command and one for the repeated trip command, separately for operation in the individual phases. During the running time of the timers the function optionally monitors the currents, the closed state of the circuit breakers or both, according to the user’s choice. The selection is made using the enumerated parameter “Operation”:

- If this parameter setting is “Current”, the current limit values “Start Ph Current” and “Start Res Current” must be set correctly. The binary input indicating the status of the circuit breaker has no meaning.
- If this parameter setting is “Contact”, the current limit values “Start current Ph” and “Start current N” have no meaning. The binary input indicating the status of the circuit breaker must be programmed correctly using the graphic equation editor.
  - *By using “BRF50” variant:* the input variable to be programmed is: BRF50\_**CBClosed**\_GrO\_ (CB Closed),
  - *By using “BRF50SP” variant:* the input variables to be programmed are: BRF50\_**CBCIL1**\_GrO\_ (CB closed L1), BRF50\_**CBCIL2**\_GrO\_ (CB closed L2) and BRF50\_**CBCIL3**\_GrO\_ (CB closed L3).
- If this parameter setting is “Current/Contact”, the current parameters and the status signal must be set correctly. The breaker failure protection function resets only if all conditions for faultless state are fulfilled.

BRF50SP




- The breaker failure protection function can be disabled by setting this parameter to “Off”. If at the end of the running time of the backup timer the currents do not drop below the pre-defined level, and/or the monitored circuit breaker is still in closed position, then a backup trip command is generated. The time delay is defined using the parameter “Backup Time Delay”.

The pulse duration of the trip command is not shorter than the time defined by setting the parameter “Pulse Duration”.

BRF50SP

*If repeated trip command is to be generated for the circuit breakers that are expected to open, then the enumerated parameter “Retrip” must be set to “On”. In this case, at the end of the retrip timer(s) the delay of which is set by the timer parameter “Retrip Time Delay”, a repeated trip command is also generated in the phase(s) where the backup timer(s) run off.*

Dynamic blocking is possible using the binary input BRF50\_**Bik**\_GrO\_ (Block). The conditions are to be programmed by the user, using the graphic equation editor.



### 3.1.5.1.2. Operation principles

The decision logic module combines status signals, binary and enumerated parameters to generate the backup trip signal.

#### Binary status signals

The breaker failure protection function has binary input signals. **The conditions are defined by the user, applying the graphic equation editor.**

The **binary input status signals** of the breaker failure protection function are listed in Table 1-1.

*Table 1-1 The binary input status signals of the decision logic*

| BINARY STATUS SIGNAL | TITLE           | EXPLANATION   |
|----------------------|-----------------|---|
| BRF50_BIk_GrO_       | Block           | Blocking of the breaker failure protection function                   |
| BRF50_CBClosed_GrO_  | CB closed       | Signal indicating the closed state of the circuit breaker             |
| BRF50SP_CBCIL1_GrO_  | CB closed L1    | Signal indicating the closed state of the circuit breaker in phase L1 |
| BRF50SP_CBCIL2_GrO_  | CB closed L2    | Signal indicating the closed state of the circuit breaker in phase L2 |
| BRF50SP_CBCIL3_GrO_  | CB closed L3    | Signal indicating the closed state of the circuit breaker in phase L3 |
| BRF50_GenSt_GrO_     | General Start   | General starting signal   |
| BRF50SP_StL1_GrO_    | Start L1        | Starting signal in phase L1   |
| BRF50SP_StL2_GrO_    | Start L2        | Starting signal in phase L2   |
| BRF50SP_StL3_GrO_    | Start L3        | Starting signal in phase L3   |
| BRF50_loSt_GrO_      | Start lo        | Starting signal for the residual current                              |
| Internal signal:     | IL1>            | Current in phase L1 is above the preset parameter value               |
| Internal signal:     | IL2>            | Current in phase L2 is above the preset parameter value               |
| Internal signal:     | IL3>            | Current in phase L3 is above the preset parameter value               |
| Internal signal:     | lo>             | Current 3lo is above the preset parameter value                       |
| Enumerated parameter | Current/Contact | The monitored condition is current, contact or both                   |






Figure 1-1 The logic scheme of the decision logic of “BRF50” variant





Figure 1-2 The logic scheme of the decision logic of “BRF50SP” variant



The **binary output status signals** of the breaker failure protection function is detailed in Table 1-2.

*Table 1-2 The binary output status signal of the decision logic*

BRF50SP

| BINARY STATUS SIGNAL | TITLE       | EXPLANATION  |
|----------------------|-------------|--|
| BRF50_BuTr_Grl_      | Backup Trip | Trip command generated for the backup circuit breakers |
| BRF50_TrL1_Grl_      | Retrip L1   | Repeated trip command in phase L1                      |
| BRF50_TrL2_Grl_      | Retrip L2   | Repeated trip command in phase L2                      |
| BRF50_TrL3_Grl_      | Retrip L3   | Repeated trip command in phase L3                      |

### 3.1.5.2. Breaker failure protection function overview

The graphic appearance of the variants the breaker failure protection function blocks are shown below. The blocks show all binary input and output status signals which are applicable in the graphic equation editor.




Figure 2-1 Graphic appearance of the variants of the breaker failure protection function block

#### 3.1.5.2.1. Settings

##### 3.1.5.2.1.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

Table 2-1 Parameters of the breaker failure protection function

| TITLE                        | DIM  | RANGE                                  | STEP | DEFAULT | EXPLANATION  |
|------------------------------|------|--|------|---------|--|
| Operation                    | -    | Off, Current, Contact, Current/Contact | -    | Off     | Enabling the function  |
| BRF50SP<br>Retrip            | -    | Off, On                                | -    | Off     | Enabling the retrip function   |
| Start Ph Current             | %    | 20 – 200                               | 1    | 30      | Phase current setting  |
| Start Res Current            | %    | 10 – 200                               | 1    | 20      | Residual current setting   |
| BRF50SP<br>Retrip Time Delay | msec | 0 – 1000                               | 1    | 100     | Time delay for retrip command generation                                 |
| Backup Time Delay            | msec | 100 – 60000                            | 1    | 1000    | Time delay for trip command generation for the backup circuit breaker(s) |
| Pulse Duration               | msec | 0 – 60000                              | 1    | 100     | Trip command impulse duration  |

### 3.1.5.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.1.5.2.2.1. Analogue inputs

The function uses the sampled values of a current input. This is defined in the configuration.

#### 3.1.5.2.2.2. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the Logic editor.

Table 2-2 The binary input signals of the breaker failure protection functions


| BINARY STATUS SIGNAL               | TITLE               | EXPLANATION  |
|------------------------------------|---------------------|--|
| BRF50_ <b>Bik</b> _GrO_            | Block               | Blocking of the breaker failure protection function                          |
| BRF50_ <b>CBClosed</b> _GrO_       | CB closed           | Signal indicating the closed state of the circuit breaker                    |
| <i>BRF50SP_ <b>CBCIL1</b>_GrO_</i> | <i>CB closed L1</i> | <i>Signal indicating the closed state of the circuit breaker in phase L1</i> |
| <i>BRF50SP_ <b>CBCIL2</b>_GrO_</i> | <i>CB closed L2</i> | <i>Signal indicating the closed state of the circuit breaker in phase L2</i> |
| <i>BRF50SP_ <b>CBCIL3</b>_GrO_</i> | <i>CB closed L3</i> | <i>Signal indicating the closed state of the circuit breaker in phase L3</i> |
| BRF50_ <b>GenSt</b> _GrO_          | General Start       | General starting signal  |
| <i>BRF50SP_ <b>StL1</b>_GrO_</i>   | <i>Start L1</i>     | <i>Starting signal in phase L1</i>   |
| <i>BRF50SP_ <b>StL2</b>_GrO_</i>   | <i>Start L2</i>     | <i>Starting signal in phase L2</i>   |
| <i>BRF50SP_ <b>StL3</b>_GrO_</i>   | <i>Start L3</i>     | <i>Starting signal in phase L3</i>   |
| BRF50_ <b>IoSt</b> _GrO_           | Start Io            | Starting signal for the residual current                                     |

#### 3.1.5.2.2.3. Binary output signals (graphed input statuses)

These signals can be used in EuroCAP to assign to LED, user LCD object etc. Parts written in **bold** are seen on the right side of the function block in the *Logic Editor*.

Table 2-3 The binary output signals of the breaker failure protection function

| BINARY STATUS SIGNAL           | TITLE            | EXPLANATION  |
|--------------------------------|------------------|--|
| BRF50_ <b>BuTr</b> _GrI_       | Backup Trip      | Trip command generated for the backup circuit breakers |
| <i>BRF50_ <b>TrL1</b>_GrI_</i> | <i>Retrip L1</i> | <i>Repeated trip command in phase L1</i>               |
| <i>BRF50_ <b>TrL2</b>_GrI_</i> | <i>Retrip L2</i> | <i>Repeated trip command in phase L2</i>               |
| <i>BRF50_ <b>TrL3</b>_GrI_</i> | <i>Retrip L3</i> | <i>Repeated trip command in phase L3</i>               |




### 3.1.5.2.2.4. Online data

Visible values on the *online data* page.

*Table 2-4 Online displayed data of the breaker failure protection function*

|         | SIGNAL TITLE     | DIMENSION | EXPLANATION  |
|---------|------------------|-----------|--|
|         | Backup Trip      | -         | Trip command generated for the backup circuit breakers |
| BRF50SP | <i>Retrip L1</i> | -         | <i>Repeated trip command in phase L1</i>               |
|         | <i>Retrip L2</i> | -         | <i>Repeated trip command in phase L2</i>               |
|         | <i>Retrip L3</i> | -         | <i>Repeated trip command in phase L3</i>               |



### 3.1.5.2.2.5. Events

The following events are generated in the event list, as well as sent to the SCADA according to the configuration.

*Table 2-5 Generated events of the breaker failure protection function*

| EVENT            | VALUE   | EXPLANATION                              |
|------------------|---------|--|
| Backup Trip      | off, on | Backup trip command of the function      |
| <i>Retrip L1</i> | off, on | <i>Repeated trip command in phase L1</i> |
| <i>Retrip L2</i> | off, on | <i>Repeated trip command in phase L2</i> |
| <i>Retrip L3</i> | off, on | <i>Repeated trip command in phase L3</i> |

BRF50SP

### 3.1.5.2.3. Technical data

*Table 2-6 Technical data of the breaker failure protection function*

| FUNCTION                  | VALUE         | ACCURACY                            |
|---------------------------|---------------|-------------------------------------|
| Pick-up starting accuracy |               | < 2 %                               |
| Operate time accuracy     |               | ±5% or ±15 ms, whichever is greater |
| Retrip time               | approx. 15 ms |                                     |
| Reset ratio               | 0.9           |                                     |
| Current reset time        | 16 – 25 ms    |                                     |

### 3.1.5.2.4. Notes for testing

Note that the time delay parameter incorporates the algorithm time as well, so the time delay **does not mean the time difference between the appearance of the start and trip signals** of the function. In other words: it is not the delay between the detection of the fault and the trip that follows it. This should be taken into consideration when checking the disturbance records.

Instead the time delay parameter defines the elapsed time from the appearance of the faulty state to the trip. Because of this, while testing, the delay measurement should start *from the moment of the fault injection* until the trip signal.

### 3.1.6. Three-phase time overcurrent protection

#### 3.1.6.1. Operation principle

The overcurrent protection function realizes definite time or inverse time characteristics according to IEC or IEEE standards, based on three phase currents. The characteristics are harmonized with IEC 60255-151, Edition 1.0, 2009-08. This function can be applied as main protection for medium-voltage applications or backup or overload protection for high-voltage network elements.

##### 3.1.6.1.1. Operating characteristics

###### 3.1.6.1.1.1. Independent time characteristic

$$t(G) = t_{OP} \text{ when } G > G_S$$




Figure 1-1 Overcurrent independent time characteristic

where

- $t_{OP}$  (seconds)      theoretical operating time if  $G > G_S$ , fix, according to the preset parameter,
- $G$                       measured value of the characteristic quantity, Fourier base harmonic of the phase currents,
- $G_S$                     preset value of the characteristic quantity ("Start current" parameter).

### 3.1.6.1.1.2. Standard dependent time characteristics

Operating characteristics:

$$t(G) = TMS \left[ \frac{k}{\left(\frac{G}{G_s}\right)^\alpha - 1} + c \right] \text{ when } G > G_s$$

where

- t(G)(seconds)      theoretical operate time with constant value of G,
- k, c                      constants characterizing the selected curve (in seconds),
- α                         constants characterizing the selected curve (no dimension),
- G                         measured value of the characteristic quantity, Fourier base harmonic of the phase currents (IL1Four, IL2Four, IL3Four),
- G<sub>s</sub>                      preset value of the characteristic quantity (“Start current” parameter),
- TMS                     preset time multiplier (no dimension).

*Table 1-1 The constants of the standard dependent time characteristics*

|    | IEC REF | TITLE            | kr     | c      | α    |
|----|---------|------------------|--------|--------|------|
| 1  | A       | IEC Inv          | 0,14   | 0      | 0,02 |
| 2  | B       | IEC VeryInv      | 13,5   | 0      | 1    |
| 3  | C       | IEC ExtInv       | 80     | 0      | 2    |
| 4  |         | IEC LongInv      | 120    | 0      | 1    |
| 5  |         | ANSI Inv         | 0,0086 | 0,0185 | 0,02 |
| 6  | D       | ANSI ModInv      | 0,0515 | 0,1140 | 0,02 |
| 7  | E       | ANSI VeryInv     | 19,61  | 0,491  | 2    |
| 8  | F       | ANSI ExtInv      | 28,2   | 0,1217 | 2    |
| 9  |         | ANSI LongInv     | 0,086  | 0,185  | 0,02 |
| 10 |         | ANSI LongVeryInv | 28,55  | 0,712  | 2    |
| 11 |         | ANSI LongExtInv  | 64,07  | 0,250  | 2    |

The end of the effective range of the dependent time characteristics (G<sub>D</sub>) is:

$$G_D = 20 * G_s$$

Above this value the theoretical operating time is definite:

$$t(G) = TMS \left[ \frac{k}{\left(\frac{G_D}{G_s}\right)^\alpha - 1} + c \right] \text{ when } G > G_D = 20 * G_s$$



Additionally, a minimum time delay can be defined by parameter “Min Time Delay”. This delay is valid if it is longer than  $t(G)$ , defined by the formula above.

The inverse characteristic is valid above  $G_T = 1,1 * G_s$ . Above this value the function is guaranteed to operate.

**Resetting characteristics:**

- For IEC type characteristics the resetting is after a fix time delay defined by “Reset delay”,
- for ANSI types however according to the formula below:

$$t_r(G) = TMS \left[ \frac{k_r}{1 - \left(\frac{G}{G_s}\right)^\alpha} \right] \text{ when } G < G_s$$

where


- $t(G)$ (seconds)      theoretical reset time with constant value of  $G$ ,
- $k_r$                       constants characterizing the selected curve (in seconds),
- $\alpha$                       constants characterizing the selected curve (no dimension),
- $G$                         measured value of the characteristic quantity, Fourier base harmonic of the phase currents,
- $G_s$                       preset value of the characteristic quantity (“Start current” parameter),
- $TMS$                     preset time multiplier (no dimension).

*Table 1-2 The resetting constants of the standard dependent time characteristics*

|    | IEC REF | TITLE            | $k_r$   | $\alpha$ |
|----|---------|------------------|---|----------|
| 1  | A       | IEC Inv          | Resetting after fix time delay, according to preset parameter “Reset delay” |          |
| 2  | B       | IEC VeryInv      |   |          |
| 3  | C       | IEC ExtInv       |   |          |
| 4  |         | IEC LongInv      |   |          |
| 5  |         | ANSI Inv         | 0,46  | 2        |
| 6  | D       | ANSI ModInv      | 4,85  | 2        |
| 7  | E       | ANSI VeryInv     | 21,6  | 2        |
| 8  | F       | ANSI ExtInv      | 29,1  | 2        |
| 9  |         | ANSI LongInv     | 4,6   | 2        |
| 10 |         | ANSI LongVeryInv | 13,46   | 2        |
| 11 |         | ANSI LongExtInv  | 30  | 2        |

### 3.1.6.1.2. Structure of the overcurrent protection algorithm

Fig.1-2 shows the structure of the overcurrent protection (TOC51) algorithm.



*Figure 1-2 Structure of the overcurrent protection algorithm*

The **inputs** are

the RMS value of the fundamental Fourier component of three phase currents,  
parameters,  
status signals.

The **outputs** are

the binary output status signals.

The **software modules** of the overcurrent protection function:

#### **Characteristics**

This module calculates the required time delay based on the Fourier components of the phase currents.

#### **Decision logic**

The decision logic module combines the status signals to generate the trip command of the function.

The following description explains the details of the individual components.

### 3.1.6.1.3. The definite time and the inverse type characteristics (characteristics)

This module calculates the required time delay based on the Fourier components of the phase currents. The formulas applied are described in Chapter 1.1.

The **inputs** are the RMS value of the fundamental Fourier component of the phase currents (IL1Four, IL2Four, IL3Four) and parameters.

The **outputs** are the status signals of the three phases individually. These indicate the started state and the generated trip command if the time delay determined by the characteristics expired.






Figure 1-3 Schema of the characteristic calculation

The inverse type characteristics are also presented graphically on the following pages. These diagrams assume 100% setting value for the Start current parameter (GS), 1 for the Time multiplier (TMS) and 0 for the Min. time delay.



*Figure 1-4 Overcurrent characteristics according to IEC 60255-151*



*Figure 1-5 Overcurrent characteristics according to ANSI standard*




Figure 1-6 Overcurrent characteristics according to ANSI standard





Figure 1-7 Overcurrent resetting characteristics according to ANSI standard



*Figure 1-8 Overcurrent resetting characteristics according to ANSI standard*



### 3.1.6.1.4. The decision logic (Decision logic)

The decision logic module combines the status signals to generate the general start signal and general trip command of the function.





Figure 1-9 The logic scheme of the overcurrent protection function

Table 1-3 The binary input status signals of the overcurrent protection function

| BINARY INPUT SIGNALS | SIGNAL TITLE | EXPLANATION                              |
|----------------------|--------------|--|
| TOC51_StL1_Grl_      | Start L1     | Starting of the function in phase L1     |
| TOC51_TrL1_Grl_      | Trip L1      | Trip command of the function in phase L1 |
| TOC51_StL2_Grl_      | Start L2     | Starting of the function in phase L2     |
| TOC51_TrL2_Grl_      | Trip L2      | Trip command of the function in phase L2 |
| TOC51_StL3_Grl_      | Start L3     | Starting of the function in phase L3     |
| TOC51_TrL3_Grl_      | Trip L3      | Trip command of the function in phase L3 |



### Binary status signals

The overcurrent protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

*Table 1-4 The binary input signal of the overcurrent protection function*

| BINARY STATUS SIGNAL | EXPLANATION   |
|----------------------|---|
| TOC51_Blk_GrO_       | Output status of a graphic equation defined by the user to disable the overcurrent protection function. |

*Table 1-5 The binary output status signals of the overcurrent protection function*

| BINARY OUTPUT SIGNALS | SIGNAL TITLE | EXPLANATION                          |
|-----------------------|--------------|--------------------------------------|
| TOC51_StL1_Grl_       | Start L1     | Starting of the function in phase L1 |
| TOC51_StL2_Grl_       | Start L2     | Starting of the function in phase L2 |
| TOC51_StL3_Grl_       | Start L3     | Starting of the function in phase L3 |
| TOC51_GenSt_Grl_      | Gen. Start   | General starting of the function     |
| TOC51_GenTr_Grl_      | Gen. Trip    | General trip command of the function |

### 3.1.6.2. 3ph overcurrent protection function overview

The function block of the three-phase overcurrent protection function is shown in Figure 2-1. This block shows all binary input and output status signals that are applicable in the graphic equation editor.





Figure 2-1 The function block of the overcurrent protection function

#### 3.1.6.2.1. Settings

##### 3.1.6.2.1.1. Parameters

Table 2-1 Parameters of the 3ph overcurrent protection function

| TITLE               | DIM  | RANGE  | STEP | DEFAULT | EXPLANATION  |
|---------------------|------|--|------|---------|--|
| Operation           | -    | Off,<br>Definite Time,<br>IEC Inv,<br>IEC VeryInv,<br>IEC ExtInv,<br>IEC LongInv,<br>ANSI Inv,<br>ANSI ModInv,<br>ANSI VeryInv,<br>ANSI ExtInv,<br>ANSI LongInv,<br>ANSI LongVeryInv,<br>ANSI LongExtInv | -    | Off     | Enabling the function by choosing the characteristics.     |
| Start Current       | %    | 10 – 3000  | 1    | 200     | Starting current of the function.                          |
| Time Multiplier     | -    | 0.05 – 15.0  | 0.01 | 200     | Time multiplier of the inverse characteristics (OC module) |
| Min Time Delay      | msec | 40 – 60000   | 1    | 100     | Minimal time delay for the inverse characteristics         |
| Definite Time Delay | msec | 40 – 60000   | 1    | 100     | Time delay setting for the definite time characteristics   |
| Reset Time          | msec | 60 – 60000   | 1    | 100     | Reset time for the IEC inverse characteristics             |



### 3.1.6.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.1.6.2.2.1. Analogue inputs

The function uses the sampled values of the three phase currents.

#### 3.1.6.2.2.2. Binary output signals (graphed input statuses)

The **binary output status signals** of the three-phase overcurrent protection function are listed in Table 2-2. **Parts** written in **bold** are seen on the function block in the logic editor.

*Table 2-2 The binary output status signals of the 3ph overcurrent protection function*

| <b>BINARY OUTPUT SIGNALS</b> | <b>SIGNAL TITLE</b> | <b>EXPLANATION</b>                       |
|------------------------------|---------------------|--|
| TOC51_ <b>StL1</b> _Grl_     | Start L1            | Starting of the function in phase L1     |
| TOC51_TrL1_Grl_              | Trip L1             | Trip command of the function in phase L1 |
| TOC51_ <b>StL2</b> _Grl_     | Start L2            | Starting of the function in phase L2     |
| TOC51_TrL2_Grl_              | Trip L2             | Trip command of the function in phase L2 |
| TOC51_ <b>StL3</b> _Grl_     | Start L3            | Starting of the function in phase L3     |
| TOC51_TrL3_Grl_              | Trip L3             | Trip command of the function in phase L3 |
| TOC51_ <b>GenSt</b> _Grl_    | General Start       | General start of the function            |
| TOC51_ <b>GenTr</b> _Grl_    | General Trip        | General trip command of the function     |

#### 3.1.6.2.2.3. Binary input signals (graphed output statuses)

The overcurrent protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

*Table 2-3 The binary input status signals of the 3ph overcurrent protection function*


| <b>BINARY INPUT SIGNAL</b> | <b>EXPLANATION</b>  |
|----------------------------|---|
| TOC51_ <b>BIk</b> _GrO_    | Output status of a graphic equation defined by the user to disable the overcurrent protection function. |

#### 3.1.6.2.2.4. On-line data

Visible values on the on-line data page:

*Table 2-4 On-line data of the 3ph overcurrent protection function*

| <b>SIGNAL TITLE</b> | <b>DIMENSION</b> | <b>EXPLANATION</b>                       |
|---------------------|------------------|--|
| Start L1            | -                | Starting of the function in phase L1     |
| Trip L1             | -                | Trip command of the function in phase L1 |
| Start L2            | -                | Starting of the function in phase L2     |
| Trip L2             | -                | Trip command of the function in phase L2 |
| Start L3            | -                | Starting of the function in phase L3     |
| Trip L3             | -                | Trip command of the function in phase L3 |
| General Start       | -                | General start of the function            |
| General Trip        | -                | General trip command of the function     |




### 3.1.6.2.2.5. Events

The following events are generated in the event list, as well as sent to SCADA according to the configuration.

*Table 2-5 Events of the 3ph overcurrent protection function*

| EVENT         | VALUE   | EXPLANATION  |
|---------------|---------|--|
| Start L1      | off, on | Start of the three-phase overcurrent protection function in measuring element L1 |
| Start L2      | off, on | Start of the three-phase overcurrent protection function in measuring element L2 |
| Start L3      | off, on | Start of the three-phase overcurrent protection function in measuring element L3 |
| General Start | off, on | General start of the three-phase overcurrent protection function                 |
| General Trip  | off, on | General trip command of the three-phase overcurrent protection function          |



### 3.1.6.2.3. Technical data

Table 2-6 Technical data of the 3ph overcurrent protection function

| FUNCTION   | VALUE                  | ACCURACY                                       |
|--|------------------------|--|
| Operating accuracy   | $20 \leq GS \leq 1000$ | < 2 %  |
| Operate time accuracy  |                        | $\pm 5\%$ or $\pm 15$ ms, whichever is greater |
| Reset ratio  | 0,95                   |  |
| Reset time *<br>Dependent time char.<br>Definite time char.          | Approx. 60 ms          | < 5% or $\pm 35$ ms, whichever is greater      |
| Transient overreach  |                        | < 2 %  |
| Pickup time *  | < 40 ms                |  |
| Overshot time<br>Dependent time char.<br>Definite time char.         | 30 ms<br>50 ms         |  |
| Influence of time varying value of the input current (IEC 60255-151) |                        | < 4 %  |

\* Measured with signal relay contact

#### 3.1.6.2.3.1. Notes for testing

Normally in the EuroProt+ devices the trip contacts are assigned to the Trip Logic function block, and not to the protection function blocks. Because of this, the testing personnel must make sure that the Trip Logic is switched on ('Operation' parameter is set to other than 'Off') before starting the testing, otherwise there will be no physical trip on the relay.

The reset time of the IDMT characteristics can be tested only indirectly by injecting the same fault currents again after a successful trip: if the time elapsed between the two injections is less than the reset time, the second injection will result in a quicker operation than the first.

### 3.1.7. Residual overcurrent protection function

The residual overcurrent protection function can realize definite time or inverse time characteristics according to IEC or IEEE standards, based on the RMS value of the fundamental Fourier component of a single measured current, which can be the measured residual current at the neutral point ( $3I_0$ ) or the calculated zero sequence current component. The characteristics are harmonized with IEC 60255-151, Edition 1.0, 2009-08.

#### 3.1.7.1. Operating characteristics

##### 3.1.7.1.1. Independent time characteristic




Figure 1-1 Overcurrent independent time characteristic

|                           |   |
|---------------------------|---|
| where                     |   |
| t <sub>OP</sub> (seconds) | theoretical operating time if $G > G_s$ , fix, according to the preset parameter,             |
| G                         | measured value of the characteristic quantity, Fourier base harmonic of the residual current, |
| G <sub>s</sub>            | preset value of the characteristic quantity (TOC51N_StCurr_IPar_, Start current).             |

### 3.1.7.1.2. Standard dependent time characteristics

Operating characteristics:

$$t(G) = TMS \left[ \frac{k_r}{\left(\frac{G}{G_s}\right)^\alpha - 1} + c \right] \text{ when } G > G_s$$

where  
 t(G)(seconds) theoretical operate time with constant value of G,  
 k<sub>r</sub>, c constants characterizing the selected curve (in seconds),  
 α constant characterizing the selected curve (no dimension),  
 G measured value of the characteristic quantity, Fourier base harmonic of the residual current (INFour),  
 G<sub>s</sub> preset value of the characteristic quantity (TOC51N\_StCurr\_IPar\_, Start current),  
 TMS preset time multiplier (no dimension).

|    | IEC ref |                  | k <sub>r</sub> | c      | α    |
|----|---------|------------------|----------------|--------|------|
| 1  | A       | IEC Inv          | 0,14           | 0      | 0,02 |
| 2  | B       | IEC VeryInv      | 13,5           | 0      | 1    |
| 3  | C       | IEC ExtInv       | 80             | 0      | 2    |
| 4  |         | IEC LongInv      | 120            | 0      | 1    |
| 5  |         | ANSI Inv         | 0,0086         | 0,0185 | 0,02 |
| 6  | D       | ANSI ModInv      | 0,0515         | 0,1140 | 0,02 |
| 7  | E       | ANSI VeryInv     | 19,61          | 0,491  | 2    |
| 8  | F       | ANSI ExtInv      | 28,2           | 0,1217 | 2    |
| 9  |         | ANSI LongInv     | 0,086          | 0,185  | 0,02 |
| 10 |         | ANSI LongVeryInv | 28,55          | 0,712  | 2    |
| 11 |         | ANSI LongExtInv  | 64,07          | 0,250  | 2    |


Table 1-1 The constants of the standard dependent time characteristics





### 3.1.7.2. Structure of the residual overcurrent protection algorithm

Fig.1-2 shows the structure of the residual overcurrent protection (TOC51N) algorithm.



*Figure 1-2 Structure of the residual overcurrent protection algorithm*

The **inputs** are

- the RMS value of the fundamental Fourier component of the residual current ( $I_N=3I_0$ ),
- parameters,
- status signals.

The **outputs** are

- the binary output status signals.

The **software modules** of the residual overcurrent protection function:

#### **Characteristics**

This module calculates the required time delay based on the RMS value of the fundamental Fourier component of the residual current.

#### **Decision logic**

The decision logic module combines the status signals to generate the trip command of the function.

The following description explains the details of the individual components.

### 3.1.7.3. The definite time and the inverse type characteristics

This module calculates the required time delay based on the Fourier components of the residual current. The formulas applied are described in Chapter 1.1.

The **inputs** are the basic Fourier components of the residual current (INFour) and parameters.

The **outputs** are the internal status signals of the function. These indicate the started state and the generated trip command if the time delay determined by the characteristics expired.




Figure 1-3 Schema of the characteristic calculation

#### Enumerated parameter

| Parameter name               | Title     | Selection range  | Default |
|------------------------------|-----------|--|---------|
| Parameter for type selection |           |  |         |
| TOC51N_Oper_EPar_            | Operation | Off, DefinitTime, IEC Inv, IEC VeryInv, IEC ExtInv, IEC LongInv, ANSI Inv, ANSI ModInv, ANSI VeryInv, ANSI ExtInv, ANSI LongInv, ANSI LongVeryInv, ANSI LongExtInv | Off     |

Table 1-3 The enumerated parameters of the residual overcurrent protection function


#### Integer parameters

| Parameter name              | Title            | Unit | Min | Max  | Step | Default |
|-----------------------------|------------------|------|-----|------|------|---------|
| Starting current parameter: |                  |      |     |      |      |         |
| TOC51N_StCurr_IPar_         | Start Current *  | %    | 10  | 1000 | 1    | 50      |
| TOC51N_StCurr_IPar_         | Start Current ** | %    | 5   | 1000 | 1    | 50      |

\* In = 1 A or 5 A

\*\* In = 200 mA or 1 A

Table 1-4 The integer parameters of the residual overcurrent protection function



**Float parameter**

| Parameter name   | Title           | Unit | Min  | Max | Step | Default |
|--|-----------------|------|------|-----|------|---------|
| Time multiplier of the inverse characteristics (OC module) |                 |      |      |     |      |         |
| TOC51N_Multip_FPar_  | Time Multiplier |      | 0.05 | 15  | 0.01 | 1.0     |

*Table 1-5 Float parameter of the OC function block*

**Timer parameters**

| Parameter name                                      | Title                  | Unit | Min | Max   | Step | Default |
|---|------------------------|------|-----|-------|------|---------|
| Minimal time delay for the inverse characteristics: |                        |      |     |       |      |         |
| TOC51N_MinDel_TPar_                                 | Min Time Delay *       | msec | 40  | 60000 | 1    | 100     |
| Definite time delay:                                |                        |      |     |       |      |         |
| TOC51N_DefDel_TPar_                                 | Definite Time Delay ** | msec | 40  | 60000 | 1    | 100     |
| Reset time delay for the inverse characteristics:   |                        |      |     |       |      |         |
| TOC51N_Reset_TPar_                                  | Reset Time*            | msec | 60  | 60000 | 1    | 100     |

\*Valid for inverse type characteristics only

\*\*Valid for definite type characteristics only

*Table 1-6 Timer parameters of the residual overcurrent protection function*

The **binary output status signals** of the residual overcurrent protection function are listed in [Table 1-7](#).

| Binary output signals | Signal title | Explanation                  |
|-----------------------|--------------|------------------------------|
| TOC51N_St_Grl_        | Start L1     | Starting of the function     |
| TOC51N_Tr_Grl_        | Trip L1      | Trip command of the function |

*Table 1-7 The binary output status signals of the residual overcurrent protection function*

### 3.1.7.4. The decision logic (Decision logic)

The decision logic module combines the status signals to generate the trip command of the function.




Figure 1-4 The (simplified) logic scheme of the residual overcurrent protection function

| Binary input signals | Signal title | Explanation                  |
|----------------------|--------------|------------------------------|
| TOC51N_St_Grl_       | Start        | Starting of the function     |
| TOC51N_Tr_Grl_       | Trip         | Trip command of the function |

Table 1-8 The binary input status signals of the residual overcurrent protection function

#### Binary status signals

The residual overcurrent protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Explanation  |
|----------------------|--|
| TOC51N_BlK_GrO_      | Output status of a graphic equation defined by the user to disable the residual overcurrent protection function. |

Table 1-9 The binary input signal of the residual overcurrent protection function

| Binary output signals | Signal title  | Explanation                          |
|-----------------------|---------------|--------------------------------------|
| TOC51N_GenSt_Grl_     | General Start | General starting of the function     |
| TOC51N_GenTr_Grl_     | General Trip  | General trip command of the function |

Table 1-10 The binary output status signals of the residual overcurrent protection function

### 3.1.7.5. Technical summary

#### 3.1.7.5.1. Technical data

| Function   | Value                   | Accuracy                                       |
|--|-------------------------|--|
| Operating accuracy *   | $20 \leq G_s \leq 1000$ | < 3 %  |
| Operate time accuracy  |                         | $\pm 5\%$ or $\pm 15$ ms, whichever is greater |
| Reset ratio  | 0,95                    |  |
| Reset time *<br>Dependent time char.<br>Definite time char.          | Approx 60 ms            | < 5% or $\pm 35$ ms, whichever is greater      |
| Transient overreach  |                         | 2 %  |
| Pickup time  | $\leq 40$ ms            |  |
| Overshot time<br>Dependent time char.<br>Definite time char.         | 30 ms<br>50 ms          |  |
| Influence of time varying value of the input current (IEC 60255-151) |                         | < 4 %  |

\* Measured in version  $I_n = 200$  mA

Table 1-11 Technical data of the residual overcurrent protection function

#### 3.1.7.5.2. The parameters

The parameters are summarized in Chapter [1.3](#).

#### 3.1.7.5.3. The binary input status signals

##### Binary input signal

The residual overcurrent protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary input signal | Explanation  |
|---------------------|--|
| TOC51N_Blk_GrO_     | Output status of a graphic equation defined by the user to disable the residual overcurrent protection function. |


Table 1-12 The binary input signal of the residual overcurrent protection function

#### 3.1.7.5.4. The binary output status signals

The **binary output status signals** of the residual overcurrent protection function are listed in Table 1-13.


| Binary output signals | Signal title  | Explanation                          |
|-----------------------|---------------|--------------------------------------|
| TOC51N_GenSt_Grl_     | General Start | General starting of the function     |
| TOC51N_GenTr_Grl_     | General Trip  | General trip command of the function |

Table 1-13 The binary output status signals of the residual overcurrent protection function



### 3.1.7.5.5. The function block

The function block of the residual overcurrent protection function is shown in [Figure 1-5](#). This block shows all binary input and output status signals that are applicable in the graphic equation editor.



*Figure 1-5 The function block of the residual overcurrent protection function*





### 3.1.8.4. Structure of the definite time overvoltage protection algorithm

Fig.1-2 shows the structure of the definite time overvoltage protection (TOV59) algorithm.




Figure 1-2 Structure of the definite time overvoltage protection algorithm

The **inputs** are

- the RMS values of the fundamental Fourier component of three phase voltages,
- parameters,
- status signals.

The **outputs** are

- the binary output status signals.

The **software modules** of the definite time overvoltage protection function:

#### **Fourier calculations**

These modules calculate the basic Fourier components of the phase voltages individually (not part of the TOV59 function). In medium voltage applications these are changed to phase-to-phase voltages.

#### **Characteristics**

This module calculates the required time delay based on the Fourier components of the phase (or phase-to-phase) voltages.

#### **Decision logic**


The decision logic module combines the status signals to generate the trip command of the function.

The following description explains the details of the individual components.

C

### 3.1.8.5. The Fourier calculation (Fourier)

These modules calculate the basic Fourier components of the phase voltages individually. They are not part of the TOV59 function; they belong to the preparatory phase.



*Figure 1-3 Schema of the Fourier calculation*

The **inputs** are the sampled values of the three phase voltages (UL1, UL2, UL3)

The **outputs** are the RMS values of the basic Fourier components of the analyzed voltages (UL1Four, UL2Four, UL3Four).

The phase-to-phase voltages (if used) are also calculated here.

C

### 3.1.8.6. The definite time characteristics (Characteristics)

This module decides the stating of the function based on the Fourier components of the phase voltages and it counts the time delay. The time delay is defined by the parameter setting, if the voltages are above the setting value.

The **inputs** are the RMS values of the basic Fourier components of the phase (or the calculated phase-to-phase) voltages (UL1Four, UL2Four, UL3Four) and parameters.

The **outputs** are the status signals of the three phases individually. These indicate the started state and the generated trip command if the time delay determined by the setting is expired.




Figure 1-4 Schema of the definite time characteristic calculation

#### Enumerated parameter

| Parameter name  | Title     | Selection range | Default |
|---|-----------|-----------------|---------|
| Enabling or disabling the overvoltage protection function |           |                 |         |
| TOV59_Oper_EPar_  | Operation | Off, On         | Off     |

Table 1-1 The enumerated parameter of the overvoltage protection function

#### Integer parameter

| Parameter name  | Title         | Unit | Min | Max | Step | Default |
|---|---------------|------|-----|-----|------|---------|
| Voltage level setting. If the measured voltage is above the setting value, the function generates a start signal. |               |      |     |     |      |         |
| TOV59_StVol_IPar_   | Start Voltage | %    | 30  | 130 | 1    | 110     |

Table 1-2 Integer parameter of the overvoltage protection function

#### Floating point parameter

| Parameter name  | Title       | Unit | Min | Max | Step | Default |
|---|-------------|------|-----|-----|------|---------|
| After starting the function drops off if the measured voltage is below the start voltage with at least this percentage. |             |      |     |     |      |         |
| TOV59_ResetRatio_FPar_  | Reset Ratio | %    | 1   | 10  | 1    | 5       |

Table 1-3 Floating point parameter of the overvoltage protection function

C

**Boolean parameter**

| Parameter name     | Title             | Default | Explanation  |
|--------------------|-------------------|---------|--|
| TOV59_StOnly_BPar_ | Start Signal Only | 0       | Selection if starting and trip signal or starting signal only is to be generated. Set 0 for trip command generation. |

*Table 1-4 The Boolean parameters of the overvoltage protection function*

**Timer parameter**

| Parameter name                                     | Title      | Unit | Min | Max   | Step | Default |
|--|------------|------|-----|-------|------|---------|
| Time delay of the overvoltage protection function. |            |      |     |       |      |         |
| TOV59_Delay_TPar_                                  | Time Delay | ms   | 0   | 60000 | 1    | 100     |

*Table 1-5 The timer parameter of the overvoltage protection function*

The **binary output status signals** of the three-phase definite time overvoltage protection function are listed in \*In case of phase-to-phase voltages, these are changed to L12, L23, L31 respectively.

\*\*The trip signals are not published for the phases individually

Table 1-6 below.

| Binary output status signal | Signal title | Explanation                               |
|-----------------------------|--------------|---|
| TOV59_StL1_Grl_             | StL1         | Starting of the function in phase L1*     |
| TOV59_TrL1_Grl_             | TrL1**       | Trip command of the function in phase L1* |
| TOV59_StL2_Grl_             | StL2         | Starting of the function in phase L2*     |
| TOV59_TrL2_Grl_             | TrL2**       | Trip command of the function in phase L2* |
| TOV59_StL3_Grl_             | StL3         | Starting of the function in phase L3*     |
| TOV59_TrL3_Grl_             | TrL3**       | Trip command of the function in phase L3* |

\*In case of phase-to-phase voltages, these are changed to L12, L23, L31 respectively.

\*\*The trip signals are not published for the phases individually

*Table 1-6 The binary output status signals of the definite time overvoltage protection function*

C

### 3.1.8.7. The decision logic (Decision logic)

The decision logic module combines binary signals and Boolean parameters to generate the trip command of the function.




Figure 1-5 The decision logic scheme of the definite time overvoltage protection function

| Binary input signal | Signal title | Explanation                               |
|---------------------|--------------|---|
| TOV59_StL1_Grl_     | StL1         | Starting of the function in phase L1*     |
| TOV59_TrL1_Grl_     | TrL1**       | Trip command of the function in phase L1* |
| TOV59_StL2_Grl_     | StL2         | Starting of the function in phase L2*     |
| TOV59_TrL2_Grl_     | TrL2**       | Trip command of the function in phase L2* |
| TOV59_StL3_Grl_     | StL3         | Starting of the function in phase L3*     |
| TOV59_TrL3_Grl_     | TrL3**       | Trip command of the function in phase L3* |

\*In case of phase-to-phase voltages, these are changed to L12, L23, L31 respectively.


\*\*The trip signals are not published for the phases individually

Table 1-7 The binary input signals of the definite time overvoltage protection function

#### Boolean parameter

| Parameter name              | Title             | Default |
|-----------------------------|-------------------|---------|
| Enabling start signal only: |                   |         |
| TOV59_StOnly_BPar_          | Start Signal Only | FALSE   |

Table 1-8 The Boolean parameter of the definite time overvoltage protection function



C

### Binary status signals

The overvoltage protection function has a binary input signal, which serves the purpose of disabling the function. The conditions of disabling are defined by the user, applying the graphic equation editor.


| Binary input status signal | Explanation   |
|----------------------------|---|
| TOV59_BlK_GrO_             | Output status of a graphic equation defined by the user to disable the definite time overvoltage protection function. |

*Table 1-9 The binary input signal of the definite time overvoltage protection function*

| Binary output status signal | Title | Explanation          |
|-----------------------------|-------|----------------------|
| TOV59_StL1_Grl_             | StL1  | Start in phase L1*   |
| TOV59_StL2_Grl_             | StL2  | Start in phase L2*   |
| TOV59_StL3_Grl_             | StL3  | Start in phase L3*   |
| TOV59_GenSt_Grl_            | GenSt | General start signal |
| TOV59_GenTr_Grl_            | GenTr | General trip command |

\*In case of phase-to-phase voltages, these are changed to L12, L23, L31 respectively.

*Table 1-10 The binary output status signals of the definite time overvoltage protection function*



C

### 3.1.8.8. Technical summary

#### 3.1.8.8.1. Technical data

| Function                        | Value          | Accuracy  |
|---------------------------------|----------------|-----------|
| Pick-up starting accuracy       |                | < ± 0,5 % |
| Reset time<br>U> → Un<br>U> → 0 | 60 ms<br>50 ms |           |
| Operate time accuracy           |                | < ± 20 ms |
| Minimum operate time            | 50 ms          |           |

*Table 1-11 Technical data of the overvoltage protection function*

#### 3.1.8.8.2. Parameters

The parameters are summarized in Chapter 1.6 Table 1-1, Table 1-2, Table 1-3, Table 1-4, Table 1-5.

### 3.1.8.8.3. Binary output status signals

The **binary output status signals** of overvoltage protection function are listed in [Table 1-12](#)  
 The binary output status signals of the overvoltage protection function

| Binary status signal | Title | Explanation          |
|----------------------|-------|----------------------|
| TOV59_StL1_Grl_      | StL1  | Start in phase L1    |
| TOV59_StL2_Grl_      | StL2  | Start in phase L2    |
| TOV59_StL3_Grl_      | StL3  | Start in phase L3    |
| TOV59_GenSt_Grl_     | GenSt | General start signal |
| TOV59_GenTr_Grl_     | GenTr | General trip command |

*Table 1-12 The binary output status signals of the overvoltage protection function*

### 3.1.8.8.4. Binary input status signals

#### Binary input signals


The overvoltage protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Title | Explanation                                     |
|----------------------|-------|---|
| TOV59_BlK_GrO_       | Blk   | Blocking of the overvoltage protection function |

*Table 1-13 The binary input signal of the overvoltage protection function*


### 3.1.8.8.5. The function block

The function block of the overvoltage protection function is shown in [Figure 1-6](#). This block shows all binary input and output status signals that are applicable in the graphic equation editor.



*Figure 1-6 The function block of the overvoltage protection function*





c

### 3.1.9. Residual definite time overvoltage protection function

The residual definite time overvoltage protection function operates according to definite time characteristics, using the RMS values of the fundamental Fourier component of the zero sequence voltage ( $U_N=3U_0$ ).

#### 3.1.9.1. Operating characteristics




Figure 1-1 Overvoltage independent time characteristic

Where

- |                    |   |
|--------------------|---|
| $t_{OP}$ (seconds) | theoretical operating time if $G > G_S$ , fix, according to the parameter setting value,    |
| $G$                | measured value of the characteristic quantity, Fourier base harmonic of the phase voltages, |
| $G_S$              | setting value of the characteristic quantity (TOV59N_StCurr_IPar_, Start voltage).          |

### 3.1.9.2. Structure of the residual definite time overvoltage protection algorithm

Fig.1-2 shows the structure of the residual definite time overvoltage protection (TOV59N) algorithm.




Figure 1-2 Structure of the definite time residual overvoltage protection algorithm

The **inputs** are

- the RMS values of the fundamental Fourier component of the residual or neutral voltage ( $U_N=3U_0$ ),
- parameters,
- status signals.

The **outputs** are

- the binary output status signals.

The **software modules** of the differential protection function:

#### **Fourier calculations**

These modules calculate the basic Fourier components of the residual voltage (not part of the TOV59 function).

#### **Characteristics**

This module calculates the required time delay based on the Fourier components of the residual voltage.

#### **Decision logic**

The decision logic module combines the status signals to generate the trip command of the function.

The following description explains the details of the individual components.

C

### 3.1.9.3. The Fourier calculation (Fourier)

This module calculates the RMS value of the fundamental Fourier component of the residual or neutral voltage ( $UN=3U_0$ ). This module is not part of the TOV59N function; it belongs to the preparatory phase.




Figure 1-3 Schema of the Fourier calculation

The **input** is the sampled value of the residual voltage ( $UN=3U_0$ ).

The **output** is the RMS value of the fundamental Fourier component of the residual or neutral voltage ( $UNFour$ ).

### 3.1.9.4. The definite time characteristics (Characteristics)

This module decides the starting of the function and counts the required time delay based on the Fourier components of the residual voltage. The time delay is defined by the parameter setting value, if the voltage is above the voltage setting value.

The **inputs** are:

- the RMS value of the fundamental Fourier component of the residual or neutral voltage ( $UNFour$ ),
- parameters.

The **outputs** are the status signals of the function. These indicate the started state of the function.

C




Figure 1-4 Schema of the residual definite time characteristic calculation

**Enumerated parameter**

| Parameter name                                | Title     | Selection range | Default |
|---|-----------|-----------------|---------|
| Parameter for enabling/disabling the function |           |                 |         |
| TOV59N_Oper_EPar_                             | Operation | Off, On         | On      |

Table 1-1 The enumerated parameters of the residual definite time overvoltage protection function

**Integer parameter**

| Parameter name              | Title         | Unit | Min | Max | Step | Default |
|-----------------------------|---------------|------|-----|-----|------|---------|
| Starting voltage parameter: |               |      |     |     |      |         |
| TOV59N_StVol_IPar_          | Start Voltage | %    | 2   | 60  | 1    | 30      |

Table 1-2 The integer parameters of the residual definite time overvoltage protection function

**Timer parameter**

| Parameter name       | Title      | Unit | Min | Max   | Step | Default |
|----------------------|------------|------|-----|-------|------|---------|
| Definite time delay: |            |      |     |       |      |         |
| TOV59N_Delay_TPar_   | Time Delay | msec | 0   | 60000 | 1    | 100     |

Table 1-3 Timer parameter of the residual definite time overvoltage protection function

The **binary output status signals** of the residual definite time overvoltage protection function are listed in Table 1-4.

| Binary output signals | Signal title | Explanation                  |
|-----------------------|--------------|------------------------------|
| TOV59N_St_GrI_        | Start L1     | Starting of the function     |
| TOV59N_Tr_GrI_        | Trip L1      | Trip command of the function |

Table 1-4 The binary output status signals of the residual definite time overvoltage protection function

C

### 3.1.9.5. The decision logic (Decision logic)

The decision logic module combines the status signals, binary and enumerated parameters to generate the trip command of the function.




Figure 1-5 The logic scheme of the residual definite time overvoltage protection function


| Binary input signals | Signal title | Explanation                  |
|----------------------|--------------|------------------------------|
| TOV59N_St_Grl_       | Start L1     | Starting of the function     |
| TOV59N_Tr_Grl_       | Trip L1      | Trip command of the function |

Table 1-5 The binary input status signals of the decision logic scheme for the residual definite time overvoltage protection function

#### Boolean parameter

| Parameter name              | Title             | Default |
|-----------------------------|-------------------|---------|
| Enabling start signal only: |                   |         |
| TOV59N_StOnly_BPar_         | Start Signal Only | FALSE   |

Table 1-6 The Boolean parameter of the residual definite time overvoltage protection function



C

### Binary status signals

The overvoltage protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Explanation  |
|----------------------|--|
| TOV59N_Blk_GrO_      | Output status of a graphic equation defined by the user to disable the residual definite time overvoltage protection function. |

*Table 1-7 The binary input signal of the residual definite time overvoltage protection function*

| Binary output signals | Signal title  | Explanation                          |
|-----------------------|---------------|--------------------------------------|
| TOV59N_GenSt_Grl_     | General Start | General starting of the function     |
| TOV59N_GenTr_Grl_     | General Trip  | General trip command of the function |

*Table 1-8 The binary output status signals of the residual definite time overvoltage protection function*

### 3.1.9.6. Technical summary

#### 3.1.9.6.1. Technical data

| Function                  | Value               | Accuracy             |
|---------------------------|---------------------|----------------------|
| Pick-up starting accuracy | 2 – 8 %<br>8 – 60 % | < ± 2 %<br>< ± 1.5 % |
| Reset time                |                     |                      |
| U> → Un                   | 60 ms               |                      |
| U> → 0                    | 50 ms               |                      |
| Operate time              | 50 ms               | < ± 20 ms            |

Table 1-9 Technical data of the residual definite time overvoltage protection function

#### 3.1.9.6.2. The parameters

The parameters are summarized in Chapters 1.4 and 1.5.

#### 3.1.9.6.3. The binary output status signals

The **binary output status signals** of the residual definite time overvoltage protection function are listed in Table 1-10.

| Binary output signals | Signal title  | Explanation                          |
|-----------------------|---------------|--------------------------------------|
| TOV59N_GenSt_Grl_     | General Start | General starting of the function     |
| TOV59_N_GenTr_Grl_    | General Trip  | General trip command of the function |

Table 1-10 The binary output status signals of the residual definite time overvoltage protection function

#### 3.1.9.6.4. The binary input status signals

The residual definite time overvoltage protection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary input signal | Explanation  |
|---------------------|--|
| TOV59N_BlK_GrO_     | Output status of a graphic equation defined by the user to disable the residual definite time overvoltage protection function. |

Table 1-11 The binary input signal of the residual definite time overvoltage protection function

#### 3.1.9.6.5. The function block

The function block of the residual overvoltage protection function is shown in Figure 1-6. This block shows all binary input and output status signals that are applicable in the graphic equation editor.





Figure 1-6 The function block of the residual overvoltage protection function



## 3.1.10. Over-frequency protection function

### 3.1.10.1. Application

The deviation of the frequency from the rated system frequency indicates unbalance between the generated power and the load demand. If the available generation is large compared to the consumption by the load connected to the power system, then the system frequency is above the rated value. The overfrequency protection function is usually applied to decrease generation to control the system frequency.

Another possible application is the detection of unintended island operation of distributed generation and some consumers. In the island, there is low probability that the power generated is the same as the consumption; accordingly, the detection of high frequency can be one of the indications of island operation.

#### 3.1.10.1.1. Mode of operation

Depending on the hardware-software configuration, the frequency measurement is usually based on channel No. 1 (line voltage) and channel No. 4 (busbar voltage) of any voltage input module.

The accurate frequency measurement is performed by measuring the time period between two rising edges and also between two falling edges at zero crossing of a voltage signal. The frequency value is calculated by the average of these two values. At each zero crossing the average value (and the frequency) is recalculated.

For the acceptance of the measured frequency, at least four subsequent valid measurements are needed. Similarly, four invalid measurements are needed to reset the measured frequency from the last valid value to zero.

The minimum voltage condition can be set as a parameter for enabling the evaluation of the frequency. This parameter is called U limit.

The overfrequency protection function generates a start signal if at least five measured frequency values are above the preset level.



### 3.1.10.2. Overfrequency protection function overview

The graphic appearance of the function block of the overfrequency protection function is shown below. The block shows all binary input and output status signals which are applicable in the graphic equation editor.




Figure 2-1 Graphic appearance of the function block of the overfrequency protection function

#### 3.1.10.2.1. Settings


##### 3.1.10.2.1.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

Table 2-1 Parameters of the overfrequency protection function

| TITLE             | DIM  | RANGE         | STEP | DEFAULT | EXPLANATION   |
|-------------------|------|---------------|------|---------|---|
| Operation         | -    | Off, On       | -    | Off     | Enabling the function   |
| Start Signal Only | -    | FALSE, TRUE   | -    | FALSE   | Enabling start signal only  |
| Start Frequency   | Hz   | 40.00 – 70.00 | 0.01 | 51.00   | Setting value of the comparison   |
| U limit           | -    | 0.1Un – 1Un   | 0.01 | 0.45    | Minimum voltage condition for enabling the operation of the function            |
| Time Delay        | msec | 140* – 10000  | 1    | 200     | Time delay (including the algorithm time, see Chapter 2.4 for more explanation) |

\*The minimum operate time is lower than the settable minimum delay, however below this value the timing is less accurate, see Chapter 2.3 for details



### 3.1.10.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.1.10.2.2.1. Analogue inputs

The function uses the sampled values of a voltage input or a calculated line-to-line voltage. This is defined in the configuration.

#### 3.1.10.2.2.2. Analogue outputs (measurements)

The frequency measurement is displayed *MXU\_F* – frequency measurement function which is an independent function.

#### 3.1.10.2.2.3. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the *Logic editor*.

*Table 2-2 The binary input signal of the overfrequency protection function*

| BINARY OUTPUT SIGNAL    | EXPLANATION                    |
|-------------------------|--------------------------------|
| TOF81_ <b>Blk</b> _GrO_ | Blocking input of the function |

#### 3.1.10.2.2.4. Binary output signals (graphed input statuses)

These signals can be used in EuroCAP to assign to LED, user LCD object etc. Parts written in **bold** are seen on the right side of the function block in the *Logic Editor*.

*Table 2-3 The binary output signals of the overfrequency protection function*

| BINARY OUTPUT SIGNAL      | SIGNAL TITLE  | EXPLANATION                          |
|---------------------------|---------------|--------------------------------------|
| TOF81_ <b>GenSt</b> _Grl_ | General Start | General start signal of the function |
| TOF81_ <b>GenTr</b> _Grl_ | General Trip  | General trip command of the function |

#### 3.1.10.2.2.5. Online data

Visible values on the *online data* page.

*Table 2-4 Online displayed data of the overfrequency protection function*

| SIGNAL TITLE  | DIMENSION | EXPLANATION                          |
|---------------|-----------|--------------------------------------|
| General Start | -         | General start signal of the function |
| General Trip  | -         | General trip command of the function |

#### 3.1.10.2.2.6. Events

The following events are generated in the event list, as well as sent to the SCADA according to the configuration.

*Table 2-5 Generated events of the overfrequency protection function*

| EVENT         | VALUE   | EXPLANATION                          |
|---------------|---------|--------------------------------------|
| General Start | off, on | General start of the function        |
| General Trip  | off, on | General trip command of the function |

### 3.1.10.2.3. Technical data

The technical data, except for the min. operate voltage, are based on the function block testing according to the directives of the **IEC 60255-181:2019** standard.

*Table 2-6 Technical data of the overfrequency protection function*

| FUNCTION                | VALUE  | ACCURACY                     |
|-------------------------|--|------------------------------|
| Operate range           | 40 - 60 Hz (50 Hz system)<br>50 - 70 Hz (60 Hz system) | ± 3 mHz (20 mHz*)            |
| Effective range         | 45 - 55 Hz (50 Hz)<br>55 - 65 Hz (60 Hz)               | ± 3 mHz (10 mHz*)            |
| Min. operate time       | 93 ms (50 Hz)<br>73 ms (60 Hz)                         | ± 32 ms<br>± 27 ms           |
| Time delay              | 140 – 60000 ms<br><140 ms (50 Hz)<br><140 ms (60 Hz)   | ± 4 ms<br>± 32 ms<br>± 27 ms |
| Reset frequency         | [Start freq.] – 101 mHz                                | ± 1 mHz                      |
| Reset time              | 98 ms (50 Hz)<br>85 ms (60 Hz)                         | ± 6 ms                       |
| Reset ratio for U limit | 0.8  |                              |

*\*with the harmonic content according to the standard*

### 3.1.10.2.4. Notes for testing

Normally in the EuroProt+ devices the trip contacts are assigned to the Trip Logic function block, and not to the protection function blocks. Because of this, the testing personnel must make sure that the Trip Logic is switched on ('Operation' parameter is set to other than 'Off') before starting the tests, otherwise there will be no physical trip on the relay.

Note that the time delay parameter incorporates the algorithm time as well, so the time delay *does not mean the time difference between the appearance of the start and trip signals* of the function. In other words: it is not the delay between the detection of the fault and the trip that follows it. This should be taken into consideration when checking the disturbance records.

Instead the time delay parameter defines the elapsed time from the appearance of the faulty state to the trip. Because of this, while testing, the delay measurement should start *from the moment of the fault injection* until the trip signal.

The source voltage for frequency measurement is defined by the voltage input of the functionblock. This can be checked in the functionblock properties in EuroCAP

Before the fault injection at least 1 second pre-fault should be simulated with nominal frequency and voltage.

Based on IEC 60255-181 standard recommendations, the operation time shall be measured with a frequency of 0.5Hz higher than the setting value for Start frequency.



## 3.1.11. Underfrequency protection function

### 3.1.11.1. Application

The deviation of the frequency from the rated system frequency indicates unbalance between the generated power and the load demand. If the available generation is small compared to the consumption by the load connected to the power system, then the system frequency is below the rated value. The underfrequency protection function is usually applied to increase generation or for load shedding to control the system frequency.

Another possible application is the detection of unintended island operation of distributed generation and some consumers. In the island, there is low probability that the power generated is the same as the consumption; accordingly, the detection of low frequency can be one of the indications of island operation.

#### 3.1.11.1.1. Mode of operation

Depending on the hardware-software configuration, the frequency measurement is usually based on channel No. 1 (line voltage) and channel No. 4 (busbar voltage) of any voltage input module.

The accurate frequency measurement is performed by measuring the time period between two rising edges and also between two falling edges at zero crossing of a voltage signal. The frequency value is calculated by the average of these two values. At each zero crossing the average value (and the frequency) is recalculated.

For the acceptance of the measured frequency, at least four subsequent valid measurements are needed. Similarly, four invalid measurements are needed to reset the measured frequency from the last valid value to zero.

The minimum voltage condition can be set as a parameter for enabling the evaluation of the frequency. This parameter is called U limit.

The underfrequency protection function generates a start signal if at least five measured frequency values are below the preset level.

### 3.1.11.2. Underfrequency protection function overview

The graphic appearance of the function block of the underfrequency protection function is shown below. The block shows all binary input and output status signals which are applicable in the graphic equation editor.




Figure 2-1 Graphic appearance of the function block of the underfrequency protection function

### 3.1.11.2.1. Settings

#### 3.1.11.2.1.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

Table 2-1 Parameters of the underfrequency protection function

| TITLE             | DIM  | RANGE         | STEP | DEFAULT | EXPLANATION   |
|-------------------|------|---------------|------|---------|---|
| Operation         | -    | Off, On       | -    | Off     | Enabling the function   |
| Start Signal Only | -    | FALSE, TRUE   | -    | FALSE   | Enabling start signal only  |
| Start Frequency   | Hz   | 40.00 – 70.00 | 0.01 | 49.00   | Setting value of the comparison   |
| U limit           | -    | 0.1Un – 1Un   | 0.01 | 0.45    | Minimum voltage condition for enabling the operation of the function                            |
| Time Delay        | msec | 140* – 10000  | 1    | 200     | Time delay (including the algorithm time, see Chapter <a href="#">2.4</a> for more explanation) |

\*The minimum operate time is lower than the settable minimum delay, however below this value the timing is less accurate, see Chapter [2.3](#) for details



### 3.1.11.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.1.11.2.2.1. Analogue inputs

The function uses the sampled values of a voltage input or a calculated line-to-line voltage. This is defined in the configuration.

#### 3.1.11.2.2.2. Analogue outputs (measurements)

The frequency measurement is displayed *MXU\_F* – frequency measurement function which is an independent function.

#### 3.1.11.2.2.3. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the Logic editor.

*Table 2-2 The binary input signal of the underfrequency protection function*

| BINARY OUTPUT SIGNAL    | EXPLANATION                    |
|-------------------------|--------------------------------|
| TUF81_ <b>Blk</b> _GrO_ | Blocking input of the function |

#### 3.1.11.2.2.4. Binary output signals (graphed input statuses)

These signals can be used in EuroCAP to assign to LED, user LCD object etc. Parts written in **bold** are seen on the right side of the function block in the *Logic Editor*.

*Table 2-3 The binary output signals of the underfrequency protection function*

| BINARY OUTPUT SIGNAL      | SIGNAL TITLE  | EXPLANATION                          |
|---------------------------|---------------|--------------------------------------|
| TUF81_ <b>GenSt</b> _Grl_ | General Start | General start signal of the function |
| TUF81_ <b>GenTr</b> _Grl_ | General Trip  | General trip command of the function |

#### 3.1.11.2.2.5. Online data

Visible values on the *online data* page.

*Table 2-4 Online displayed data of the underfrequency protection function*

| SIGNAL TITLE  | DIMENSION | EXPLANATION                          |
|---------------|-----------|--------------------------------------|
| General Start | -         | General start signal of the function |
| General Trip  | -         | General trip command of the function |

#### 3.1.11.2.2.6. Events

The following events are generated in the event list, as well as sent to the SCADA according to the configuration.

*Table 2-5 Generated events of the underfrequency protection function*

| EVENT         | VALUE   | EXPLANATION                          |
|---------------|---------|--------------------------------------|
| General Start | off, on | General start of the function        |
| General Trip  | off, on | General trip command of the function |

### 3.1.11.2.3. Technical data

The technical data, except for the min. operate voltage, are based on the function block testing according to the directives of the IEC 60255-181:2019 standard.

Table 2-6 Technical data of the underfrequency protection function

| FUNCTION                | VALUE  | ACCURACY                     |
|-------------------------|--|------------------------------|
| Operate range           | 40 - 60 Hz (50 Hz system)<br>50 - 70 Hz (60 Hz system) | ± 3 mHz (20 mHz*)            |
| Effective range         | 45 - 55 Hz (50 Hz)<br>55 - 65 Hz (60 Hz)               | ± 3 mHz (10 mHz*)            |
| Min. operate time       | 93 ms (50 Hz)<br>73 ms (60 Hz)                         | ± 32 ms<br>± 27 ms           |
| Time delay              | 140 – 60000 ms<br><140 ms (50 Hz)<br><140 ms (60 Hz)   | ± 4 ms<br>± 32 ms<br>± 27 ms |
| Reset frequency         | [Start freq.] + 101 mHz                                | ± 1 mHz                      |
| Reset time              | 98 ms (50 Hz)<br>85 ms (60 Hz)                         | ± 6 ms                       |
| Reset ratio for U limit | 0.8  |                              |

\*with the harmonic content according to the standard

### 3.1.11.2.4. Notes for testing

Normally in the EuroProt+ devices the trip contacts are assigned to the Trip Logic function block, and not to the protection function blocks. Because of this, the testing personnel must make sure that the Trip Logic is switched on ('Operation' parameter is set to other than 'Off') before starting the tests, otherwise there will be no physical trip on the relay.

Note that the time delay parameter incorporates the algorithm time as well, so the time delay *does not mean the time difference between the appearance of the start and trip signals* of the function. In other words: it is not the delay between the detection of the fault and the trip that follows it. This should be taken into consideration when checking the disturbance records.

Instead the time delay parameter defines the elapsed time from the appearance of the faulty state to the trip. Because of this, while testing, the delay measurement should start *from the moment of the fault injection* until the trip signal.

The source voltage for frequency measurement is defined by the voltage input of the functionblock. This can be checked in the functionblock properties in EuroCAP.

Before the fault injection at least 1 second pre-fault should be simulated with nominal frequency and voltage.

Based on IEC 60255-181 standard recommendations, the operation time shall be measured with a frequency of 0.5Hz lower than the setting value for Start frequency.

## 3.1.12. Rate of change of frequency protection function

### 3.1.12.1. Application

The deviation of the frequency from the rated system frequency indicates unbalance between the generated power and the load demand. If the available generation is large compared to the consumption by the load connected to the power system, then the system frequency is above the rated value, and if it is small, the frequency is below the rated value. If the unbalance is large, then the frequency changes rapidly. The rate of change of frequency protection function is usually applied to reset the balance between generation and consumption to control the system frequency.

Another possible application is the detection of unintended island operation of distributed generation and some consumers. In the island, there is low probability that the power generated is the same as consumption; accordingly, the detection of a high rate of change of frequency can be one of the indications of island operation.

#### 3.1.12.1.1. Mode of operation

Depending on the hardware-software configuration, the frequency measurement is usually based on channel No. 1 (line voltage) and channel No. 4 (busbar voltage) of any voltage input module.

The accurate frequency measurement is performed by measuring the time period between two rising edges and also between two falling edges at zero crossing of a voltage signal. The frequency value is calculated by the average of these two values. At each zero crossing the average value (and the frequency) is recalculated.

For the acceptance of the measured frequency, at least four subsequent valid measurements are needed. Similarly, four invalid measurements are needed to reset the measured frequency from the last valid value to zero.

Other basic criterion is that the evaluated voltage should be above 10% of the rated voltage value.

The rate of change of frequency protection function generates a start signal if the  $df/dt$  value is above the setting value. The rate of change of frequency is calculated as the difference of the frequency at the present sampling and at 5 periods earlier; the  $df/dt$  comparator has a built-in delay of 100 ms to filter out unwanted operations.



### 3.1.12.2. Rate of change of frequency protection function overview

The graphic appearance of the function block of the rate of change of frequency protection function is shown below. The block shows all binary input and output status signals which are applicable in the graphic equation editor.




Figure 2-1 Graphic appearance of the function block of the rate of change of frequency protection function

### 3.1.12.2.1. Settings


#### 3.1.12.2.1.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

Table 2-1 Parameters of the rate of change of frequency protection function

| TITLE             | DIM    | RANGE        | STEP | DEFAULT | EXPLANATION   |
|-------------------|--------|--------------|------|---------|---|
| Operation         | -      | Off, On      | -    | Off     | Enabling the function   |
| Start Signal Only | -      | FALSE, TRUE  | -    | FALSE   | Enabling start signal only  |
| Start df/dt       | Hz/sec | -5.00 – 5.00 | 0.01 | 0.50    | Setting value of the comparison   |
| Time Delay        | msec   | 200* – 10000 | 1    | 200     | Time delay (including the algorithm time, see Chapter 2.4 for more explanation) |

*\*the minimum operate time is lower than the settable minimum delay, however below this value the timing is less accurate, see Chapter 2.3 for details*



### 3.1.12.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.1.12.2.2.1. Analogue inputs

The function uses the sampled values of a voltage input or a calculated line-to-line voltage. This is defined in the configuration.

#### 3.1.12.2.2.2. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the *Logic editor*.

Table 2-2 The binary input signal of the rate of change of frequency protection function

| BINARY OUTPUT SIGNAL    | EXPLANATION                    |
|-------------------------|--------------------------------|
| FRC81_ <b>Blk</b> _GrO_ | Blocking input of the function |

#### 3.1.12.2.2.3. Binary output signals (graphed input statuses)

These signals can be used in EuroCAP to assign to LED, user LCD object etc. Parts written in **bold** are seen on the right side of the function block in the *Logic Editor*.

Table 2-3 The binary output signals of the rate of change of frequency protection function

| BINARY OUTPUT SIGNAL      | SIGNAL TITLE  | EXPLANATION                          |
|---------------------------|---------------|--------------------------------------|
| FRC81_ <b>GenSt</b> _Grl_ | General Start | General start signal of the function |
| FRC81_ <b>GenTr</b> _Grl_ | General Trip  | General trip command of the function |

#### 3.1.12.2.2.4. Online data

Visible values on the *online data* page.

Table 2-4 Online displayed data of the rate of change of frequency protection function

| SIGNAL TITLE  | DIMENSION | EXPLANATION                          |
|---------------|-----------|--------------------------------------|
| General Start | -         | General start signal of the function |
| General Trip  | -         | General trip command of the function |

#### 3.1.12.2.2.5. Events

The following events are generated in the event list, as well as sent to the SCADA according to the configuration.

Table 2-5 Generated events of the rate of change of frequency protection function

| EVENT         | VALUE   | EXPLANATION                          |
|---------------|---------|--------------------------------------|
| General Start | off, on | General start of the function        |
| General Trip  | off, on | General trip command of the function |

### 3.1.12.2.3. Technical data

The technical data, except for the min. operate voltage, are based on the function block testing according to the directives of the IEC 60255-181:2019 standard.

Table 2-6 Technical data of the rate of change of frequency protection function

| FUNCTION                                   | VALUE                                 | ACCURACY               |
|--|---------------------------------------|------------------------|
| Min. operate voltage                       | 0.1 Un                                |                        |
| Operate range                              | ± 10 Hz/s                             | ± 50 mHz/s (60 mHz/s*) |
| Effective range                            | ± 5 Hz/s                              | ± 15 mHz/s (50 mHz/s*) |
| Min. operate time                          | 191 ms (50 Hz)<br>159 ms (60 Hz)      | ± 40 ms<br>± 39 ms     |
| Time delay (at 0.2 Hz/s)                   | 200 – 60000 ms (50 Hz)                | ± 2 ms                 |
| Reset ratio (drop/pick in absolute values) | 0.92 (>0.5 Hz/s)<br>0.999 (<0.5 Hz/s) | -0.03<br>-0.072        |
| Reset time                                 | 187 ms (50 Hz)<br>157 ms (60 Hz)      | ± 44 ms<br>± 38 ms     |


\*with the harmonic content according to the standard

### 3.1.12.2.4. Notes for testing

Normally in the EuroProt+ devices the trip contacts are assigned to the Trip Logic function block, and not to the protection function blocks. Because of this, the testing personnel must make sure that the Trip Logic is switched on ('Operation' parameter is set to other than 'Off') before starting the tests, otherwise there will be no physical trip on the relay.

Note that the time delay parameter incorporates the algorithm time as well, so the time delay does **not** mean the time difference between the appearance of the start and trip signals of the function. In other words: it is not the delay between the detection of the fault and the trip that follows it. This should be taken into consideration when checking the disturbance records.

Instead the time delay parameter defines the elapsed time from the appearance of the faulty state to the trip. Because of this, while testing, the delay measurement should start *from the moment of the fault injection* until the trip signal.



C

### 3.1.13. Vector jump protection function

#### 3.1.13.1. Application

The modern electric power systems include an increasing number of small generators (distributed generation system). There can be several events in the network resulting that the small generators get disconnected from the system, and the small generator supplies some consumer only, remaining in the electric “island” (unintended islanding).

If a small generator remains in an island with some consumers, it is highly possible that the balance of the generated and consumed active and reactive power is not fulfilled. This results changing of the frequency and/or voltage, accordingly the voltage vector position of the island is changing, related to that of the disconnected grid. An automatic reclosing of the circuit breaker at an unfavorable vector position can result high currents and serious damages. To prevent these damages a protection is needed to detect the islanding and to disconnect the generator from the island.

One of the protection methods to detect unintended islanding is this vector jump protection function.

#### 3.1.13.2. Mode of operation

When an unintended islanding occurs then the induced voltage inside the generator (EMF) may not change abruptly. As a consequence, on other locations within the island (at the connection point of the generator, at the bus-bar or at the consumer) a sudden change of the voltage vector can be detected. It means that the vector „jumps”, the time period of the sinusoid at the moment of the change can be shorter or longer than the previous or subsequent ones.

The main task of the vector jump protection function is to detect the unintended islanding, when the generator with some consumer area is disconnected from the electric power grid.

The application of the vector jump function needs careful setting. One of the problems is caused by the scenario, when the balance of the electric power before and after the islanding is not changing significantly (the generated and consumed power within the island is balanced). Accordingly the limit for jump detection must be set to a low angle value, but there is no guarantee that the islanding is detected by this method. At the same time, however, a switching of a relatively large consumer can cause also a vector jump. To prevent the unwanted trip, in this scenario the setting limit for the vector jump angle should be selected large.

For vector jump detection the function must be enabled, and the measured positive sequence voltage component must be above a minimum value.

If a fault occurs on the network, the voltage vector jumps. In this case a decision is needed if the role of the vector jump function is the fault protection, or the fault is to be cleared at other locations of the network. For excluding the operation in case of asymmetrical faults, the negatives sequence and zero sequence voltage components must be supervised. If they are above the setting, asymmetrical fault is detected and the operation of the vector jump protection function is blocked.


For vector jump detection the function must be enabled, and the measured voltage must be above a minimum value. For disabling the operation in case of low voltage an additional undervoltage binary input is provided.

C

If the network frequency is deviating from the nominal frequency then the voltage vector rotates slowly in the complex coordinate system. As the vector jump detection function is based on comparison of the vectors of the actual and some previous states, the vector rotation caused by the frequency deviation must be compensated. For this purpose also the network frequency is measured continuously.

### 3.1.13.3. Structure of the vector jump protection algorithm

The scheme of operation of the vector jump protection function is shown in *Figure 1-1*.



*Figure 1-1 Structure of the vector jump protection algorithm*

The **inputs** are


- the three phase voltages,
- parameters,
- status signals.

NOTE: in some device configurations also the residual voltage is measured separately. In this case the zero sequence voltage component is calculated directly from the residual voltage. For the actual realization please consult the configuration manual delivered with the device.

The **output** is

- the binary output status signal for tripping.

The **software modules** of the vector jump protection function are:



C

### Modules for processing the input signals:

#### **Fourier calculations**

These modules calculate the basic Fourier components of the phase voltages individually. (They are not part of the Vector jump function.)

#### **Positive sequence component calculation**

This module calculates the positive sequence voltage component based on the basic Fourier components of the phase voltages. (It is not part of the Vector jump function). The magnitude of the positive sequent voltage component must be above the setting to enable the operation.

#### **Negative sequence component calculation**

This module calculates the negative sequence voltage component based on the basic Fourier components of the phase voltages. (It is not part of the Vector jump function). If the magnitude of the negative sequent voltage component is above the setting then an asymmetrical fault is supposed and the operation of the vector jump protection function is blocked.

#### **Zero sequence component calculation**

This module calculates the zero sequence voltage component based on the basic Fourier components of the phase voltages. (It is not part of the Vector jump function). If the magnitude of the zero sequent voltage component is above the setting then an asymmetrical fault is supposed and the operation of the vector jump protection function is blocked.

#### **Frequency calculation**

This module calculates the frequency. (It is not part of the Vector jump function.) Based on the frequency value the calculated angle of the vector jump is corrected, if the frequency deviates from the rated frequency.

### Modules for vector jump detection and decision:


#### **Vector jump calculation**

This module calculates the vector jump, based on the Fourier components of the positive sequence voltage component.

#### **Decision logic**

The decision logic module combines the status signals to generate the trip command of the function.

The following description explains the details of the individual components.



c

### 3.1.13.3.1. The Fourier calculation

These modules calculate the basic Fourier components of the phase voltages individually. They are not part of the vector jump function; they belong to the preparatory phase.

The **inputs** are the sampled values of the three phase voltages (UL1, UL2, UL3)

The **outputs** are the basic Fourier components of the analyzed voltages (UL1Four, UL2Four, UL3Four).

NOTE: in some device configurations also the residual voltage is measured separately. In this case the zero sequence voltage component is calculated directly from the residual voltage. For the actual realization please consult the configuration manual delivered with the device.

### 3.1.13.3.2. The symmetrical component calculation

These modules (Positive sequence component calculation, negative sequence component calculation, zero sequence component calculation) calculate the magnitudes and phase angles of the symmetrical components, based on the theory of the component calculation.

The magnitude of the positive sequent component is used to enable the vector jump decision. The magnitudes of the negative and zero sequence components can disable the vector jump decision.

The angle of the vector jump is calculated based on the angle of the positive sequence component and the angle of this component two periods before. The rotation of the vector caused by the frequency deviation is compensated based on the frequency input.

NOTE: in some device configurations also the residual voltage is measured separately. In this case the zero sequence voltage component is calculated directly from the residual voltage. For the actual realization please consult the configuration manual delivered with the device.

The **inputs** of this module are the basic Fourier components of the phase voltages (UL1Four, UL2Four, IUL3Four).

The **outputs** of this module are the basic Fourier components of the positive, negative and zero sequence voltage components, given in terms of magnitudes and phase angles.


### 3.1.13.3.3. The frequency calculation

Depending on the hardware-software configuration, the frequency measurement is usually based on channel No. 1 of the voltage input module. In some applications, the frequency is measured based on the weighted sum of the phase voltages. For the actual realization please consult the configuration manual delivered with the device.

The accurate frequency measurement is performed by measuring the time period between two rising edges at zero crossing of a voltage signal. For the acceptance of the measured frequency, at least four subsequent identical measurements are needed. Similarly, four invalid measurements are needed to reset the measured frequency to zero. The basic criterion is that the evaluated voltage should be above 30% of the rated voltage value.

The **inputs** of this module are assigned voltages channels, according to the device configuration.

The **output** of this module is the calculated frequency in mHz units.



C

### 3.1.13.3.4. The vector jump calculation

The vector jump is the difference between the phase angle of the actual positive sequence component and the angle measured two network periods earlier. A vector jump is detected if the absolute value of the calculated angle difference is above the setting value.

The **inputs** of this module are the data of the positive sequence voltage, the frequency and the setting value of the vector jump. The module stores the angles of the positive sequence voltage component in the memory for two network periods, and calculates the “raw” vector jump. This value is corrected if the frequency deviates from the rated network frequency.

The binary **output** of this module is true if the corrected vector jump is above the setting value.

### 3.1.13.3.5. The decision logic

The decision logic module combines the status signals and parameters to generate the trip command of the function.

The performed logic is a simple one: a trip command is generated if:

- The calculated vector jump is above the setting value,
- The magnitude of the positive sequence voltage component is above the setting value,
- The magnitude of the negative sequence voltage component is below the setting value,
- The magnitude of the zero sequence voltage component is below the setting value,
- The “Blk” binary input does not block the function, and
- The “UVBlk” binary input does not block the function.

The vector jump means that one network frequency period of the voltage sinusoid is shorter or longer than the previous periods or that of the subsequent periods. This binary information must be prolonged to generate the trip pulse. The minimum duration of the trip command is set by a parameter.

NOTE: when checking the pulse duration please consider that the timer parameter defines the prolongation, the operating time span is added to the pulse duration.



C

### 3.1.13.4. Technical summary

#### 3.1.13.4.1. Technical data

| Function                       | Value          | Accuracy |
|--------------------------------|----------------|----------|
| Pick-up starting accuracy      |                | < ± 0,5° |
| Blocking voltage               | U>0.2Un        | < 5%     |
| Operate time<br>Jump>2*setting | <50 ms         |          |
| Minimum operate time           | 40 ms          |          |
| Pulse duration                 | 150 ... 500 ms | <10 ms   |

Table 1-1 Technical data of the vector jump protection function

#### 3.1.13.4.2. The parameters

##### Enumerated parameters

| Parameter name  | Title     | Selection range | Default |
|---|-----------|-----------------|---------|
| Enabling or disabling the vector jump protection function |           |                 |         |
| VectJmp_Oper_EPar_  | Operation | Off,On          | Off     |

Table 1-2 The enumerated parameters of the vector jump protection function

##### Integer parameters

| Parameter name   | Title               | Unit | Min | Max | Step | Default |
|--|---------------------|------|-----|-----|------|---------|
| Starting phase difference level setting. If the vector jump is above the setting value, the function generates a start signal.   |                     |      |     |     |      |         |
| VectJmp_PhDiff_IPar_   | PhaseDiff Limit     | deg  | 5   | 25  | 1    | 10      |
| Enabling positive voltage level setting. If the measured positive sequence voltage component is above the setting value, the function enables the trip signal.         |                     |      |     |     |      |         |
| VectJmp_UposLim_IPar_  | Min PosSeq Voltage  | %    | 10  | 100 | 1    | 30      |
| Blocking negative sequence voltage level setting. If the measured negative sequence voltage component is above the setting value, the function blocks the trip signal. |                     |      |     |     |      |         |
| VectJmp_UnegLim_IPar_  | Max NegSeq Voltage  | %    | 5   | 50  | 1    | 10      |
| Blocking zero sequence voltage level setting. If the measured voltage is above the setting value, the function blocks the trip signal.                                 |                     |      |     |     |      |         |
| VectJmp_UoLim_IPar_  | Max ZeroSeq Voltage | %    | 1   | 30  | 1    | 5       |

Table 1-3 Integer parameters of the vector jump protection function

##### Timer parameter

| Parameter name              | Title          | Unit | Min | Max | Step | Default |
|-----------------------------|----------------|------|-----|-----|------|---------|
| Trip command pulse duration |                |      |     |     |      |         |
| VectJmp_Pulse_TPar_         | Pulse Duration | msec | 150 | 500 | 1    | 150     |

Table 1-4 Timer parameter of the vector jump protection function

### 3.1.13.4.3. Binary output status signal

The **binary output status signal** of vector jump protection function is shown in Table 1-5.

| Binary status signal | Title | Explanation                  |
|----------------------|-------|------------------------------|
| VectJmp_Trip_Grl_    | Trip  | Trip command of the function |

*Table 1-5 The binary output status signals of the vector jump protection function*

### 3.1.13.4.4. Binary input status signals

#### Binary input signals


The vector jump protection function has binary input signals, which serve the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Title | Explanation                                   |
|----------------------|-------|---|
| VectJmp_Blkl_GrO_    | Blk   | General blocking status signal                |
| VectJmp_UVBlkl_GrO_  | UVBlk | External under-voltage blocking status signal |

*Table 1-6 The binary input signal of vector jump protection function*

### 3.1.13.4.5. The function block

The function block of vector jump protection function is shown in Figure 1-2. This block shows all binary input and output status signals that are applicable in the graphic logic editor.



*Figure 1-2 The function block of vector jump protection function*

## 3.2. Control & supervision functions

### 3.2.1. Phase-Selective Trip Logic

#### 3.2.1.1. Operation principle

The phase-selective trip logic function operates according to the functionality required by the IEC 61850 standard for the “Trip logic logical node”.

##### 3.2.1.1.1. Application

The phase-selective function is applied when one-phase trip commands might be required, mostly in distance protection applications.

The function receives the trip requirements of the protective functions implemented in the device and combines the binary signals and parameters to the outputs of the device.

The trip requirements are programmed by the user, using the graphic equation editor. The decision logic has the following aims:

- Define a minimal impulse duration even if the protection functions detect a very short time fault,
- In case of phase-to-phase faults, involve the third phase in the trip command,
- Fulfill the requirements of the automatic reclosing function to generate a three-phase trip command even in case of single-phase faults,
- In case of an evolving fault, during the evolving fault waiting time include all three phases into the trip command

##### 3.2.1.1.2. The decision logic

The decision logic module combines the status signals and the enumerated parameter to generate the general trip command on the output module of the device.




Figure 1-1 Logic scheme of the decision logic

### 3.2.1.2. PhSel. Trip logic function overview

The graphic appearance of the function block of the phase-selective trip logic function is shown in the figure below.




Figure 2-1 Graphic appearance of the function block of the phase-selective trip logic function

### 3.2.1.2.1. Settings

#### 3.2.1.2.1.1. Parameters

| TITLE               | DIM | RANGE                       | STEP | DEFAULT | EXPLANATION                             |
|---------------------|-----|-----------------------------|------|---------|---|
| Operation           | -   | Off, 3ph trip, 1ph/3ph trip | -    | Off     | Selection of the operating mode         |
| Min Pulse Duration  | ms  | 50 – 60000                  | 1    | 150     | Minimum duration of the generated pulse |
| Evolving Fault Time | ms  | 50 – 60000                  | 1    | 1000    | Waiting time for evolving fault         |

Table 2-1 Parameters of the phase-selective trip logic function

### 3.2.1.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.2.1.2.2.1. Analogue inputs

This function does not have analogue inputs.

#### 3.2.1.2.2.2. Analogue outputs (measurements)

This function does not have measurements.

#### 3.2.1.2.2.3. Binary input signals (graphed output statuses)

The conditions of the inputs are defined by the user, applying the graphic equation editor (logic editor). The part written in **bold** is seen on the function block in the logic editor.

| BINARY INPUT SIGNAL        | EXPLANATION   |
|----------------------------|---|
| TRC94_ <b>Blk</b> _GrO_    | Blocking the outputs of the function                        |
| TRC94_ <b>Tr1ph</b> _GrO_  | Request for single-phase trip command                       |
| TRC94_ <b>Tr3ph</b> _GrO_  | Request for three-phase trip command                        |
| TRC94_ <b>StL1</b> _GrO_   | Request for trip command in phase L1                        |
| TRC94_ <b>StL2</b> _GrO_   | Request for trip command in phase L2                        |
| TRC94_ <b>StL3</b> _GrO_   | Request for trip command in phase L3                        |
| TRC94_ <b>Fin3ph</b> _GrO_ | Forcing three-phase trip even in case of single-phase fault |

Table 2-2 The binary input signals of the phase-selective trip logic function

### 3.2.1.2.2.4. Binary output signals (graphed input statuses)

The binary output status signals of the differential protection function. Parts written in **bold** are seen on the function block in the logic editor.

| BINARY OUTPUT SIGNAL | SIGNAL TITLE | EXPLANATION   |
|----------------------|--------------|---|
| TRC94_TrL1_Grl_      | Trip L1      | Generated trip command for phase L1                                   |
| TRC94_TrL2_Grl_      | Trip L2      | Generated trip command for phase L2                                   |
| TRC94_TrL3_Grl_      | Trip L3      | Generated trip command for phase L3                                   |
| TRC94_GenTr_Grl_     | General Trip | Generated general trip command (active for 1ph and 3ph trips as well) |
| TRC94_Tr3ph_Grl_     | 3Ph Trip     | Generated three-phase trip command                                    |

Table 2-3 The binary output signal of the phase-selective trip logic function

### 3.2.1.2.2.5. On-line data

Visible values on the on-line data page:

| SIGNAL TITLE | DIMENSION | EXPLANATION                              |
|--------------|-----------|--|
| General Trip | -         | Status of the General Trip binary output |
| Trip L1      | -         | Status of the Trip L1 binary output      |
| Trip L2      | -         | Status of the Trip L2 binary output      |
| Trip L3      | -         | Status of the Trip L3 binary output      |
| 3Ph Trip     | -         | Status of the 3Ph Trip binary output     |

Table 2-4 On-line data of the phase-selective trip logic function

### 3.2.1.2.2.6. Events

The following events are generated in the event list, as well as sent to SCADA according to the configuration.

| EVENT        | VALUE   | EXPLANATION                              |
|--------------|---------|--|
| Trip L1      | off, on | Status of the Trip L1 binary output      |
| Trip L2      | off, on | Status of the Trip L2 binary output      |
| Trip L3      | off, on | Status of the Trip L3 binary output      |
| General Trip | off, on | Status of the General Trip binary output |

Table 2-5 Event of the phase-selective trip logic function

### 3.2.1.2.3. Technical data

| FUNCTION   | VALUE | ACCURACY |
|------------|-------|----------|
| Pulse time |       | < 3 ms   |

Table 2-6 The technical data of the phase-selective trip logic function

### 3.2.1.2.3.1. Notes for testing

When using an EuroProt+ device with phase-selective trip logic, the first 3 trip contacts of the trip module are assigned to the corresponding Trip L1-L2-L3 outputs of the Trip Logic function block. These assignments can be checked in the configuration file of the device by using the EuroCAP tool (see the picture below, note that the actual configuration might be different from that of on the figure). It is possible to assign multiple contacts to one trip logic output (mainly when two trip circuits are used).

▼ E1-Line\_F

- ▼ Hardware Configuration
  - Connector allocation
  - LED assignment
  - ▼ IO Signals
    - > Analogue Inputs
    - > Analogue Outputs
    - > Binary Inputs
    - > Binary Outputs
    - ▼ Trip definition
      - Assignment
      - Communication
  - > Software Configuration
  - Subscribed GOOSE assignment
  - > System

### Trip definition / Assignment

Add

Insert

Remove

Modify

| Ix | Name        | Title   | Defined by        | Show order | Parameters                       | Type             |
|----|-------------|---------|-------------------|------------|----------------------------------|------------------|
| 0  | TripAssign1 | Trip L1 | RootFunctionBlock |            | TRC94_TripL1_TLO_TripContact_O02 | 4444 Trip assign |
| 1  | TripAssign2 | Trip L2 | RootFunctionBlock |            | TRC94_TripL2_TLO_TripContact_O04 | 4444 Trip assign |
| 2  | TripAssign3 | Trip L3 | RootFunctionBlock |            | TRC94_TripL3_TLO_TripContact_O06 | 4444 Trip assign |

Move Up

Move Dn

*Figure 2-2 Trip assignment in EuroCAP*

During commissioning the testing personnel must make sure that, along with the protection functions under test, the corresponding Trip Logic(s) is (are) switched on ('Operation' parameter is set to other than 'Off') before starting the testing, otherwise there will be no actual trip signal given on the assigned trip contacts.

### 3.2.2. Circuit breaker wear monitoring function

If a circuit breaker interrupts a current, the electric arc between the contacts results some metal loss. If the metal loss due to the burning of the electric arc becomes substantial, the contacts must be replaced.


Manufacturers define the permitted number of short circuits by formulas such as:

$$\sum_{i=1}^n I_i^k = CycNum$$

where

- n = number of short circuits
- k = exponent, calculated by the algorithm, based on the parameters I = short-circuit current, kA (RMS)
- CycNum = total value of weighted breaking currents.

Similar information is conveyed by the diagram below. This shows the number of permitted interruptions (logarithmic scaling) versus short-circuit current (logarithmic scaling) that the contacts in a circuit breaker can manage before the metal loss due to burning becomes so significant that the contacts must be replaced.




*Figure 1-1 Example: Number of permitted interruptions as the function of the interrupted current*

The straight line of the curve is defined by two points:

- The number of permitted interruptions of 1 kA current (CycNum - 1kA)
- The number of permitted interruptions of the rated breaking current of the circuit breaker (CycNum – I Rated Trip).

The circuit breaker wear monitoring function finds the maximum value of the phase currents of each interruption and calculates the wear caused by the operation performed. If the sum of the calculated wear reaches the limit, a warning signal is generated. This indicates the time of the required preventive maintenance of the circuit breaker.



### 3.2.2.1. Operation of the circuit breaker wear monitoring algorithm

The operating principle of the circuit breaker wear monitoring function is based on curves similar to the one shown in [Figure 1-1](#). With this figure, the manufacturer of the circuit breaker defines the permitted total number of current interruptions up to the subsequent preventive maintenance.

The straight line of the curve is defined by two points:

- The number of interruptions of 1 kA current, by parameter `CBWear_CycNumIn_IPar_` (`CycNum - 1kA`)
- The number of interruptions of the rated breaking current of the circuit breaker by parameter `CBWear_CycNumInTrip_IPar_` (`CycNum - I Rated Trip`). The rated breaking current of the circuit breaker is set by parameter `CBWear_InTrCB_FPar_` (`Rated Trip Current`)

The circuit breaker wear monitoring function processes the Fourier basic harmonic component of the three phase currents.

The circuit breaker wear monitoring function identifies the highest value of the phase currents at each interruption.

The procedure of monitoring starts at the receipt of a trip command on the dedicated input (`Trip`). For the start of this procedure, the circuit breaker also needs to be in closed state. This signal is received on the dedicated binary input (`CB Closed`).

The procedure of identifying the maximum phase current value terminates when the current falls below the minimum current defined by the parameter `CBWear_Imin_FPar_` (`Min Current`) AND the circuit breaker gets in open position. This signal is received on the dedicated binary input (`CB Open`).

The procedure also stops if the time elapsed since its start exceeds 1 s. In this case no CB wear is calculated.

Based on the characteristic defined above, the function calculates the wear caused by the operation performed. If the sum of the calculated wear reaches the limit defined by the parameter `CBWear_CycNumAlm_IPar_` (`CycNum - Alarm`), a warning signal is generated (`Alarm`). This indicates the advised time of the preventive maintenance of the circuit breaker.

The accumulated “wear” of the circuit breaker is stored on non-volatile memory; therefore, the value is not lost even if the power supply of the devices is switched off.

This information is displayed among the on-line data as “Actual wear”. This counter indicates how many 1 kA equivalent switches were performed since the last maintenance (reset).

When preventive maintenance is performed, the accumulated “wear” of the circuit breaker must be reset to 0 to start a new maintenance cycle. The circuit breaker wear monitoring function offers two ways of resetting:

- Binary True signal programmed to the “Reset” input of the function
- Performing a direct command via the Commands menu of the supervising WEB browser (for details, see the “Europrot+ manual”, “Remote user interface description” document). The Command window looks like [Figure 1-2](#).





Figure 1-2 The command window to reset the CB wear counter

The **inputs** of the circuit breaker wear monitoring function are

- the Fourier components of three phase currents,
- binary inputs,
- parameters.

The **output** of the circuit breaker wear monitoring function is

- the Alarm binary output status signal.

### 3.2.2.2. Technical summary

#### 3.2.2.2.1. Technical data

| Function  | Range            | Accuracy  |
|---|------------------|-----------|
| Current accuracy  | 20 – 2000% of In | ±1% of In |
| Accuracy in tracking the theoretical wear characteristics |                  | 5%        |

Table 1-1 Technical data of the circuit breaker wear monitoring

#### 3.2.2.2.2. Summary of the parameters

The parameters of the circuit breaker wear monitoring function are explained in the following tables.

##### Enumerated parameter

| Parameter name                                      | Title     | Selection range | Default |
|---|-----------|-----------------|---------|
| Disabling or enabling the operation of the function |           |                 |         |
| CBWear_Oper_EPar_                                   | Operation | Off,On          | Off     |

Table 1-2 The enumerated parameter of the circuit breaker wear monitoring function

### Integer parameters

| Parameter name   | Title                 | Unit | Min | Max    | Step | Default |
|--|-----------------------|------|-----|--------|------|---------|
| Permitted number of trip operation if the breaking current is 1kA  |                       |      |     |        |      |         |
| CBWear_CycNumIn_IPar_  | CycNum - 1kA          |      | 1   | 100000 | 1    | 50000   |
| Permitted number of trip operation if the breaking current is InTrip (See floating parameter "Rated Trip Current") |                       |      |     |        |      |         |
| CBWear_CycNumInTrip_IPar_  | CycNum – I Rated Trip |      | 1   | 100000 | 1    | 100     |
| Permitted level of the weighted sum of the breaking currents   |                       |      |     |        |      |         |
| CBWear_CycNumAlm_IPar_   | CycNum - Alarm        |      | 1   | 100000 | 1    | 50000   |

Table 1-3 The integer parameters of the circuit breaker wear monitoring function

### Floating point parameters

| Parameter name   | Title              | Unit | Min  | Max  | Step | Default |
|--|--------------------|------|------|------|------|---------|
| Rated breaking current of the circuit breaker  |                    |      |      |      |      |         |
| CBWear_InTrCB_FPar_  | Rated Trip Current | kA   | 10   | 100  | 0.01 | 10      |
| Minimum level of the current below which the procedure to find the highest breaking current is stopped |                    |      |      |      |      |         |
| CBWear_Imin_FPar_  | Min Current        | kA   | 0.10 | 0.50 | 0.01 | 0.10    |

Table 1-4 The floating-point parameters of the circuit breaker wear monitoring function

## 3.2.2.2.3. Binary output status signals

The **binary output status signals** of the circuit breaker wear monitoring function.

| Binary output signals              | Signal title | Explanation   |
|------------------------------------|--------------|---|
| Alarm signal of the function block |              |   |
| CBWear_Alarm_GrI_                  | Alarm        | Alarm signal is generated if the weighted sum of the breaking currents is above the permitted level |

Table 1-5 The binary output status signal of the circuit breaker wear monitoring function

## 3.2.2.2.4. The binary input status signals

The **binary inputs** are signals influencing the operation of the circuit breaker wear monitoring function. These signals are the results of logic equations graphically edited by the user.


| Binary input signals                | Signal title | Explanation   |
|-------------------------------------|--------------|---|
| Disabling the function              |              |   |
| CBWear_BlK_GrO_                     | Blk          | The programmed True state of this input disables the operation of the function                                  |
| Open state of the circuit breaker   |              |   |
| CBWear_Open_GrO_                    | Open         | The open state of the circuit breaker is needed to stop the procedure to find the maximum breaking current      |
| Closed state of the circuit breaker |              |   |
| CBWear_Closed_GrO_                  | Closed       | The closed state of the circuit breaker is needed to perform the procedure to find the maximum breaking current |
| Trip command to the circuit breaker |              |   |

|                   |       |   |
|-------------------|-------|---|
| CBWear_Trip_GrO_  | Trip  | This signal starts the procedure to find the highest breaking current   |
| Reset command     |       |   |
| CBWear_Reset_GrO_ | Reset | If this input is programmed to logic True, at maintenance the weighted sum of the breaking currents can be set to 0 |

*Table 1-6 The binary input signals of the circuit breaker wear monitoring function*

### 3.2.2.2.5. The function block

The function block of the circuit breaker wear monitoring function is shown in [Figure 1-3](#). This block shows all binary input and output status signals that are applicable in the graphic equation editor.



*Figure 1-3 The function block of the circuit breaker wear monitoring function*



### 3.2.3. Circuit breaker control function block

#### 3.2.3.1. Application

The circuit breaker control block can be used to integrate the circuit breaker control of the EuroProt+ device into the station control system and to apply active scheme screens of the local LCD of the device.

##### 3.2.3.1.1. Mode of operation

The circuit breaker control block receives remote commands from the SCADA system and local commands from the local LCD of the device, performs the prescribed checking and transmits the commands to the circuit breaker. It processes the status signals received from the circuit breaker and offers them to the status display of the local LCD and to the SCADA system.

Main features:

- Local (LCD of the device) and Remote (SCADA) operation modes can be enabled or disabled individually.
- The signals and commands of the synchro-check / synchro-switch function block can be integrated into the operation of the function block.
- Interlocking functions can be programmed by the user applying the inputs “EnaOff” and “EnaOn”, using the graphic equation editor.
- Programmed conditions can be used to temporarily disable the operation of the function block using the graphic equation editor.
- The function block supports the control models prescribed by the IEC 61850 standard.
- All necessary timing tasks are performed within the function block:
  - Time limitation to execute a command
  - Command pulse duration
  - Filtering the intermediate state of the circuit breaker
  - Checking the synchro-check and synchro-switch times
  - Controlling the individual steps of the manual commands
- Sending trip and close commands to the circuit breaker (to be combined with the trip commands of the protection functions and with the close command of the automatic reclosing function; the protection functions and the automatic reclosing function directly gives commands to the CB). The combination is made graphically using the graphic equation editor
- Operation counter
- Event reporting

### 3.2.3.2. Circuit Breaker control function overview




Figure 2-1 Graphic appearance of the function block of the circuit breaker control function

### 3.2.3.3. Settings

#### 3.2.3.3.1. Parameters

| TITLE                 | DIM | RANGE  | STEP | DEFAULT       | EXPLANATION  |
|-----------------------|-----|--|------|---------------|--|
| ControlModel          | -   | Direct normal, Direct enhanced, SBO enhanced | -    | Direct normal | The control model of the circuit breaker node according to the IEC 61850 standard  |
| Forced Check          | -   | FALSE, TRUE                                  | -    | TRUE          | If true, then the check function cannot be neglected by the check attribute defined by the IEC 61850 standard  |
| Max Operating Time    | ms  | 10 – 1000                                    | 1    | 200           | When either enhanced control model is selected, the status of the CB must change within this time after the issued command. At timeout an invalid-position error will be generated for the client.                 |
| Pulse Duration        | ms  | 50 – 1000                                    | 1    | 300           | Duration of the generated On and Off impulse*  |
| Max Intermediate Time | ms  | 20 – 500                                     | 1    | 100           | Waiting time for status signals, at expiry the CB is reported to be in intermediate state  |
| Max SynCheck Time     | ms  | 10 – 5000                                    | 1    | 1000          | Length of the time period to wait for the conditions of the synchronous state. After expiry of this time, the synchro-switch procedure is initiated (see synchro-check/ synchro-switch function block description) |
| Max SynSW Time**      | ms  | 0 – 60000                                    | 1    | 0             | Length of the time period to wait for the synchro-switch impulse (see synchro-check/ synchro-switch function block description). After this time the function resets, no switching is performed                    |
| SBO Timeout           | ms  | 1000 – 20000                                 | 1    | 5000          | Duration of the waiting time between object selection and command selection. At timeout no command is performed  |

\* If the input status signals (stValOff, stValOn) indicate the successful switching then the pulse is withdrawn, but the minimum duration is 100 ms (factory setting).

\*\* If this parameter is set to 0, then the “StartSW” output is not activated

Table 2-1 Parameters of the circuit breaker control function

### 3.2.3.3.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.2.3.3.2.1. Binary input signals (graphed output statuses)

The conditions of the inputs are defined by the user, applying the graphic equation editor (logic editor). The part written in **bold** is seen on the function block in the logic editor.

| BINARY INPUT SIGNAL            | EXPLANATION  |
|--------------------------------|--|
| CB1Pol_ <b>Local</b> _GrO_     | If this input is active, the circuit breaker can be controlled using the local LCD of the device.  |
| CB1Pol_ <b>Remote</b> _GrO_    | If this input is active, the circuit breaker can be controlled via remote communication channels of the SCADA system or the device web page ('commands' menu)  |
| CB1Pol_ <b>SynOK</b> _GrO_     | This input indicates if the synchronous state of the voltage vectors at both sides of the circuit breaker enables the closing command. This signal is usually generated by the synchro check/ synchro switch function. If this function is not available, set the input to logic true. |
| CB1Pol_ <b>EnaOff</b> _GrO_    | The active state of this input enables the opening of the circuit breaker. The state is usually generated by the <i>interlocking conditions defined graphically by the user</i> .  |
| CB1Pol_ <b>EnaOn</b> _GrO_     | The active state of this input enables the closing of the circuit breaker. The state is usually generated by the <i>interlocking conditions defined graphically by the user</i> .  |
| CB1Pol_ <b>BlkProc</b> _GrO_   | The active state of this input blocks the operation of the circuit breaker. The conditions are defined graphically by the user.  |
| CB1Pol_ <b>stValOff</b> _GrO_  | Off (Opened) state of the circuit breaker.   |
| CB1Pol_ <b>stValOn</b> _GrO_   | On (Closed) state of the circuit breaker.  |
| CB1Pol_ <b>ExtSwitch</b> _GrO_ | This signal is considered only when evaluating unintended operation (see "SelfOper" output in Chapter 2.2.2). It indicates that an external command has been issued to the circuit breaker (e.g. trip request from other protection device or external on/off command is given).       |

*Table 2-2 The binary input signals of the circuit breaker control function*

### 3.2.3.3.2.2. Binary output signals (graphed input statuses)

The binary output status signals of the differential protection function. Parts written in **bold** are seen on the function block in the logic editor.

| BINARY OUTPUT SIGNAL          | SIGNAL TITLE         | EXPLANATION  |
|-------------------------------|----------------------|--|
| CB1Pol_ <b>CmdOff</b> _Grl_   | Off Command          | Off command impulse, the duration of which is defined by the parameter "Pulse duration"  |
| CB1Pol_ <b>CmdOn</b> _Grl_    | On Command           | On command impulse, the duration of which is defined by the parameter "Pulse duration"   |
| CB1Pol_ <b>StartSW</b> _Grl_  | Start Synchro-switch | If the synchro check/synchro switch function is applied and the synchronous state conditions are not valid for the time defined by the parameter "Max.SynChk time", then this output triggers the synchro switch function (see synchro-check/synchro-switch function block description). |
| CB1Pol_ <b>Oper</b> _Grl_     | Operation            | An impulse with a duration of 150 ms at any operation of the circuit breaker   |
| CB1Pol_ <b>SelfOper</b> _Grl_ | Unintended Operation | This output is logic true if the status of the circuit breaker has changed without detected command from the SCADA system or on the input "ExtSwitch"  |
| CB1Pol_ <b>Closed</b> _Grl_   | Closed               | The filtered status signal for closed state of the circuit breaker   |
| CB1Pol_ <b>Opened</b> _Grl_   | Opened               | The filtered status signal for opened state of the circuit breaker   |

Table 2-3 The binary output signals of the circuit breaker control function

### 3.2.3.3.2.3. On-line data

Visible values on the on-line data page:

| SIGNAL TITLE         | DIMENSION | EXPLANATION   |
|----------------------|-----------|---|
| Status               | -         | State of the CB (see Chapter 2.2.6)   |
| Off Command          | -         | Off command impulse, the duration of which is defined by the parameter "Pulse duration"   |
| On Command           | -         | On command impulse, the duration of which is defined by the parameter "Pulse duration"  |
| Operation            | -         | An impulse with a duration of 150 ms at any operation of the circuit breaker  |
| Unintended Operation | -         | This output is logic TRUE if the status of the circuit breaker has changed without detected command from the SCADA system or on the input "ExtSwitch" |
| Opened               | -         | The filtered status signal for opened state of the circuit breaker  |
| Closed               | -         | The filtered status signal for closed state of the circuit breaker  |
| Operation counter    | -         | Resettable* counter that increments every time the Operation (see above) output gets active   |

\*The operation counter can be reset on the device web page on-line menu.

Table 2-4 On-line data of the circuit breaker control function

### 3.2.3.3.2.4. Events

The following events are generated in the event list, as well as sent to SCADA according to the configuration.

| EVENT  | VALUE                   | EXPLANATION                                       |
|--------|-------------------------|---|
| Status | Intermediate,Off,On,Bad | CB state indication based on the received signals |

*Table 2-5 Event of the circuit breaker control function*

### 3.2.3.3.2.5. Commands

The following table contains the issuable commands of the function block. The name of the command channel is used while working in the EuroCAP configuration tool, whereas the title is seen by the user on the device web page.

| COMMAND CHANNEL  | TITLE     | RANGE  | EXPLANATION   |
|------------------|-----------|--------|---|
| CB1Pol_Oper_Con_ | Operation | Off,On | Issue open (off) or close (on) command on the corresponding outputs of the function block |

*Table 2-6 The command of the circuit breaker control function*

### 3.2.3.3.2.6. Indication of the four states (Intermediate, On, Off, Bad)

To generate an active scheme on the local LCD, there is an internal status variable indicating the state of the circuit breaker. Different graphic symbols can be assigned to the values, the function block's events are generated also according to this status variable.

This integer status has four values based on the states of the **stValOn** and **stValOff** inputs of the function block.

| INTEGER STATUS    | TITLE  | STVALON STATE | STVALOFF STATE | VALUE           | EXPLANATION  |
|-------------------|--------|---------------|----------------|-----------------|--|
| CB1Pol_stVal_ISt_ | Status | FALSE         | FALSE          | 0: Intermediate | Integer status signal for indicating the state of the CB according to the corresponding inputs of the function block |
|                   |        | FALSE         | TRUE           | 1: Off          |  |
|                   |        | TRUE          | FALSE          | 2: On           |  |
|                   |        | TRUE          | TRUE           | 3: Bad          |  |

*Table 2-7 State signals from the circuit breaker control function*



### 3.2.3.3.3. Technical data

| FUNCTION   | VALUE | ACCURACY |
|------------|-------|----------|
| Pulse time |       | < 3 ms   |

Table 2-8 The technical data of the circuit breaker control function

#### 3.2.3.3.3.1. Notes for testing

If the commands get blocked from time to time during commissioning, it is advised to check how the conditions are fulfilled to issue commands on the function block. The following **three** conditions must be fulfilled at the same time:

- Local or Remote input is active appropriately
- The enabling input (EnaOff or EnaOn) of the issued command (off or on) is active
- (close/on command only) Synchro-check is OK (SynOK input is active)

If there are no conditions to be defined for any of these three (e.g. there is no synchro-check function present, so no valid signal can be provided to that input), the corresponding input can be connected to constant logical TRUE signal provided by the fixture output of the Common function block.

#### 3.2.3.3.3.1.1. IEC 61850 commands

In several configurations the Interlocking and Control logical nodes may have the same prefix for CB and DC function blocks (**INTCILO#** and **SBwCSWI#** respectively where the '#' marks the instance number). This means that their instance number not necessarily corresponds to the actual function block:

- Example: if there are **2** DC and **1** CB function blocks in the same configuration where the former ones were added first, the instance number **#1** and **#2** will belong to the DC function blocks whereas number **#3** will belong to the CB function block even if it is the only CB control function in the device.
- Make sure to check which logical nodes belong to which function by checking the DOI description using the EuroCAP tool (right click the function block in the Logic editor)





Figure 2-2 Checking the description of the Interlocking LN of the function block

In other cases, the two prefixes are given according to the type of the function block, so they are individual for each (i.e. **CBCILO#** and **CBCSW#** for circuit breaker and **DCCILO#** and **DCCSW#** for disconnector).



## 3.2.4. Disconnecter control function

### 3.2.4.1. Application

The disconnecter control block can be used to integrate the disconnecter control of the EuroProt+ device into the station control system and to apply active scheme screens of the local LCD of the device.

#### 3.2.4.1.1. Mode of operation

The disconnecter control block receives remote commands from the SCADA system and local commands from the local LCD of the device, performs the prescribed checking and transmits the commands to the disconnecter. It processes the status signals received from the disconnecter and offers them to the status display of the local LCD and to the SCADA system.

Main features:

- Local (LCD of the device) and Remote (SCADA) operation modes can be enabled or disabled individually.
- Interlocking functions can be programmed by the user applying the inputs “EnaOff” and “EnaOn”, using the graphic equation editor.
- Programmed conditions can be used to temporarily disable the operation of the function block using the graphic equation editor.
- The function block supports the control models prescribed by the IEC 61850 standard.
- All necessary timing tasks are performed within the function block:
  - Time limitation to execute a command
  - Command pulse duration
  - Filtering the intermediate state of the disconnecter
  - Controlling the individual steps of the manual commands
- Sending open and close commands to the disconnecter
- Operation counter
- Event reporting

### 3.2.4.2. Disconnecter control function overview




Figure 2-1 Graphic appearance of the function block of the disconnecter control function

#### 3.2.4.2.1. Settings

##### 3.2.4.2.1.1. Parameters

| TITLE                 | DIM | RANGE  | STEP | DEFAULT       | EXPLANATION  |
|-----------------------|-----|--|------|---------------|--|
| Control Model         | -   | Direct normal, Direct enhanced, SBO enhanced                       | -    | Direct normal | The control model of the disconnecter node according to the IEC 61850 standard   |
| Type of Switch        | -   | N/A, Load Break, Disconnecter, Earthing Switch, HS Earthing Switch | -    | Disconnecter  |  |
| Forced Check          | -   | FALSE, TRUE  | -    | TRUE          | If true, then the check function cannot be neglected by the check attribute defined by the IEC 61850 standard  |
| Max Operating Time    | ms  | 10 – 60000   | 1    | 10000         | When either enhanced control model is selected, the status of the DC must change within this time after the issued command. At timeout an invalid-position error will be generated for the client. |
| Pulse Duration        | ms  | 100 – 60000  | 1    | 1000          | Duration of the generated On and Off impulse*  |
| Max Intermediate Time | ms  | 20 – 60000   | 1    | 10000         | Waiting time for status signals, at expiry the DC is reported to be in intermediate state  |
| SBO Timeout           | ms  | 1000 – 20000   | 1    | 5000          | Duration of the waiting time between object selection and command selection. At timeout no command is performed  |

\* If the input status signals (stValOff, stValOn) indicate the successful switching then the pulse is withdrawn, but the minimum duration is 1000 ms (factory setting).

Table 2-1 Parameters of the disconnecter control function

### 3.2.4.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.2.4.2.2.1. Binary input signals (graphed output statuses)

The conditions of the inputs are defined by the user, applying the graphic equation editor (logic editor). The part written in **bold** is seen on the function block in the logic editor.

| BINARY INPUT SIGNAL            | EXPLANATION  |
|--------------------------------|--|
| DisConn_ <b>Local</b> _GrO_    | If this input is active, the disconnector can be controlled using the local LCD of the device.   |
| DisConn_ <b>Remote</b> _GrO_   | If this input is active, the disconnector can be controlled via remote communication channels of the SCADA system or the device web page ('commands' menu)                     |
| DisConn_ <b>EnaOff</b> _GrO_   | The active state of this input enables the opening of the disconnector. The state is usually generated by the <i>interlocking conditions defined graphically by the user</i> . |
| DisConn_ <b>EnaOn</b> _GrO_    | The active state of this input enables the closing of the disconnector. The state is usually generated by the <i>interlocking conditions defined graphically by the user</i> . |
| DisConn_ <b>BlkProc</b> _GrO_  | The active state of this input blocks the operation of the disconnector. The conditions are defined graphically by the user.   |
| DisConn_ <b>stValOff</b> _GrO_ | Off (Opened) state of the disconnector.  |
| DisConn_ <b>stValOn</b> _GrO_  | On (Closed) state of the disconnector.   |

Table 2-2 The binary input signals of the disconnector control function

#### 3.2.4.2.2.2. Binary output signals (graphed input statuses)

The binary output status signals of the differential protection function. Parts written in **bold** are seen on the function block in the logic editor.

| BINARY OUTPUT SIGNAL         | SIGNAL TITLE | EXPLANATION   |
|------------------------------|--------------|---|
| DisConn_ <b>CmdOff</b> _Grl_ | Off Command  | Off command impulse, the duration of which is defined by the parameter "Pulse duration" |
| DisConn_ <b>CmdOn</b> _Grl_  | On Command   | On command impulse, the duration of which is defined by the parameter "Pulse duration"  |
| DisConn_ <b>Oper</b> _Grl_   | Operation    | An impulse with a duration of 150 ms at any operation of the disconnector               |
| DisConn_ <b>Closed</b> _Grl_ | Closed       | The filtered status signal for closed state of the disconnector                         |
| DisConn_ <b>Opened</b> _Grl_ | Opened       | The filtered status signal for opened state of the disconnector                         |

Table 2-3 The binary output signals of the disconnector control function

### 3.2.4.2.2.3. On-line data

Visible values on the on-line data page:

| SIGNAL TITLE      | DIMENSION | EXPLANATION   |
|-------------------|-----------|---|
| Status            | -         | State of the DC (see Chapter 2.2.6)   |
| Off Command       | -         | Off command impulse, the duration of which is defined by the parameter "Pulse duration"     |
| On Command        | -         | On command impulse, the duration of which is defined by the parameter "Pulse duration"      |
| Operation         | -         | An impulse with a duration of 150 ms at any operation of the disconnecter                   |
| Opened            | -         | The filtered status signal for opened state of the disconnecter                             |
| Closed            | -         | The filtered status signal for closed state of the disconnecter                             |
| Operation counter | -         | Resettable* counter that increments every time the Operation (see above) output gets active |

*Table 2-4 On-line data of the disconnecter control function*

\*The operation counter can be reset on the device web page on-line menu.

### 3.2.4.2.2.4. Events

The following events are generated in the event list, as well as sent to SCADA according to the configuration.

| EVENT  | VALUE                   | EXPLANATION  |
|--------|-------------------------|--|
| Status | Intermediate,Off,On,Bad | DC state indication based on the received status signals |

*Table 2-5 Event of the disconnecter control function*

### 3.2.4.2.2.5. Commands

The following table contains the issuable commands of the function block. The name of the command channel is used while working in the EuroCAP configuration tool, whereas the title is seen by the user on the device web page.

| COMMAND CHANNEL   | TITLE     | RANGE  | EXPLANATION   |
|-------------------|-----------|--------|---|
| DisConn_Oper_Con_ | Operation | Off,On | Issue open (off) or close (on) command on the corresponding outputs of the function block |

*Table 2-6 The command of the disconnecter control function*

### 3.2.4.2.2.6. Indication of the four states (Intermediate, On, Off, Bad)

To generate an active scheme on the local LCD, there is an internal status variable indicating the state of the disconnecter. Different graphic symbols can be assigned to the values, the function block's events are generated also according to this status variable.

This integer status has four values based on the states of the **stValOn** and **stValOff** inputs of the function block.

| INTEGER STATUS     | TITLE  | STVALON STATE | STVALOFF STATE | VALUE           | EXPLANATION  |
|--------------------|--------|---------------|----------------|-----------------|--|
| DisConn_stVal_ISt_ | Status | FALSE         | FALSE          | 0: Intermediate | Integer status signal for indicating the state of the DC according to the corresponding inputs of the function block |
|                    |        | FALSE         | TRUE           | 1: Off          |  |
|                    |        | TRUE          | FALSE          | 2: On           |  |
|                    |        | TRUE          | TRUE           | 3: Bad          |  |

Table 2-7 State signals from the disconnecter control function

### 3.2.4.2.3. Technical data

| FUNCTION     | VALUE | ACCURACY                            |
|--------------|-------|-------------------------------------|
| Operate time |       | ±5% or ±15 ms, whichever is greater |

Table 2-8 The technical data of the disconnecter control function

#### 3.2.4.2.3.1. Notes for testing

If the commands get blocked from time to time during commissioning, it is advised to check how the conditions are fulfilled to issue commands on the function block. The following **three** conditions must be fulfilled at the same time:


- Local or Remote input is active appropriately
- The enabling input (EnaOff or EnaOn) of the issued command (off or on) is active

If there are no conditions to be defined for any of these two (e.g. there is no difference made between local/remote control), the corresponding input can be connected to constant logical TRUE signal provided by the fixture output of the Common function block.

##### 3.2.4.2.3.1.1. IEC 61850 commands

In several configurations the Interlocking and Control logical nodes may have the same prefix for DC and CB function blocks (**INTCILO#** and **SBwCSWI#** respectively where the '#' marks the instance number). This means that their instance number not necessarily corresponds to the actual function block:

- Example: if there are **1** CB and **1** DC function blocks in the same configuration where the former was added first, the instance number **#1** will belong to the CB function block whereas number **#2** will belong to the DC function block even if it is the only DC control function in the device.
- Make sure to check which logical nodes belong to which function by checking the DOI description using the EuroCAP tool (right click the function block in the Logic editor)



*Figure 2-2 Checking the description of the Interlocking LN of the function block*

In other cases, the two prefixes are given according to the type of the function block, so they are individual for each (i.e. **DCCILO#** and **DCCSW#** for disconnecter and **CBCILO#** and **CBCSW#** for circuit breaker).

### 3.2.4.3. Example logic

A simple example can be seen below of how to insert the function block in the user logic using the EuroCAP Logic Editor:

- The Local/Remote state of the device is provided by the Common function block which is present in all configurations
- The connections to the BIn and BOut elements show the connections to the physical input and output contacts
- The highlighted signal leading to the EnaOff and EnaOn inputs is the realization of the interlocking logic. In this case the disconnecter can operate only if the circuit breaker is opened.

The opened state of the CB is now indicated by its filtered 'Opened' signal which is active only if the CB is open and there is no state error (or intermediate state) of it.





Figure 3-1 Inserting the disconnecter function block into the logic (example)





## 3.2.5. Ethernet Links function

### 3.2.5.1. Introduction

The EuroProt+ device constantly checks the statuses of its connections to the outside world (wherever possible). These statuses can be seen on the **status/log** page in the advanced menu on the web page of the device.

When further indications are needed or the signals of the statuses (such as events, logic signals for the user logic, LEDs etc.), the Ethernet Links function block makes these available for the user.

#### 3.2.5.1.1. Ports


The function can check the following types of communication ports:

- Fiber Optic (MM – multi mode)
- Fiber Optic (SM – single mode)
- RJ45
- PRP/HSR
- EOB (Ethernet On Board on the front HMI of the device)

See the EuroProt+ Hardware Description (different document) for the list of the CPU modules that contain any of these ports.

### 3.2.5.2. Ethernet Links function overview

The graphic appearance of the function block is shown on [Figure 2-1](#). These blocks show all binary input and output status signals, which are applicable in the graphic equation editor.



*Figure 2-1 Graphic appearance of the function block of the ethernet links function*

#### 3.2.5.2.1. Settings

There are no settings for this function block.

#### 3.2.5.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

This function block owns only binary output signals.

##### 3.2.5.2.2.1. Binary output signals (graphed input statuses)

The binary output status signals of the Ethernet Links function. **Parts written in bold** are seen on the function block in the logic editor.

| BINARY OUTPUT SIGNAL       | SIGNAL TITLE            | EXPLANATION  |
|----------------------------|-------------------------|--|
| EthLnk_ <b>SB1</b> _Grl_   | Station Bus1            | Active if the first (upper) fiber optic port of the CPU module has an active connection.   |
| EthLnk_ <b>SB2F</b> _Grl_  | Station Bus2 – Fiber    | Active if the second (middle) fiber optic port of the CPU module has an active connection. |
| EthLnk_ <b>SB2RJ</b> _Grl_ | Station Bus2 –RJ4       | Active if the RJ45 port of the CPU module has an active connection.                        |
| EthLnk_ <b>PB</b> _Grl_    | Process Bus             | Active if the third (lower) fiber optic port of the CPU module has an active connection    |
| EthLnk_ <b>Front</b> _Grl_ | RJ45/EOB on front panel | Active if the front RJ45 port (or EOB) has an active connection                            |

*Table 2-1 The binary output status signals of the ethernet links function*

### 3.2.5.2.2.2. On-line data

Visible values on the on-line data page:

| SIGNAL TITLE            | DIMENSION | EXPLANATION  |
|-------------------------|-----------|--|
| Station Bus1            | -         | Active if the first (upper) fiber optic port of the CPU module has an active connection.   |
| Station Bus2 – Fiber    | -         | Active if the second (middle) fiber optic port of the CPU module has an active connection. |
| Station Bus2 –RJ4       | -         | Active if the RJ45 port of the CPU module has an active connection.                        |
| Process Bus             | -         | Active if the third (lower) fiber optic port of the CPU module has an active connection    |
| RJ45/EOB on front panel | -         | Active if the front RJ45 port (or EOB) has an active connection                            |

*Table 2-2 The measured analogue values of the ethernet links function*

### 3.2.5.2.2.3. Events

The following events are generated in the event list, as well as sent to SCADA according to the configuration.

| EVENT                   | VALUE   | EXPLANATION  |
|-------------------------|---------|--|
| Station Bus1            | off, on | Active if the first (upper) fiber optic port of the CPU module has an active connection.   |
| Station Bus2 – Fiber    | off, on | Active if the second (middle) fiber optic port of the CPU module has an active connection. |
| Station Bus2 –RJ4       | off, on | Active if the RJ45 port of the CPU module has an active connection.                        |
| Process Bus             | off, on | Active if the third (lower) fiber optic port of the CPU module has an active connection    |
| RJ45/EOB on front panel | off, on | Active if the front RJ45 port (or EOB) has an active connection                            |

*Table 2-3 Events of the ethernet links function*

### 3.2.5.2.3. Technical data

There is no technical data to add.

## 3.2.6. Trip Circuit Supervision

### 3.2.6.1. Introduction

This document describes the applicable hardware and provides guidelines for usage in the device configuration.

#### 3.2.6.1.1. Operation principle

The trip circuit supervision is utilized for checking the integrity of the circuit between the trip coil and the tripping output of the protection device.

This is realized by injecting a small DC current (around 1-5 mA) into the trip circuit. If the circuit is intact, the current flows, causing an active signal to the opto coupler input of the trip contact.

The state of the input is shown on the devices' binary input listing among the other binary inputs, and it can be handled like any other of them (it can be added to the user logic, etc.)

#### 3.2.6.1.2. Applicable modules

The following modules contain trip outputs with trip circuit supervision. The information here is restricted to the trip circuit supervision only. For more details please refer to the EuroProt+ Hardware description from which these were extracted. Note that there are other modules without trip circuit supervision, those are not listed here.

Table 1-1 Modules with Trip Circuit Supervision

| MODULE TYPE               | TRIP+4201           | TRIP+2101 | TRIP+2201 | PSTP+4201                       | PSTP+2101             |
|---------------------------|---------------------|-----------|-----------|---------------------------------|-----------------------|
| CHANNEL NUMBER            | 4                   | 4         | 4         | 2                               | 2                     |
| RATED VOLTAGE             | 24 V DC and 48 V DC | 110 V DC  | 220 V DC  | 24 V DC and 48 V DC and 60 V DC | 110 V DC and 220 V DC |
| THERMAL WITHSTAND VOLTAGE | 72 V DC             | 150 V DC  | 242 V DC  | 72 V DC                         | 242 V DC              |




Figure 1-1 I/O arrangement of the modules with TCS

## 3.2.6.2. Hardware application

### 3.2.6.2.1. Wiring

The wiring of these modules can be 2-wire or 3-wire. The TCS – Trip Circuit Supervision function is active with both methods.



The voltage of the "No" contact is maximized at 15 V by a Zener-diode. Make sure that the voltage caused by the resistance of the circuit breaker and the injected current from the TRIP+ module does not reach 10 V. In case of PSTP+ modules, this voltage is 8 V (PSTP+/4201) and 13 V (PSTP+/2101).



Our TRIP+ modules are made to switch DC circuits. **Using reversed polarity or AC voltage can cause the damage of the internal circuits.**

#### 3.2.6.2.1.1. 3-wire TRIP+ wiring methods




Figure 2-1 3-wire TRIP+ wiring

It is possible to use parallel connected TRIP+ modules. In this case the negative contacts must be common.




Figure 2-2 3-wire TRIP+ wiring using parallel connected TRIP+ modules

### 3.2.6.2.1.2. 2-wire TRIP+ wiring methods

If it is necessary, you can also wire the TRIP+ modules using only the “+” and the “No” contacts.




Figure 2-3 2-wire TRIP+ wiring

It is possible to use parallel connected TRIP+ modules.




Figure 2-4 2-wire TRIP+ wiring using parallel connected TRIP+ modules

If the circuit breaker needs two-pole switching, TRIP+ modules can be connected series as you can see in [Figure 2-5](#).




Figure 2-5 2-wire TRIP+ wiring using series connected TRIP+ modules

### 3.2.6.2.2. TCS signal handling

The Trip Circuit Supervision detects broken trip circuit if the current flowing through the trip coil is below 1 mA or (in case of 3-wire wirings) the voltage on it is above 8-10-13 V (depending on the module).

In Chapter [2.3](#) there are calculated maximum values for the resistance of the trip coil. If these values are exceeded, the TCS might consider the trip circuit broken even if it is intact.

To solve this, there are two ways:

- Using the 2-wire wiring method\***: leaving out/disconnecting the DC- part of the TRIP wiring may solve the issue.  
Note that in this case the voltage is not maximized on 15 V, so **the used voltage (up to 220 Vdc) will appear on the “NO” pin**. Caution is advised when touching the wiring in this case.
- Usage of modules without TCS**: if the TCS is not a requirement (e.g. in backup protections), it can be simply left out by opting for the appropriate modules (such as PSTP+/2131 or TRIP+/21F1) while ordering.

*\*The inputs of some relay testers might sense the states of the Trip contacts active even if they are not. In such cases the “-” pin must be wired in for the tests.*







### 3.2.6.3. Software application

#### 3.2.6.3.1. Binary inputs



The **TCS input is active if the trip circuit is intact**, so the logical '0' or FALSE signal of the input means that either the trip circuit is broken, or it connects to high resistance.

The TCS signals are shown the same way as other binary inputs are in the device: they can be seen in the **on-line data** menu on the local HMI or the device web page, and they can be utilized just like any other binary input when editing the device configuration with EuroCAP software.

The names/titles of the inputs follow the occupied slot of the TRIP module (if it is in Slot **N**, the TCS contact is named Bln\_#N##).

#### 3.2.6.3.2. The TCS macro

In most cases the trip circuit is tripped along with the circuit breaker as well. In situations like this the TCS input would signal a broken trip circuit (logical '0' or FALSE) unnecessarily. To avoid this, the status signals of the CB are to be used combined with the TCS input signal so that it will be evaluated only when the CB is closed.

The TCS macro incorporates this logic for two separate TCS inputs for one CB (see [Figure 3-2](#) for the two TCS inputs and the CB status signal inputs). The outputs are the failure signals for each connected TCS input.




Figure 3-1 Graphic appearance of the Trip Circuit Supervision macro



The internal logic of the macro can be seen on [Figure 3-2](#) below. Both outputs have a fixed pick delay of 1000 ms. Note that **here the outputs are active if the trip circuit is broken**. For a CB with only 1 trip circuit it is enough to simply leave the **TCS2** input open (naturally in this case the TC\_Failure2 output cannot be used).




Figure 3-2 Internal logic of the Trip Circuit Supervision macro



### 3.2.6.3.2.1. Binary input signals

The following table explains the binary input signals of the macro.

*Table 3-1 Binary input signals of the Trip Circuit Supervision macro*

| BINARY INPUT SIGNAL | EXPLANATION                              |
|---------------------|--|
| <b>TCS1</b>         | Connect here the first TCS binary input  |
| <b>TCS2</b>         | Connect here the second TCS binary input |
| <b>stValOff</b>     | CB Off/Open signal                       |
| <b>stValOn</b>      | CB On/Closed signal                      |


### 3.2.6.3.2.2. Binary output signals

The following table explains the binary output signals of the macro.

*Table 3-2 Binary output signals of the Trip Circuit Supervision macro*

| BINARY OUTPUT SIGNAL | EXPLANATION                   |
|----------------------|-------------------------------|
| <b>TC_Failure1</b>   | Failure on the first circuit  |
| <b>TC_Failure2</b>   | Failure on the second circuit |

Note that these are the outputs of a macro, and not a function block, so they must be connected to a physical or a logical output (ConnOut, create status) to make them usable in other parts of the configuration. For further information please refer to the EuroCAP software description.



## 3.2.7. Dead Line Detection Function

### 3.2.7.1. Application

The “Dead Line Detection” (DLD) function generates a signal indicating the dead or live state of the line. Additional signals are generated to indicate if the phase voltages and phase currents are above the pre-defined limits.

#### 3.2.7.1.1. Mode of Operation

The task of the “Dead Line Detection” (DLD) function is to decide the Dead line/Live line state.

Criteria of “Dead line” state: all three phase voltages are below the voltage setting value AND all three currents are below the current setting value.

Criteria of “Live line” state: all three phase voltages are above the voltage setting value.

### 3.2.7.1.2. Structure of the Algorithm

Figure 1-1 shows the structure of the dead line detection algorithm.




Figure 1-1 Structure of the dead line detection algorithm

For the preparation phase:

The **inputs** are

- the sampled values of the three phase voltages (UL1, UL2, UL3) and three phase currents (IL1, IL2, IL3),
- parameters.

The **outputs** are

- the fundamental Fourier components of the three phase voltages (UL1, UL2, UL3) and three phase currents (IL1, IL2, IL3).

For the DLD function:

The **inputs** are

- the fundamental Fourier components of the three phase voltages (UL1, UL2, UL3) and three phase currents (IL1, IL2, IL3),
- parameters,
- status signals.

The **software modules** of the dead line detection function are:

#### **Fourier calculations**

These modules calculate the basic Fourier components of the phase currents and phase voltages individually. These modules belong to the preparation phase.

#### **Dead Line Detection**

This module decides if the “Live line condition” (Line\_OK) or the “DeadLine condition” is fulfilled.

#### **Decision logic**

The decision logic module combines the status signals to generate the outputs of the function.

The following description explains the details of the individual components.

### 3.2.7.1.3. The Fourier Calculation (Fourier)

These modules calculate the basic Fourier current components of the phase voltages and phase currents individually. These modules belong to the preparation phase.




Figure 1-2 Principal scheme of the Fourier calculation

The **inputs** are the sampled values of:

- the three phase voltages (UL1, UL2, UL3)
- the three phase currents (IL1, IL2, IL3)

The **outputs** are:

- the basic Fourier components of the analyzed voltages (UL1Four, UL2Four, UL3Four),
- the basic Fourier components of the analyzed currents (IL1Four, IL2Four, IL3Four).

### 3.2.7.1.4. The Dead Line Detection Algorithm (Dead Line Detection)

This module decides if the “Live line condition” (Line\_OK) or the “DeadLine condition” is fulfilled.


The **inputs** are

- the basic Fourier components of the phase voltages (UL1Four, UL2Four, UL3Four),
- the basic Fourier components of the phase currents (IL1Four, IL2Four, IL3Four),
- status signals,
- parameters.


The **outputs** are the internal status signals of the function. These indicate the “DeadLine condition” or the “Live line condition” (Line\_OK) state.

Criteria of “Dead line” state: all three phase voltages are below the voltage setting value AND all three currents are below the current setting value.

Criteria of “Live line” state: all three phase voltages are above the voltage setting value.



*Figure 1-3 Principal scheme of the dead line detection function*



## Enumerated parameters

*Table 1-1 The enumerated parameters of the dead line detection function*

| TITLE     | DIM | RANGE   | STEP | DEFAULT | EXPLANATION                         |
|-----------|-----|---------|------|---------|-------------------------------------|
| Operation | -   | Off, On | -    | Off     | Parameter for enabling the function |

## Integer parameters

*Table 1-2 The integer parameters of the dead line detection function*

| TITLE               | DIM | RANGE    | STEP | DEFAULT | EXPLANATION                                     |
|---------------------|-----|----------|------|---------|---|
| Min Operate Voltage | %   | 10 – 100 | 1    | 60      | Voltage setting for “Dead line” state criteria. |
| Min Operate Current | %   | 2 – 100  | 1    | 10      | Current setting for “Dead line” state criteria. |

## Binary status signals

The dead line detection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

*Table 1-3 The binary input signal of the dead line detection function*

| BINARY STATUS SIGNAL | SIGNAL TITLE | EXPLANATION                        |
|----------------------|--------------|------------------------------------|
| DLD_Blk_GrO_         | Block        | Input used to disable the function |

The **binary output status signals** of the residual dead line detection function are listed in [Table 1-4](#).

*Table 1-4 The binary output status signals of the dead line detection function*

| BINARY OUTPUT SIGNAL | SIGNAL TITLE | EXPLANATION  |
|----------------------|--------------|--|
| DLD_StUL1_GrI_       | Start UL1    | The voltage of phase L1 is above the setting limit |
| DLD_StUL2_GrI_       | Start UL2    | The voltage of phase L2 is above the setting limit |
| DLD_StUL3_GrI_       | Start UL3    | The voltage of phase L3 is above the setting limit |
| DLD_StIL1_GrI_       | Start IL1    | The current of phase L1 is above the setting limit |
| DLD_StIL2_GrI_       | Start IL2    | The current of phase L2 is above the setting limit |
| DLD_StIL3_GrI_       | Start IL3    | The current of phase L3 is above the setting limit |

### 3.2.7.1.5. The Decision Logic (Decision logic)

The decision logic module combines status signals, binary and enumerated parameters to generate the dead line or live line status signals.




Figure 1-4 The logic scheme of the decision logic

Table 1-5 The binary input status signal of the decision logic

| BINARY INPUT SIGNAL | SIGNAL TITLE | EXPLANATION  |
|---------------------|--------------|--|
| DLD_StUL1_Grl_      | Start UL1    | The voltage of phase L1 is above the setting limit |
| DLD_StUL2_Grl_      | Start UL2    | The voltage of phase L2 is above the setting limit |
| DLD_StUL3_Grl_      | Start UL3    | The voltage of phase L3 is above the setting limit |
| DLD_StIL1_Grl_      | Start IL1    | The current of phase L1 is above the setting limit |
| DLD_StIL2_Grl_      | Start IL2    | The current of phase L2 is above the setting limit |
| DLD_StIL3_Grl_      | Start IL3    | The current of phase L3 is above the setting limit |

#### Binary status signals

The function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

Table 1-6 The binary input signal of the dead line detection function

| BINARY STATUS SIGNAL | SIGNAL TITLE | EXPLANATION                      |
|----------------------|--------------|----------------------------------|
| DLD_Blk_GrO_         | Block        | Input for disabling the function |

Table 1-7 The binary output status signals of the dead line detection function

| BINARY OUTPUT SIGNAL | SIGNAL TITLE       | EXPLANATION  |
|----------------------|--------------------|--|
| DLD_DeadLine_Grl_    | DeadLine condition | The requirements of "DeadLine condition" are fulfilled           |
| DLD_LineOK_Grl_      | LineOK condition   | The requirements of "Live line condition" (LineOK) are fulfilled |



### 3.2.7.2. DeadLine Detection Function Overview

The graphic appearance of the dead line detection function block is shown in [Figure 2-1](#). This block shows all binary input and output status signals that are applicable in the graphic equation editor.




Figure 2-1 The function block of the residual instantaneous overcurrent protection

### 3.2.7.2.1. Settings

#### 3.2.7.2.1.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

Table 2-1 Parameters of the dead line detection function

| TITLE               | DIM | RANGE    | STEP | DEFAULT | EXPLANATION                                     |
|---------------------|-----|----------|------|---------|---|
| Operation           | -   | Off, On  | -    | Off     | Parameter for enabling the function             |
| Min Operate Voltage | %   | 10 – 100 | 1    | 60      | Voltage setting for “Dead line” state criteria. |
| Min Operate Current | %   | 2 – 100  | 1    | 10      | Current setting for “Dead line” state criteria. |



### 3.2.7.2.2. Function I/O

This section briefly describes the analogue and digital inputs and outputs of the function block.

#### 3.2.7.2.2.1. Analogue inputs

The analog inputs are the sampled values of the three phase voltages and the three phase currents.

#### 3.2.7.2.2.2. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side of the function block in the Logic editor.

*Table 2-2 The binary input signals of the dead line detection function*

| BINARY INPUT SIGNAL   | SIGNAL TITLE | EXPLANATION                      |
|-----------------------|--------------|----------------------------------|
| DLD_ <b>BIk</b> _GrO_ | Block        | Input for disabling the function |

#### 3.2.7.2.2.3. Binary output signals (graphed input statuses)

These signals can be used in EuroCAP to assign to LED, user LCD object etc. Parts written in **bold** are seen on the right side of the function block in the *Logic Editor*.

*Table 2-3 The binary output signals of the dead line detection function*


| BINARY OUTPUT SIGNAL       | SIGNAL TITLE       | EXPLANATION  |
|----------------------------|--------------------|--|
| DLD_ <b>StUL1</b> _GrI_    | Start UL1          | The voltage of phase L1 is above the setting limit               |
| DLD_ <b>StUL2</b> _GrI_    | Start UL2          | The voltage of phase L2 is above the setting limit               |
| DLD_ <b>StUL3</b> _GrI_    | Start UL3          | The voltage of phase L3 is above the setting limit               |
| DLD_ <b>StIL1</b> _GrI_    | Start IL1          | The current of phase L1 is above the setting limit               |
| DLD_ <b>StIL2</b> _GrI_    | Start IL2          | The current of phase L2 is above the setting limit               |
| DLD_ <b>StIL3</b> _GrI_    | Start IL3          | The current of phase L3 is above the setting limit               |
| DLD_ <b>DeadLine</b> _GrI_ | DeadLine condition | The requirements of "DeadLine condition" are fulfilled           |
| DLD_ <b>LineOK</b> _GrI_   | LineOK condition   | The requirements of "Live line condition" (LineOK) are fulfilled |

#### 3.2.7.2.2.4. Online data

The following values are visible in the *online data* page.

*Table 2-4 Online data of the dead line detection function*

| SIGNAL TITLE       | DIMENSION | EXPLANATION   |
|--------------------|-----------|---|
| DeadLine condition | -         | The requirements of "DeadLine condition" are fulfilled  |
| LineOK condition   | -         | The requirements of "Live line condition" are fulfilled |



### 3.2.7.2.2.5. Events

There are no events generated for this function block.


### 3.2.7.2.3. Technical Data

*Table 2-5 Technical data of the dead line detection function*

| FUNCTION        | VALUE   | ACCURACY |
|-----------------|---------|----------|
| Pick-up voltage |         | 1%       |
| Operation time  | < 20 ms |          |
| Reset ratio     | 0.95    |          |

### 3.2.7.2.4. Notes for Testing

This function does not generate events on its own. To create them, another function block, the GGIO16 custom event function block must be utilized, see its description for more information.



### 3.2.8. Voltage transformer supervision function

The voltage transformer supervision function generates a signal to indicate an error in the voltage transformer secondary circuit. This signal can serve, for example, as a warning, indicating disturbances in the measurement, or it can disable the operation of the distance protection function if appropriate measured voltage signals are not available for a distance decision.

The voltage transformer supervision function is designed to detect faulty asymmetrical states of the voltage transformer circuit caused, for example, by a broken conductor in the secondary circuit.

(Another method for detecting voltage disturbances is the supervision of the auxiliary contacts of the miniature circuit breakers in the voltage transformer secondary circuits. This function is not described here.)

The user has to generate graphic equations for the application of the signal of this voltage transformer supervision function.

This function is interconnected with the “dead line detection function”. Although the dead line detection function is described fully in a separate document, the explanation necessary to understand the operation of the VT supervision function is repeated also in this document.

#### 3.2.8.1. Mode of operation

##### 3.2.8.1.1. “Dead line detection” (DLD) function - modes of operation

The voltage transformer supervision function is based on the “Dead line detection” (DLD) function, the task of which is to decide the Dead line/Live line state.

Criteria of “Dead line” state: all three phase voltages are below the preset voltage value AND all three currents are below the preset current value.

Criteria of “Live line” state: all three phase voltages are above the preset voltage value.

The dead line detection function is described in a separate document.

##### 3.2.8.1.2. “Voltage transformer supervision” (VTS) function - modes of operation

The voltage transformer supervision function can be used in three different modes of application:

Zero sequence detection (for typical applications in systems with grounded neutral): “VT failure” signal is generated if the residual voltage ( $3U_0$ ) is above the preset voltage value AND the residual current ( $3I_0$ ) is below the preset current value.

Negative sequence detection (for typical applications in systems with isolated or resonant grounded (Petersen) neutral): “VT failure” signal is generated if the negative sequence voltage component ( $U_2$ ) is above the preset voltage value AND the negative sequence current component ( $I_2$ ) is below the preset current value.

Special application: “VT failure” signal is generated if the residual voltage ( $3U_0$ ) is above the preset voltage value AND the residual current ( $3I_0$ ) AND the negative sequence current component ( $I_2$ ) are below the preset current values.



### 3.2.8.1.3. Activating the VTS function

The voltage transformer supervision function can be activated if “Live line” status is detected for at least 200 ms. This delay avoids mal-operation at line energizing if the poles of the circuit breaker make contact with a time delay. The function is set to be inactive if “Dead line” status is detected.

If the conditions specified by the selected mode of operation are fulfilled (for at least 4 milliseconds) then the voltage transformer supervision function is activated and the operation signal is generated. (When evaluating this time delay, the natural operating time of the applied Fourier algorithm must also be considered.)

**NOTE:** For the operation of the voltage transformer supervision function the “Dead line detection function” must be operable as well: it must be enabled by binary parameter setting, and its blocking signal may not be active.

### 3.2.8.1.4. Resetting the VTS function

If, in the active state, the conditions for operation are no longer fulfilled, the resetting of the function depends on the mode of operation of the primary circuit:

- If the “Live line” state is valid, then the function resets after approx. 200 ms of time delay. (When evaluating this time delay, the natural operating time of the applied Fourier algorithm must also be considered.)
- If the “Dead line” state is started and the “VTS Failure” signal has been continuous for at least 100 ms, then the “VTS failure” signal does not reset; it is generated continuously even when the line is in a disconnected state. Thus, the “VTS Failure” signal remains active at reclosing.
- If the “Dead line” state is started and the “VTS Failure” signal has not been continuous for at least 100 ms, then the “VTS failure” signal resets.

### 3.2.8.2. Structure of the voltage transformer supervision algorithm

Fig.1-1 shows the structure of the voltage transformer supervision (VTS) algorithm.




Figure 1-1 Structure of the voltage transformer supervision algorithm

For the preparation phase:

The **inputs** are

- the sampled values of the three phase voltages (UL1, UL2, UL3) and three phase currents (IL1, IL2, IL3),
- parameters.

The **outputs** are

- negative and zero sequence voltage and current components.
- signals indicating the “Live line” or “Dead line” condition.

For the VTS function:

The **inputs** are

- negative and zero sequence voltage and current components.
- signals indicating the “Live line” or “Dead line” condition,
- parameters,
- status signals.

The **outputs** are

- the binary output status signal indicating a failure of the voltage transformer secondary circuit,
- signals indicating the “Live line” or “Dead line” condition.



The **software modules** of the voltage transformer supervision function and those of the preparation phase:

#### **Fourier calculations**

These modules calculate the basic Fourier current components of the phase voltages and currents. These modules belong to the preparation phase.

#### **Negative sequence**

This module calculates the basic Fourier current components of the negative sequence voltage and current, based on the Fourier components of the phase voltages and currents. This module belongs to the preparation phase.

#### **Zero sequence**

This module calculates the basic Fourier voltage and current components of the residual voltage ( $3U_0$ ) and current ( $3I_0$ ), based on the Fourier components of the phase voltages and currents. This module belongs to the preparation phase.

#### **Dead Line Detection**

This module decides if the "Line\_OK condition" or the "DeadLine condition" is fulfilled. This module belongs to the preparation phase.

#### **VTS algorithm**

This module decides if the "VTS\_FAIL" conditions are fulfilled according to the conditions specified for the selected mode.


#### **Decision logic**

The decision logic module combines the status signals to generate the trip command of the function.

The following description explains the details of the individual components.

### 3.2.8.3. The Fourier calculation (Fourier)

These modules calculate the basic Fourier current components of the phase voltages and phase currents individually. These modules belong to the preparation phase.



*Figure 1-2 Principal scheme of the Fourier calculation*

The **inputs** are the sampled values of:

- the three phase voltages (UL1, UL2, UL3)
- the three phase currents (IL1, IL2, IL3)

The **outputs** are

- the basic Fourier components of the analyzed voltages (UL1Four, UL2Four, UL3Four),
- the basic Fourier components of the analyzed currents (IL1Four, IL2Four, IL3Four).



### 3.2.8.4. The negative phase sequenc calculation (Negative sequence)

This module calculates the negative phase sequence components based on the Fourier components of the phase voltages and phase currents. These modules belong to the preparation phase.

The **inputs** are the basic Fourier components of the phase voltages and phase currents (UL1Four, UL2Four, UL3Four, IL1Four, IL2Four, IL3Four).

The **outputs** are

- the basic Fourier components of the negative sequence voltage component (UNegFour),
- the basic Fourier components of the negative sequence current component (INegFour).




Figure 1-3 Schema of the negative sequence component calculation

### 3.2.8.5. The residual voltage and current calculation (Zero sequence)


This module calculates the residual voltage ( $U_{ZerFour}$ ) and current ( $I_{ZerFour}$ ) based on the Fourier components of the phase voltages and currents. These modules belong to the preparation phase.

The **inputs** are

- the basic Fourier components of the phase voltages ( $UL1Four$ ,  $UL2Four$ ,  $UL3Four$ ),
- the basic Fourier components of the phase currents ( $IL1Four$ ,  $IL2Four$ ,  $IL3Four$ ).

The **outputs** are

- the basic Fourier components of the residual voltage ( $U_{ZerFour}$ ),
- the basic Fourier components of the residual current ( $I_{ZerFour}$ ).



*Figure 1-4 Schema of the residual voltage and current calculation*

### 3.2.8.6. The dead line detection algorithm (Dead Line Detection)

This module decides if the “Line\_OK condition” or the “DeadLine condition” is fulfilled. This module belongs to the preparation phase.

The **inputs** are

- the basic Fourier components of the phase voltages (UL1Four, UL2Four, UL3Four),
- the basic Fourier components of the phase currents (IL1Four, IL2Four, IL3Four),
- parameters.

The **outputs** are the internal status signals of the function. These indicate the “DeadLine condition state” or the “Line\_OK conditions” state. This module belongs to the preparation phase.

Criteria of “Dead line” state: all three phase voltages are below the voltage setting value AND all three currents are below the current setting value.

Criteria of “Live line” state: all three phase voltages are above the voltage setting value.




Figure 1-5 Principal scheme of the dead line detection function

The parameters of the dead line detection function are listed in [Table 1-1](#).

#### Integer parameters

| Parameter name   | Title               | Unit | Min | Max | Step | Default |
|--|---------------------|------|-----|-----|------|---------|
| Integer parameters of the dead line detection function |                     |      |     |     |      |         |
| DLD_ULev_IPar_   | Min Operate Voltage | %    | 10  | 100 | 1    | 60      |
| DLD_ILev_IPar_   | Min Operate Current | %    | 2   | 100 | 1    | 10      |

Table 1-1 The integer parameters of the dead line detection function



### Binary status signals

The dead line detection function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Explanation  |
|----------------------|--|
| DLD_Blk_GrO_         | Output status of a graphic equation defined by the user to disable the dead line detection function. |

*Table 1-2 The binary input signal of the dead line detection function*

The **binary output status signals** of the dead line detection function are listed in Table 1-3.

| Binary output signals | Signal title       | Explanation   |
|-----------------------|--------------------|---|
| DLD_StUL1_GrI_        | Start UL1          | The voltage of phase L1 is above the preset parameter value |
| DLD_StUL2_GrI_        | Start UL2          | The voltage of phase L2 is above the preset parameter value |
| DLD_StUL3_GrI_        | Start UL3          | The voltage of phase L3 is above the preset parameter value |
| DLD_StIL1_GrI_        | Start IL1          | The current of phase L1 is above the preset parameter value |
| DLD_StIL2_GrI_        | Start IL2          | The current of phase L2 is above the preset parameter value |
| DLD_StIL3_GrI_        | Start IL3          | The current of phase L3 is above the preset parameter value |
| DLD_DeadLine_GrI_     | DeadLine condition | The criteria for dead line condition are fulfilled          |
| DLD_LineOK_GrI_       | LineOK condition   | The criteria for line OK condition are fulfilled            |

*Table 1-3 The binary output status signals of the dead line detection function*



### 3.2.8.7. Voltage transformer supervision (VTS algorithm)

The voltage transformer supervision function can be used in three different modes of operation:

Zero sequence detection (for typical applications in systems with grounded neutral): “VT failure” signal is generated if the residual voltage ( $3U_0$ ) is above the preset voltage value AND the residual current ( $3I_0$ ) is below the preset current value.

Negative sequence detection (for typical applications in systems with isolated or resonant grounded (Petersen) neutral): “VT failure” signal is generated if the negative sequence voltage component ( $U_2$ ) is above the preset voltage value AND the negative sequence current component ( $I_2$ ) is below the preset current value.

Special application: “VT failure” signal is generated if the residual voltage ( $3U_0$ ) is above the preset voltage value AND the residual current ( $3I_0$ ) AND the negative sequence current component ( $I_2$ ) are below the preset current values.

The task of this module is to detect if the conditions of the “VTS FAIL” state are fulfilled, according to the conditions defined for the selected mode of operation.

The **inputs** are

- the basic Fourier components of the residual voltage ( $UZerFour$ ) and current ( $IZerFour$ ),
- the negative sequence components of the voltage ( $UNegFour$ ) and current ( $INegFour$ ),
- binary signals from the dead line detection function,
- parameters.


**NOTE:** For the operation of the voltage transformer supervision function the “Dead line detection function” must be operable as well: it must be enabled by binary parameter setting, and its blocking signal may not be active.

The **output** is the internal status signal of the function. This internal signal indicates if the “VTS\_FAIL\_int” condition is fulfilled.

| Binary output signals | Signal title | Explanation   |
|-----------------------|--------------|---|
| VTS_FAIL_int          | VTS_FAIL_int | Internal status signal indicating the fulfillment of conditions. This status signal is not available for the users. |

*Table 1-4 The binary internal status signals of the voltage transformer supervision algorithm*

The parameters of the voltage transformer supervision algorithm are listed in [Table 1-5](#) and in [Table 1-6](#).



### Enumerated parameter

| Parameter name               | Title     | Selection range                           | Default       |
|------------------------------|-----------|---|---------------|
| Parameter for type selection |           |   |               |
| VTS_Oper_EPar_               | Operation | Off, Zero sequence, Neg sequence, Special | Zero sequence |

*Table 1-5 The enumerated parameters of the voltage transformer supervision function*

### Integer parameters

| Parameter name   | Title      | Unit | Min | Max | Step | Default |
|--|------------|------|-----|-----|------|---------|
| Starting voltage and current parameter for residual and negative sequence detection: |            |      |     |     |      |         |
| VTS_Uo_IPar_   | Start URes | %    | 5   | 50  | 1    | 30      |
| VTS_Io_IPar_   | Start IRes | %    | 10  | 50  | 1    | 10      |
| VTS_Uneg_IPar_   | Start UNeg | %    | 5   | 50  | 1    | 10      |
| VTS_Ineg_IPar_   | Start INeg | %    | 10  | 50  | 1    | 10      |

*Table 1-6 The integer parameters of the voltage transformer supervision algorithm*

### 3.2.8.8. The decision logic (Decision logic)

The decision logic module combines the status signals, binary and enumerated parameters to generate the trip command of the function.




Figure 1-6 The logic scheme of the decision logic

| Binary input signals | Signal title | Explanation   |
|----------------------|--------------|---|
| DLD_StUL1_Grl_       | Start UL1    | The voltage of phase L1 is above the preset parameter value   |
| DLD_StUL2_Grl_       | Start UL2    | The voltage of phase L2 is above the preset parameter value   |
| DLD_StUL3_Grl_       | Start UL3    | The voltage of phase L3 is above the preset parameter value   |
| DLD_StIL1_Grl_       | Start IL1    | The current of phase L1 is above the preset parameter value   |
| DLD_StIL2_Grl_       | Start IL2    | The current of phase L2 is above the preset parameter value   |
| DLD_StIL3_Grl_       | Start IL3    | The current of phase L3 is above the preset parameter value   |
| VTS_FAIL_int         | VTS_FAIL_int | Internal status signal indicating the fulfillment of conditions. This status signal is not available for the users. |

Table 1-7 The binary input signals of the decision logic

### Binary status signals

The voltage transformer supervision function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Explanation  |
|----------------------|--|
| VTS_BlK_GrO_         | Output status of a graphic equation defined by the user to disable the voltage transformer supervision function. |

Table 1-8 The binary input signal of the decision logic

| Binary output signals | Signal title       | Explanation  |
|-----------------------|--------------------|--|
| DLD_DeadLine_Grl_     | DeadLine condition | The requirements of “DeadLine condition” are fulfilled |
| DLD_LineOK_Grl_       | LineOK condition   | The requirements of “LineOK condition” are fulfilled   |
| VTS_Fail_Grl          | VT Failure         | Failure status signal of the VTS function              |

Table 1-9 The binary output status signals of the decision logic

### 3.2.8.9. Technical summary

#### 3.2.8.9.1. Technical data

| Function  | Value | Accuracy   |
|---|-------|------------|
| Pick-up voltage<br>I <sub>0</sub> =0A<br>I <sub>2</sub> =0A |       | <1%<br><1% |
| Operation time  | <20ms |            |
| Reset ratio   | 0.95  |            |

Table 1-10 Technical data of the voltage transformer supervision function

#### 3.2.8.9.2. The parameters

##### Integer parameters

| Parameter name   | Title               | Unit | Min | Max | Step | Default |
|--|---------------------|------|-----|-----|------|---------|
| Integer parameters of the dead line detection function                               |                     |      |     |     |      |         |
| DLD_ULev_IPar_   | Min Operate Voltage | %    | 10  | 100 | 1    | 60      |
| DLD_ILev_IPar_   | Min Operate Current | %    | 2   | 100 | 1    | 10      |
| Starting voltage and current parameter for residual and negative sequence detection: |                     |      |     |     |      |         |
| VTS_Uo_IPar_   | Start URes          | %    | 5   | 50  | 1    | 30      |
| VTS_Io_IPar_   | Start IRes          | %    | 10  | 50  | 1    | 10      |
| VTS_Uneg_IPar_   | Start UNeg          | %    | 5   | 50  | 1    | 10      |
| VTS_Ineg_IPar_   | Start INeg          | %    | 10  | 50  | 1    | 10      |

Table 1-11 The integer parameters of the voltage transformer supervision function

##### Enumerated parameter

| Parameter name               | Title     | Selection range                            | Default       |
|------------------------------|-----------|--|---------------|
| Parameter for type selection |           |  |               |
| VTS_Oper_EPar_               | Operation | Off, Zero sequence, Neg. sequence, Special | Zero sequence |

Table 1-12 The enumerated parameter of the voltage transformer supervision function



### 3.2.8.9.3. The binary input status signals

#### Binary status signals

The voltage transformer supervision function has a binary input signal, which serves the purpose of disabling the function. **The conditions of disabling are defined by the user, applying the graphic equation editor.**

| Binary status signal | Explanation  |
|----------------------|--|
| VTS_BlK_GrO_         | Output status of a graphic equation defined by the user to disable the voltage transformer supervision function. |

Table 1-13 The binary input signal of the voltage transformer supervision function

### 3.2.8.9.4. Binary output status signals


The **binary output status signals** of the voltage transformer supervision function are listed in Table 1-14.

| Binary output signals | Signal title       | Explanation   |
|-----------------------|--------------------|---|
| DLD function          |                    |   |
| DLD_StUL1_Grl_        | Start UL1          | The voltage of phase L1 is above the preset parameter value, signal of the DLD function |
| DLD_StUL2_Grl_        | Start UL2          | The voltage of phase L2 is above the preset parameter value, signal of the DLD function |
| DLD_StUL3_Grl_        | Start UL3          | The voltage of phase L3 is above the preset parameter value, signal of the DLD function |
| DLD_StIL1_Grl_        | Start IL1          | The current of phase L1 is above the preset parameter value, signal of the DLD function |
| DLD_StIL2_Grl_        | Start IL2          | The current of phase L2 is above the preset parameter value, signal of the DLD function |
| DLD_StIL3_Grl_        | Start IL3          | The current of phase L3 is above the preset parameter value, signal of the DLD function |
| DLD_DeadLine_Grl_     | DeadLine condition | The requirements of "DeadLine condition" are fulfilled, signal of the DLD function      |
| DLD_LineOK_Grl_       | LineOK condition   | The requirements of "LineOK condition" are fulfilled, signal of the DLD function        |
| VTS function          |                    |   |
| VTS_Fail_Grl          | VT Failure         | Failure status signal of the VTS function   |

Table 1-14 The binary output signals of the voltage transformer supervision function

### 3.2.8.9.5. The function block

The function block of the dead line detection and voltage transformer supervision function is shown in Figure 1-7. This block shows all binary input and output status signals that are applicable in the graphic equation editor.



*Figure 1-7 The function block of the dead line detection and voltage transformer supervision function*

## 3.2.9. Current unbalance function

### 3.2.9.1. Application

The current unbalance protection function can be applied to detect unexpected asymmetry in current measurement.

#### 3.2.9.1.1. Mode of operation

The applied method selects maximum and minimum phase currents (RMS values of the fundamental Fourier components). If the difference between them is above the setting limit, the function generates a start signal. It is a necessary precondition of start signal generation that the maximum of the currents be above 10 % of the rated current and below 150% of the rated current.

The function can be disabled by parameter setting, and by an input signal programmed by the user with the graphic programming tool.

The trip command is generated after the defined time delay if trip command is enabled by parameter setting.

#### 3.2.9.1.2. Operation principles

Figure 1-1 shows the structure of the current unbalance protection algorithm.




Figure 1-1 Structure of the current unbalance protection algorithm

The **inputs** of the preparatory phase are

- the three phase currents,

The **outputs** of the preparatory phase are

- the RMS values of the fundamental Fourier component of three phase currents.

The **inputs** of the current unbalance function are

- the RMS values of the fundamental Fourier component of three phase currents,
- parameters,
- status signals.

The **outputs** are

- the binary output status signals.

The **software modules** of the current unbalance function:

**Fourier calculations**

These modules calculate the RMS values of the basic Fourier current components of the phase currents individually (not part of the VCB60 function).

**Analogue signal processing**

This module processes the RMS values of the Fourier components of the phase currents to prepare the signals for the decision.


**Decision logic**

The decision logic module combines the status signals to generate the starting signal and the trip command of the function.

The following description explains the details of the individual components.

**3.2.9.1.3. The Fourier calculation (Fourier)**

These modules calculate the RMS values of the fundamental Fourier components of the phase currents individually. They are not part of the VCB60 function; they belong to the preparatory phase.



*Figure 1-2 Principal scheme of the Fourier calculation*

The **inputs** are the sampled values of the three phase currents (IL1, IL2, IL3)

The **outputs** are the RMS values of the fundamental Fourier components of the phase currents (IL1Four, IL2Four, IL3Four).

### 3.2.9.1.4. The Analogue signal processing

This module processes the Fourier components of the phase currents to prepare the signals for the decision.




Figure 1-3 Principal scheme of the analogue signal processing

The **inputs** are the fundamental Fourier components of the analyzed currents (IL1Four, IL2Four, IL3Four)

The **outputs** are internal binary signals:

- $\Delta I >$  The difference between the maximum and minimum of the RMS values of the fundamental Fourier components of the phase currents as a percentage of the maximum of these values is above the limit defined by the preset parameter "Start current";
- $I_{max} > 0.1 I_n$  The maximum of the RMS values of the fundamental Fourier components of the phase currents is sufficient for evaluation;
- $I_{max} < 1.5 I_n$  The maximum of the RMS values of the fundamental Fourier components of the phase currents is not considered as a fault current.

### 3.2.9.1.5. The decision logic (Decision logic)

The decision logic module combines the status signals, binary and enumerated parameters to generate the trip command of the function.




Figure 1-4 The logic scheme of the current unbalance function

The **inputs** are internal binary signals:

- $\Delta I >$  the difference between the maximum and minimum of the RMS values of the fundamental Fourier components of the phase currents as a percentage of the maximum of these values is above the limit defined by parameter setting "Start Current Diff";
- $I_{max} > 0.1 I_n$  the maximum of the RMS values of the fundamental Fourier components of the phase currents is sufficient for evaluation;
- $I_{max} < 1.5 I_n$  the maximum of the RMS values of the fundamental Fourier components of the phase currents is not considered as a fault current.

### 3.2.9.2. Current unbalance protection function overview

The graphic appearance of the function block of the current unbalance protection function is shown below. The block shows all binary input and output status signals which are applicable in the graphic equation editor.




Figure 2-1 Graphic appearance of the function block of the current unbalance protection function



### 3.2.9.2.1. Settings

#### 3.2.9.2.1.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

*Table 2-1 Parameters of the current unbalance protection function*

| TITLE             | DIM  | RANGE       | STEP | DEFAULT | EXPLANATION   |
|-------------------|------|-------------|------|---------|---|
| Operation         | -    | Off, On     | -    | Off     | Enabling the function   |
| Start Signal Only | -    | FALSE, TRUE | -    | FALSE   | When checked, the function provides start signal only, and no trip signal.      |
| Start Current     | %    | 10 – 90     | 1    | 50      | Phase difference current setting  |
| Time Delay        | msec | 100 – 60000 | 1    | 1000    | Time delay (including the algorithm time, see Chapter 2.4 for more explanation) |

#### 3.2.9.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

##### 3.2.9.2.2.1. Analogue inputs

The function uses the sampled values of a current input. This is defined in the configuration.

##### 3.2.9.2.2.2. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the Logic editor.

*Table 2-2 The binary input signal of the current unbalance protection function*

| BINARY OUTPUT SIGNAL    | EXPLANATION                    |
|-------------------------|--------------------------------|
| VCB60_ <b>Blk</b> _GrO_ | Blocking input of the function |

##### 3.2.9.2.2.3. Binary output signals (graphed input statuses)

These signals can be used in EuroCAP to assign to LED, user LCD object etc. Parts written in **bold** are seen on the right side of the function block in the *Logic Editor*.

*Table 2-3 The binary output signals of the current unbalance protection function*

| BINARY OUTPUT SIGNAL      | SIGNAL TITLE  | EXPLANATION                          |
|---------------------------|---------------|--------------------------------------|
| VCB60_ <b>GenSt</b> _Grl_ | General Start | General start signal of the function |
| VCB60_ <b>GenTr</b> _Grl_ | General Trip  | General trip command of the function |

##### 3.2.9.2.2.4. Online data

Visible values on the *online data* page.

*Table 2-4 Online displayed data of the current unbalance protection function*

| SIGNAL TITLE  | DIMENSION | EXPLANATION                          |
|---------------|-----------|--------------------------------------|
| General Start | -         | General start signal of the function |
| General Trip  | -         | General trip command of the function |







| <i>Synchrocheck function (SYN25)</i>   |   |
|--|---|
| Voltage Diff   | Voltage different value   |
| Frequency Diff   | Frequency different value   |
| Angle Diff   | Angle different value   |
| <i>Line measurement (MXU_L) (here the displayed information means primary value)</i> |   |
| Active Power – P   | Three-phase active power  |
| Reactive Power – Q   | Three-phase reactive power  |
| Apparent Power – S   | Three-phase power based on true RMS voltage and current measurement |
| Current L1   | True RMS value of the current in phase L1                           |
| Current L2   | True RMS value of the current in phase L2                           |
| Current L3   | True RMS value of the current in phase L3                           |
| Voltage L1   | True RMS value of the voltage in phase L1                           |
| Voltage L2   | True RMS value of the voltage in phase L2                           |
| Voltage L3   | True RMS value of the voltage in phase L3                           |
| Voltage L12  | True RMS value of the voltage between phases L1 L2                  |
| Voltage L23  | True RMS value of the voltage between phases L2 L3                  |
| Voltage L31  | True RMS value of the voltage between phases L3 L1                  |
| Frequency  | Frequency   |
| <i>Metering (MTR)</i>  |   |
| Forward MWh  | Forward MWh   |
| Backward MWh   | Backward MWh  |
| Forward MVarh  | Forward MVarh   |
| Backward MVarh   | Backward MVarh  |
| <i>Line thermal protection (TTR49L)</i>  |   |
| Calc. Temperature  | Calculated line temperature   |

\* *The reference angle is the phase angle of “Voltage Ch - U1”*

*Table 3-146 Measured analog values*



### 3.3.1. Current input function

#### 3.3.1.1. Application of the current input function

The application of the current inputs depends on the correct connection of the hardware terminals and also on the correct parameter setting for the CT4 function block. This guide describes examples, based on which any other combinations can be realized.

In the applications of the current transformer hardware module, the first three current inputs (terminals 1-2, 3-4, 5-6) receive the three phase currents (IL1, IL2, IL3), the fourth input (terminals 7-8) is reserved for zero sequence current, for the zero sequence current of the parallel line or for any additional currents. Accordingly, the first three inputs have common parameters while the fourth current input needs individual setting.

The CT4 function block is an independent module in the sense that:

- It has independent parameters to be set, associated to the current inputs,
- It delivers the sampled current values for protection, measurement function blocks and for disturbance recording and for on-line displaying,
- It provides parameters for the subsequent functions blocks for scaling the measured currents.
- It performs the basic calculations
  - Fourier basic harmonic magnitude and angle,
  - True RMS value.

#### 3.3.1.1.1. Parameter setting

##### 3.3.1.1.1.1. Summary of the parameters

The parameters of the current input function are explained in the following tables.

#### Enumerated parameters

| Parameter name   | Title                | Selection range     | Default |
|--|----------------------|---------------------|---------|
| Rated secondary current of the first three input channels. 1A or 5A is selected by parameter setting, no hardware modification is needed.      |                      |                     |         |
| CT4_Ch13Nom_EPar_  | Rated Secondary I1-3 | 1A,5A               | 1A      |
| Rated secondary current of the fourth input channel. 1A or 5A (0.2A, 1A) is selected by parameter setting, no hardware modification is needed. |                      |                     |         |
| CT4_Ch4Nom_EPar_   | Rated Secondary I4   | 1A,5A<br>(0.2A, 1A) | 1A      |
| Definition of the positive direction of the first three currents, given by location of the secondary star connection point                     |                      |                     |         |
| CT4_Ch13Dir_EPar_  | Starpoint I1-3       | Line,Bus            | Line    |
| Definition of the positive direction of the fourth current, given as normal or inverted  |                      |                     |         |
| CT4_Ch4Dir_EPar_   | Direction I4         | Normal,Inverted     | Normal  |

*Table 1-1 The enumerated parameters of the current input function*

#### Floating point parameters

| Parameter name                      | Title              | Dim. | Min | Max  | Default |
|-------------------------------------|--------------------|------|-----|------|---------|
| Rated primary current of channel1-3 |                    |      |     |      |         |
| CT4_Pri13_FPar_                     | Rated Primary I1-3 | A    | 100 | 4000 | 1000    |
| Rated primary current of channel4   |                    |      |     |      |         |
| CT4_Pri4_FPar_                      | Rated Primary I4   | A    | 100 | 4000 | 1000    |

*Table 1-2 The floating point parameters of the current input function*



NOTE: The rated primary current of the channels is not needed for the current input function block itself. These values are passed on to the subsequent function blocks.

### 3.3.1.1.1.2. Setting the rated secondary current

The scaling of the currents (even hardware scaling) depends on parameter setting.

#### Rated Secondary I1-3 and Rated Secondary I4

Select the rated secondary current according to the nominal data of the main current transformer. The options to choose from are 1A or 5A (in special applications, 0.2A or 1A). This parameter influences the internal number format and, naturally, accuracy. (A small current is processed with finer resolution if 1A is selected.) The first parameter is common for the first three channels and the second one is applied for the fourth channel.

NOTE: when selecting from the available choice, no hardware modification is needed.

### 3.3.1.1.1.3. Setting the positive direction of the currents

The positive direction of the currents influences the correct operation of directionality (e.g. distance protection, directional overcurrent protection, power calculation, etc.) If needed, the currents can be inverted by setting parameters. This is equivalent to interchanging the two wires, connecting the currents to the inputs.

#### Starpoint I1-3 and Direction I4.

Starpoint I1-3 applies to each of the channels IL1, IL2 and IL3. The example of Figure 1-1 below shows the connection and the correct parameter setting for Starpoint I1-3=Line. The current L1 is connected to terminal No1 of the CT input, the current L2 to No3, and the current L3 to No5. The common point of the CT inputs is the connected No2-No4-No6. This point leads the residual current to the input No7. The connection point No8 is connected with the fourth wire to the star-point of the CTs. This application of the fourth channel is the "Normal" direction.

If the currents are connected not this way then change the parameter values accordingly.

### 3.3.1.1.1.4. Setting the rated primary current

These parameters are needed only to display the currents (and powers) in primary scale. The protection function apply secondary values, these parameters are not needed for protection functions.

#### Rated Primary I1-3 and Rated Primary I-4

Select the rated primary currents according to the nominal data of the main current transformers. The first parameter (Rated Primary I1-3) is common for the first three channels and the second (Rated Primary I-4) is for the fourth channel.

### 3.3.1.1.2. Application of the on-line measurements in commissioning

The **measured values** of the current input function block are listed and explained in the Table below.

| Measured value  | Dim.         | Explanation   |
|-----------------|--------------|---|
| Current Ch - I1 | A(secondary) | Fourier basic component of the current in channel IL1 |
| Angle Ch - I1   | degree       | Vector position of the current in channel IL1         |
| Current Ch - I2 | A(secondary) | Fourier basic component of the current in channel IL2 |
| Angle Ch - I2   | degree       | Vector position of the current in channel IL2         |
| Current Ch - I3 | A(secondary) | Fourier basic component of the current in channel IL3 |
| Angle Ch - I3   | degree       | Vector position of the current in channel IL3         |
| Current Ch - I4 | A(secondary) | Fourier basic component of the current in channel IL4 |
| Angle Ch - I4   | degree       | Vector position of the current in channel IL4         |

*Table 1-3 The measured analogue values of the current input function*

NOTE1: The scaling of the Fourier basic component is such that if pure sinusoid 1A RMS of the rated frequency is injected, the displayed value is 1A.

NOTE2: The reference of the vector position depends on the device configuration. If a voltage input module is included, then the reference vector (vector with angle 0 degree) is the vector calculated for the first voltage input channel of the first applied voltage input module. If no voltage input module is configured, then the reference vector (vector with angle 0 degree) is the vector calculated for the first current input channel of the first applied current input module. (The first input module is the one, located closer to the CPU module.)

### 3.3.1.1.3. Examples

When the vector position of the currents are relevant (e.g. distance protection, directional overcurrent protection, power measurement, etc.) then mind the correct connection of the instrument transformers and the related parameter setting. If the wires of the secondary cables are interchanged then change also the related parameter values.

#### 3.3.1.1.3.1. Residual current measurement

Figure 1-1 shows a connection example with 3I<sub>0</sub> measurement. The star-point of the CT-s is towards the line, L1 is connected to terminal No1 of the CT input, L2 to No3, L3 to No5.

The common point of the CT inputs is the connected No2-No4-No6. This point leads the residual current to the input No7. The connection point No8 is connected with the fourth wire to the star-point of the CTs.




Figure 1-1 Example: CT connection with 3I<sub>0</sub> measurement

The related proposed parameter setting is the screen-shot of Figure 1-2. Parameter “Starpoint I1-3” is set to “Line”, indicating that the star-point is toward the protected object (line). The parameter “Direction I4” is set to “Normal”, indicating that the residual current flows in to terminal No7 and the star point of the primary current transformer is toward the protected object (line).

|                      | Device value<br>(Default_set_1) | New value |   |                  |
|----------------------|---------------------------------|-----------|---|------------------|
| Rated Secondary I1-3 | 1A                              | 1A        |   |                  |
| Rated Secondary I4   | 1A                              | 1A        |   |                  |
| Starpoint I1-3       | Line                            | Line      |   |                  |
| Direction I4         | Normal                          | Normal    |   |                  |
| Rated Primary I1-3   | 1000                            | 1000      | A | (100 - 4000 / 1) |
| Rated Primary I4     | 1000                            | 1000      | A | (100 - 4000 / 1) |

Figure 1-2 Example: Parameter setting, according to Figure 1-1

In case of normal operation of the network, the correct connection of the CT-s and the related parameter setting can be checked using the “On-line” measurements. Disconnect one phase of the protected line, e.g. L1. The expected result is shown in Figure 1-3. The current is missing in phase L1 (Current Ch-I1 = 0) and the measured 3I<sub>0</sub> value is the vector sum of the remaining I<sub>2</sub>+I<sub>3</sub>. (Value of “Current Ch - I4” with the related “Angle - I4”).

NOTE: If in this test, only the secondary current is disclosed using a short measuring cable, then the measured current in this phase is usually not zero, due to the current distribution between the low-impedance input and the impedance of the measuring cable. For correct result, additionally to the short-circuit, also the disconnection of this input is needed. In this example the reference vector is the vector of the first voltage channel (not shown in the screenshot).




Figure 1-3 Example: Checking the current connection

### 3.3.1.1.3.2. Application of core-balanced CT

Figure 1-4 shows a connection example with 3I<sub>0</sub> measurement. The star-point of the CT-s is towards the line, L1 is connected to terminal No1 of the CT input, L2 to No3, L3 to No5. The common point of the CT inputs is the connected No2-No4-No6. The separately measured residual current is connected with the same polarity to terminals 7-8.




Figure 1-4 Example: CT connection with core-balance CT application

This figure also indicates the proposed parameter values for this connection. The checking is similar to that, shown in Figure 1-3.

### 3.3.2. AIC current input function

#### 3.3.2.1. Application of the AIC current input function

If the factory configuration includes an AIC input hardware module, the AIC current input function block is automatically configured among the software function blocks. Separate current input function blocks are assigned to each AIC current input hardware module.

The AIC current input module accepts transducers current outputs. The AIC module has four channels, they can measure unipolar and bipolar current values in wide ranges. (See EuroProt+ hardware description document.) The transducer converts any physical quantity to DC current values.

The transmitters can be connected by wiring methods, shown in Figure 1–1, Figure 1–2 and Figure 1–3.




Figure 1–1 2-wire AIC wiring without 12 V excitation




Figure 1–2 2-wire AIC wiring with 12 V excitation






Figure 1-3 3-wire AIC wiring with 12 V excitation

The channels of the module are independent of each other. To each channel a dedicated measuring module is assigned. These measuring modules are described in a separate document: “**GGIOmA current measurement module function block description**”.

### 3.3.2.2. Technical summary

#### 3.3.2.2.1. Technical data

The technical data of the AIC analog current input module are related to the hardware module. This is described in the document “**EuroProt+ Hardware description**, Chapter 11: analog input module”.

#### 3.3.2.2.2. Summary of the parameters

The parameters of the AIC analog current input function are explained in the following table.

##### Enumerated parameters

| Parameter name        | Title           | Selection range  | Default |
|-----------------------|-----------------|------------------|---------|
| Polarity of Channel 1 |                 |                  |         |
| AIC_Ch1Dir_EPar_1     | Direction - Ch1 | Normal,Inverted* | Normal  |
| Polarity of Channel 2 |                 |                  |         |
| AIC_Ch2Dir_EPar_1     | Direction – Ch2 | Normal,Inverted* | Normal  |
| Polarity of Channel 3 |                 |                  |         |
| AIC_Ch3Dir_EPar_1     | Direction – Ch3 | Normal,Inverted* | Normal  |
| Polarity of Channel 4 |                 |                  |         |
| AIC_Ch4Dir_EPar_1     | Direction – Ch4 | Normal,Inverted* | Normal  |

\*Figures 1-1, 1-2 and 1-3 show “Normal” connection polarity

Table 1-1 The enumerated parameters of the current input function

NOTE: The function block has no input and output binary signals, the graphic logic editor does not show this function block.



### 3.3.3. Voltage input function

#### 3.3.3.1. Application of the voltage input function

The application of the voltage inputs depends on the correct connection of the hardware terminals and also on the correct parameter setting for the VT4 function block. This guide describes examples, based on which any other combinations can be realized.

In the applications of the voltage transformer hardware module, the first three voltage inputs receive the three phase voltages (UL1, UL2, UL3), the fourth input is reserved for zero sequence voltage, for the busbar voltage if synchronized switching is applied or for any additional voltages. Accordingly, the first three inputs have common parameters while the fourth voltage input needs individual setting.

The VT4 function block is an independent module in the sense that:

- It has independent parameters to be set, associated to the voltage inputs,
- It delivers the sampled voltage values for protection, measurement function blocks and for disturbance recording,
- It provides parameters for the subsequent functions blocks for scaling the measured voltages.
- It performs the basic calculations
  - Fourier basic harmonic magnitude and angle,
  - True RMS value.

#### 3.3.3.1.1. Parameter setting

##### 3.3.3.1.1.1. Summary of the parameters

The parameters of the voltage input function are explained in the following tables.

##### Enumerated parameters

| Parameter name   | Title           | Selection range            | Default  |
|--|-----------------|----------------------------|----------|
| Rated secondary voltage of the input channels. 100 V or 200V is selected by parameter setting, no hardware modification is needed. |                 |                            |          |
| VT4_Type_EPar_   | Range           | Type 100,Type 200          | Type 100 |
| Connection of the first three voltage inputs (main VT secondary)   |                 |                            |          |
| VT4_Ch13Nom_EPar_  | Connection U1-3 | Ph-N, Ph-Ph, Ph-N-Isolated | Ph-N     |
| Selection of the fourth channel input: phase-to-neutral or phase-to-phase voltage  |                 |                            |          |
| VT4_Ch4Nom_EPar_   | Connection U4   | Ph-N,Ph-Ph                 | Ph-Ph    |
| Definition of the positive direction of the first three input channels, given as normal or inverted                                |                 |                            |          |
| VT4_Ch13Dir_EPar_  | Direction U1-3  | Normal,Inverted            | Normal   |
| Definition of the positive direction of the fourth voltage, given as normal or inverted  |                 |                            |          |
| VT4_Ch4Dir_EPar_   | Direction U4    | Normal,Inverted            | Normal   |

*Table 1-1 The enumerated parameters of the voltage input function*

##### Integer parameter

| Parameter name     | Title         | Unit | Min | Max | Step | Default |
|--------------------|---------------|------|-----|-----|------|---------|
| Voltage correction |               |      |     |     |      |         |
| VT4_CorrFact_IPar_ | VT correction | %    | 100 | 115 | 1    | 100     |

*Table 1-2 The integer parameter of the voltage input function*



### Floating point parameters

| Parameter name                           | Title              | Dim. | Min | Max  | Default |
|--|--------------------|------|-----|------|---------|
| Rated primary voltage of channel 1, 2, 3 |                    |      |     |      |         |
| VT4_PriU13_FPar                          | Rated Primary U1-3 | kV   | 1   | 1000 | 100     |
| Rated primary voltage of channel 4       |                    |      |     |      |         |
| VT4_PriU4_FPar                           | Rated Primary U4   | kV   | 1   | 1000 | 100     |

*Table 1-3 The floating point parameters of the voltage input function*

NOTE: The rated primary voltage of the channels is not needed for the voltage input function block itself. These values are passed on to the subsequent function blocks.

### 3.3.3.1.1.2. Setting the rated secondary voltage

The scaling of the voltage depends on parameter setting.

#### Range

There are basically two standard voltage transformer types: one with secondary rated voltage 100 V, the other with 200 V. Select the parameter value respectively: Type 100, Type 200. No hardware modification is needed. This parameter influences the internal number format and, naturally, accuracy. (A small voltage is processed with finer resolution if 100V is selected.)

#### VT correction

In some cases the rated secondary of the voltage transformers is not 100V but e.g. 110 V. This parameter is to correct this difference, if the rated secondary voltage of the main voltage transformer does not match the rated input of the device. As an example: if the rated secondary voltage of the main voltage transformer is 110V, then select Type 100 for the parameter "Range" and the required value to set here is 110%.

### 3.3.3.1.1.3. Setting the connection and the positive direction of the voltages

The connection and direction parameters of the first three VT secondary windings must be set to reflect actual physical connection of the main VTs.

#### Connection U1-3.

The selection can be: "Ph-N", "Ph-Ph" or "Ph-N-Isolated".

The *Ph-N* option is applied in solidly grounded networks, where the measured phase voltage is never above  $1.5 \cdot U_n$ . In this case the primary rated voltage of the VT must be the value of the rated PHASE-TO-NEUTRAL voltage.

The *Ph-N-Isolated* option is applied in compensated or isolated networks, where the measured phase voltage can be above  $1.5 \cdot U_n$  even in normal operation. In this case the primary rated voltage of the VT must be the value of the rated PHASE-TO-PHASE voltage.

The *Ph-Ph* option is to be selected if phase-to-phase voltage is connected to the VT input of the device. Here, the primary rated voltage of the VT must be the value of the rated PHASE-TO-PHASE voltage. This option must not be selected if the distance protection function or



directional overcurrent protection function is supplied from the VT input.

#### Connection U4

The fourth input is reserved for zero sequence voltage or for a voltage from the other side of the circuit breaker for synchronized switching. Accordingly, the connected voltage must be identified with parameter setting Connection U4. Here, phase-to-neutral or phase-to-phase voltage can be selected: “Ph-N”, “Ph-Ph”

#### Direction U1-3

If needed, the phase voltages can be inverted by setting the parameter Direction U1-3. This selection applies to each of the channels UL1, UL2 and UL3. The primary/secondary connection of the VT windings is generally star/star connected and the phase voltages signed with • are connected to the VT4 terminals 1-3-5. In this case the parameter setting is „Normal”. Select “Inverted” to the parameter Direction U1-3 in case of inverted connection of phase voltages.” (See also Figure 1-1 in setting example.)

#### Direction U4

This parameter applies to the channel UL4. If the voltage signed with • is connected to the VT4 terminal 7 the parameter setting is „Normal”. Select “Inverted” to the parameter Direction U4 in case of inverted connection of the voltage. This inversion may be needed in protection functions such as distance protection or for any functions with directional decision, or for checking the voltage vector positions.

Figure 1-1 shows an example with harmonized connection and parameter setting.

If the voltages are connected not this way then change the parameter values accordingly.

### 3.3.3.1.1.4. Setting the rated primary voltage

These parameters are needed only to display the voltages (and powers) in primary scale. The protection functions apply secondary values, these parameters are not needed for protection functions.

#### Rated Primary U1-3 and Rated Primary U-4

Select the rated primary voltages according to the nominal data of the main voltage transformers. The two parameters are: common for the first three channels and one for the fourth channel respectively.

### 3.3.3.1.2. Application of the on-line measurements in commissioning

The performed basic calculation results the Fourier basic harmonic magnitude and angle value of the voltages. These results are processed by subsequent protection function blocks and they are available for on-line displaying as well.

#### 3.3.3.1.2.1. Summary of the on-line measurements

The **measured values** of the voltage input function block.

| Measured value  | Dim.         | Explanation   |
|-----------------|--------------|---|
| Voltage Ch - U1 | V(secondary) | Fourier basic component of the voltage in channel UL1 |
| Angle Ch - U1   | degree       | Vector position of the voltage in channel UL1         |
| Voltage Ch - U2 | V(secondary) | Fourier basic component of the voltage in channel UL2 |
| Angle Ch - U2   | degree       | Vector position of the voltage in channel UL2         |
| Voltage Ch - U3 | V(secondary) | Fourier basic component of the voltage in channel UL3 |
| Angle Ch - U3   | degree       | Vector position of the voltage in channel UL3         |
| Voltage Ch - U4 | V(secondary) | Fourier basic component of the voltage in channel U4  |
| Angle Ch - U4   | degree       | Vector position of the voltage in channel U4          |

*Table 1-4 The measured analogue values of the voltage input function*

NOTE1: The scaling of the Fourier basic component is such that if pure sinusoid 57V RMS of the rated frequency is injected, the displayed value is 57V.

NOTE2: The reference vector (vector with angle 0 degree) is the vector calculated for the first voltage input channel of the first applied voltage input module. (The first voltage input module is the one, configured closer to the CPU module.)

### 3.3.3.1.3. Examples

When the vector position of the voltages are relevant (e.g. distance protection, directional overcurrent protection, power measurement, synchrocheck, etc.) then mind the correct connection of the instrument transformers and the related parameter setting. If the wires of the secondary cables are interchanged then change also the related parameter values.

#### 3.3.3.1.3.1. Phase voltage and residual voltage measurement

Figure 1-1 shows the phase voltage measurement and also the residual voltage measurement e.g. for residual directional overcurrent protection function. In this example the residual voltage is measured in open delta of the VT secondary coils. The network is supposed to be compensated. This figure also indicates the proposed parameter values.




Figure 1-1 Example: Phase voltage and residual voltage measurement

|                    |               |   |
|--------------------|---------------|---|
| Range              | Type 100      | The type indicates the rated secondary voltage of the VT. This can be 100 V (in this example) or 200V   |
| Connection U1-3    | Ph-N-Isolated | This indicates that the VT primary is connected between the conductor and the ground (in this example in compensated network). This could be Ph-N or Ph-Ph in other application. (NOTE: If the neutral of the system is not grounded, select Ph-N-Isolated) |
| Connection U4      | Ph-Ph         | In case of earth fault the open delta measures 100 V. This corresponds to the phase-to-phase value  |
| Direction U1-3     | Normal        | Figure 1-1 shows the normal VT connection, i.e. the signed • phase wires are connected to the terminals 1-3-5. (Select "Inverted" in case of inverted connection.)  |
| Direction U4       | Normal        | Figure 1-1 shows the normal VT connection, i.e. the signed • wire of the open delta of VT-s is connected to the terminal 7. (Select "Inverted" in case of inverted connection.)   |
| VT correction      | 100           | If the rated secondary value of the VT is e.g. 110 V then select this correction value to 110%.   |
| Rated Primary U1-3 | 20            | Setting, according to the VT rated voltage, applied at the primary side. This parameter is used for scaling the displayed values only.  |
| Rated Primary U4   | 11.55         | This parameter is used for scaling the displayed values only. In case of earth fault, the open delta measures 100 V. In primary value it is displayed as the phase voltage in the 20 kV network.  |

Table 1-5 Example parameters for the voltage input function

### 3.3.3.1.3.2. Syncrocheck using phase-to neutral voltage

Figure 1-2 shows the application of the fourth voltage input of the VT module for syncrocheck function. Here UL2 of the busbar voltage is used for this purpose.

NOTE: Among syncrocheck parameters set "Voltage select" parameter to "L2-N."





Figure 1-2 Example: Syncrocheck, using phase-to-neutral voltage

Figure 1-3 shows the screenshot indicating the proposed parameter values.



|                    | Device value<br>(Default_set_1) | New value |    |                         |
|--------------------|---------------------------------|-----------|----|-------------------------|
| Range              | Type 100                        | Type 100  |    |                         |
| Connection U1-3    | Ph-N                            | Ph-N      |    |                         |
| Connection U4      | Ph-N                            | Ph-N      |    |                         |
| Direction U1-3     | Normal                          | Normal    |    |                         |
| Direction U4       | Normal                          | Normal    |    |                         |
| VT correction      | 100                             | 100       | %  | (100 - 115 / 1)         |
| Rated Primary U1-3 | 69.28                           | 69.28     | kV | (1.00 - 1000.00 / 0.01) |
| Rated Primary U4   | 69.28                           | 69.28     | kV | (1.00 - 1000.00 / 0.01) |

Figure 1-3 Example: Parameters for syncrocheck, using phase-to-neutral voltage

The "On-line window" of the VT4 input module shows the checking the correct voltage vector position. When the line is connected to the busbar, i.e. the CB is closed, in this example the U4 voltage is expected to have the same value and position as U2. See Figure 1-4.






Figure 1-4 Example: On-line measurement for syncrocheck, using phase-to-neutral voltage

### 3.3.3.1.3.3. Syncrocheck using phase-to-phase voltage

Figure 1-5 shows the application of the fourth voltage input of the VT module for syncrocheck function. Here UL1-UL3 line-to-line signal of the busbar voltage is used for this purpose.

NOTE: Among syncrocheck parameters set "Voltage select" parameter to "L3-L1". This selection is opposite to that, of the connected voltage. This can be corrected selecting the "Direction U4" parameter value to "Inverse".




Figure 1-5 Example: Syncrocheck, using phase-to-phase voltage

Figure 1-6 shows the proposed parameter values for the connection shown above.



[ - ] VT4 module "U"

|                    | Device value<br>(Default_set_1) | New value |    |                         |
|--------------------|---------------------------------|-----------|----|-------------------------|
| Range              | Type 100                        | Type 100  |    |                         |
| Connection U1-3    | Ph-N                            | Ph-N      |    |                         |
| Connection U4      | Ph-Ph                           | Ph-Ph     |    |                         |
| Direction U1-3     | Normal                          | Normal    |    |                         |
| Direction U4       | Inverted                        | Inverted  |    |                         |
| VT correction      | 100                             | 100       | %  | (100 - 115 / 1)         |
| Rated Primary U1-3 | 69.28                           | 69.28     | kV | (1.00 - 1000.00 / 0.01) |
| Rated Primary U4   | 120.00                          | 120.00    | kV | (1.00 - 1000.00 / 0.01) |

Figure 1-6 Example: Parameters for syncrocheck, using phase-to-phase voltage

The "On-line window" of the VT4 input module shows the checking the correct voltage vector position. When the line is connected to the busbar, i.e. the CB is closed, in this example the U4 voltage is expected to have a vector identical with the voltage difference U3-U1. See Figure 1-7.




Figure 1-7 Example: On-line measurement for syncrocheck, using phase-to-phase voltage

NOTE that due to the reverse connection of the voltage difference and the parameter setting also reverted by "Inverse" setting, the indicated U4 vector corresponds to the parameter "Voltage select=L3-L1" among syncrocheck parameters.



### 3.3.4. Line and frequency measurement functions

#### 3.3.4.1. Application

The input values of the EuroProt+ devices are the secondary signals of the voltage transformers and those of the current transformers when they are available in the actual configuration.

These signals are pre-processed by the “VT4 module” voltage input function block and by “CT4 module” the current input function block. These function blocks are described in separate documents. The pre-processed values include the Fourier basic harmonic phasors of the voltages and currents and the true RMS values. Additionally, it is in these function blocks that parameters are set concerning the voltage ratio of the primary voltage transformers and current ratio of the current transformers.

Based on the pre-processed values and the measured transformer parameters, the measurement function blocks calculate - depending on the hardware and software configuration - the primary RMS values of the voltages and currents and some additional values such as active and reactive power, symmetrical components of voltages and currents. These values are available as primary quantities and they can be displayed on the on-line screen of the device or on the remote user interface of the computers connected to the communication network and they are available for the SCADA system using the configured communication system.

#### 3.3.4.2. Mode of operation

The **inputs** of the line measurement function are

- the Fourier components and true RMS values of the measured voltages and currents,
- frequency measurement,
- parameters.

The **outputs** of the line measurement function are

- displayed measured values,
- reports to the SCADA system.

**NOTE:** the scaling values are entered as parameter setting for the “Voltage transformer input” function block and for the “Current transformer input” function block.

### 3.3.4.3. The measurement

#### 3.3.4.3.1. The measured values; variants of the function

There are six variants of the MXU function, based on their **measured values**. Parameters and measurements are alike for each. The **type of the variant** is shown in the *function block name*:

- Line Measurement (*MXU\_LM*)
- Frequency Measurement (*MXU\_F*)
- Voltage measurement (*MXU\_V*)
- Voltage measurement (*MXU\_V1*) (single voltage)
- Current measurement (*MXU\_C*)
- Current measurement (*MXU\_C1*) (single current)

Table 1-1 Measured values of each variant

| ON-LINE MEASURED VALUE | EXPLANATION   | MXU FUNCTION BLOCK VARIANT |   |   |    |   |    |
|------------------------|---|----------------------------|---|---|----|---|----|
|                        |   | LM                         | F | V | V1 | C | C1 |
| MXU_P_OLM_             | Active Power – P<br>(Fourier base harmonic value)   | X                          |   |   |    |   |    |
| MXU_Q_OLM_             | Reactive Power – Q<br>(Fourier base harmonic value) | X                          |   |   |    |   |    |
| MXU_S_OLM_             | Apparent Power – S<br>(Fourier base harmonic value) | X                          |   |   |    |   |    |
| MXU_Fi_OLM_            | Power factor  | X                          |   |   |    |   |    |
| MXU_I1_OLM_            | Current L1  | X                          |   |   |    | X | X  |
| MXU_I2_OLM_            | Current L2  | X                          |   |   |    | X |    |
| MXU_I3_OLM_            | Current L3  | X                          |   |   |    | X |    |
| MXU_Ipos_OLM_          | Calculated positive seq. current                    | X                          |   |   |    | X |    |
| MXU_Ineg_OLM_          | Calculated negative seq. current                    | X                          |   |   |    | X |    |
| MXU_3Io_OLM_           | Calculated 3Io                                      | X                          |   |   |    | X |    |
| MXU_U1_OLM_            | Voltage L1  | X                          |   | X | X  |   |    |
| MXU_U2_OLM_            | Voltage L2  | X                          |   | X |    |   |    |
| MXU_U3_OLM_            | Voltage L3  | X                          |   | X |    |   |    |
| MXU_U12_OLM_           | Voltage L12   | X                          |   | X |    |   |    |
| MXU_U23_OLM_           | Voltage L23   | X                          |   | X |    |   |    |
| MXU_U31_OLM_           | Voltage L31   | X                          |   | X |    |   |    |
| MXU_Upos_OLM           | Calculated positive seq. voltage                    | X                          |   | X |    |   |    |
| MXU_Uneg_OLM_          | Calculated negative seq. voltage                    | X                          |   | X |    |   |    |
| MXU_3Uo_OLM_           | Calculated 3Uo                                      | X                          |   | X |    |   |    |
| MXU_f_OLM_             | Frequency   |                            | X | X |    |   |    |



### 3.3.4.4.2. “Integrated” mode of reporting

If the “Integrated” mode is selected for reporting, a report is generated if the time integral of the measured value since the last report gets becomes larger, in the positive or negative direction, then the (deadband\*1sec) area. As an example, [Figure 1-2](#) shows that the integral of the current in time becomes higher than the Deadband value multiplied by 1sec, this results “report2”, etc.




Figure 1-2 Reporting if “Integrated” mode is selected

### 3.3.4.4.3. Periodic reporting

Periodic reporting is generated independently of the changes of the measured values when the defined time period elapses. If the reporting time period is set to 0, then no periodic reporting is performed for this quantity.

Applying periodic reporting and setting up its interval is done by using the **Communication configurator**, a part of the **EuroCAP** software (see its description for detailed information).

Once the “Trigger period” property is set to “True”, the “Integrity period” setting becomes available to set (in milliseconds). As an example, see the picture below.




Figure 1-3 Setting up periodic reporting in EuroCAP



#### 3.3.4.4.4. Zero-point clamping

A measured value under the zero-point clamping limit is cut off to zero.

- Three-phase current measurement 0.2% of nominal ( $I_n$ )
- Three-phase voltage measurement 2% of nominal ( $U_n$ )
- Residual current measurement 0.2% of nominal ( $I_n$ )
- Residual voltage measurement 2% of nominal ( $U_n$ )
- Phase sequence current measurement 0.2% of the nominal ( $I_n$ )
- Phase sequence voltage measurement 2% of the nominal ( $U_n$ )
- Three-phase power and energy measurement 0.23% of the nominal ( $S_n$ )






|                     |       |                            |      |           |  |
|---------------------|-------|----------------------------|------|-----------|--|
| Range Value - Ipos  | A     | 1 – 5000                   | 1    | 500       | Range value for the positive seq. current                      |
| Report Deadband - P | -     | Off, Amplitude, Integrated | -    | Amplitude | Selection of the reporting mode for active power measurement   |
| Deadband Value - P  | kW*   | 0.10 – 10000.00            | 0.01 | 10        | Deadband value for the active power                            |
| Range Value - P     | kW*   | 1.00 – 100000.00           | 0.01 | 500       | Range value for the active power                               |
| Report Deadband - Q | -     | Off, Amplitude, Integrated | -    | Amplitude | Selection of the reporting mode for reactive power measurement |
| Deadband Value - Q  | kVAr* | 0.10 – 10000.00            | 0.01 | 10        | Deadband value for the reactive power                          |
| Range Value - Q     | kVAr* | 1.00 – 100000.00           | 0.01 | 500       | Range value for the reactive power                             |
| Report Deadband - S | -     | Off, Amplitude, Integrated | -    | Amplitude | Selection of the reporting mode for apparent power measurement |
| Deadband Value - S  | kVA*  | 0.10 – 10000.00            | 0.01 | 10        | Deadband value for the apparent power                          |
| Range Value - S     | kVA*  | 1.00 – 100000.00           | 0.01 | 500       | Range value for the apparent power                             |
| Report Deadband     | Hz    | Off, Amplitude, Integrated | -    | Amplitude | Selection of the reporting mode for frequency measurement      |
| Deadband Value      | Hz    | 0.01 – 1.00                | 0.01 | 0.03      | Deadband value for the frequency                               |
| Range Value         | Hz    | 0.05 – 10.00               | 0.01 | 5         | Range value for the frequency                                  |

*\*the prefixes can change (i.e. kW→MW, kV→V etc.) depending on the configuration; changing these is done by Protecta personnel*

*\*\*if the setting range is to be extended, contact Protecta personnel*





### 3.3.4.5.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.3.4.5.2.1. Analogue inputs

The analogue inputs of the measurement functions are

- the Fourier components and true RMS values of the measured and calculated secondary voltages
- the Fourier components and true RMS values of the measured secondary currents,

#### 3.3.4.5.2.2. Analogue outputs (measurements)

See the next chapter (On-line data) for the listing of all measurements. Note again, that the measured values depend on the type of the actual measurement function block, see Chapter [1.3.1](#)

#### 3.3.4.5.2.3. On-line data





The **on-line data** of the line measurement function depend on the available analogue values which are referring to the applied hardware configuration.

Visible values on the on-line data page:

*Table 2-2 On-line data of the line measurement function*

| SIGNAL TITLE               | DIMENSION | EXPLANATION  |
|----------------------------|-----------|--|
| Power - P                  | kW*       | Calculated three-phase active power  |
| Reactive Power - Q         | kVAr*     | Calculated three-phase reactive power  |
| Apparent Power - S         | kVA*      | Calculated three-phase apparent power  |
| Power factor               | -         | Calculated power factor  |
| Current L1                 | A         | Measured primary current L1 based on the nominal values of the CT4 current input function          |
| Current L2                 | A         | Measured primary current L2 based on the nominal values of the CT4 current input function          |
| Current L3                 | A         | Measured primary current L3 based on the nominal values of the CT4 current input function          |
| Positive sequence current  | A         | Calculated positive sequence current from the three phase currents                                 |
| Negative sequence current  | A         | Calculated negative sequence current from the three phase currents                                 |
| Calculated 3I <sub>0</sub> | A         | Calculated 3I <sub>0</sub> from the three phase currents   |
| Voltage L1                 | kV*       | Measured primary L1 phase voltage L1 based on the nominal values of the VT4 voltage input function |
| Voltage L2                 | kV*       | Measured primary L2 phase voltage L2 based on the nominal values of the VT4 voltage input function |
| Voltage L3                 | kV*       | Measured primary L3 phase voltage L3 based on the nominal values of the VT4 voltage input function |
| Voltage L12                | kV*       | Calculated L12 phase-to-phase voltage  |
| Voltage L23                | kV*       | Calculated L23 phase-to-phase voltage  |
| Voltage L31                | kV*       | Calculated L31 phase-to-phase voltage  |
| Positive sequence voltage  | kV*       | Calculated positive sequence voltage from the three phase voltages                                 |
| Negative sequence voltage  | kV*       | Calculated negative sequence voltage from the three phase voltages                                 |
| Calculated 3U <sub>0</sub> | kV*       | Calculated 3U <sub>0</sub> from the three phase voltages   |
| Frequency                  | Hz        | Measured frequency   |

*\*the prefixes may be different (i.e. kW→MW, kV→V etc.) depending on the configuration; changing these is done by Protecta personnel*



### 3.3.4.5.3. Technical data

Table 2-3 Technical data of the line measurement function (power)

| POWER MEASUREMENT (P, Q, S)*         | RANGE   | ACCURACY        |
|--------------------------------------|---|-----------------|
| <b>HW MODULES</b>                    |   |                 |
| CT+/5115                             | 0,002 – 0,01 In                                     | ±3%, ±1 digit   |
|                                      | 0,01 – 0,03 In                                      | ±1%, ±1 digit   |
|                                      | 0,03 – 5 In<br>(max. 5 In for measurement purposes) | ±0,5%, ±1 digit |
| CT+/1500**                           | 0,002 – 0,005 In                                    | ±1,5%, ±1 digit |
|                                      | 0,005 – 0,02 In                                     | ±0,5%, ±1 digit |
|                                      | 0,02 – 2 In   | ±0,2%, ±1 digit |
| CT+/5151**<br>CT+/5153 (Channel 1-3) | 0,02 – 0,05 In                                      | ±3%, ±1 digit   |
|                                      | 0,05 – 20 In  | ±0,5%, ±1 digit |

\* By using VT+/2211 with nominal voltage.

\*\* The defined accuracy regarding the CT+/1500 and CT+/5151 modules are valid from 2020/Q2 or on customer request. For the values before this date, see [Table 2-7](#) in the next chapter.

Table 2-4 Technical data of the line measurement function (currents)

| CURRENT MEASUREMENT (PHASE AND SEQUENTIAL) | RANGE   | ACCURACY        |
|--|---|-----------------|
| <b>HW MODULES</b>                          |   |                 |
| CT+/5115                                   | 0,002 – 0,01 In                                     | ±3%, ±1 digit   |
|  | 0,01 – 0,03 In                                      | ±1%, ±1 digit   |
|  | 0,03 – 5 In<br>(max. 5 In for measurement purposes) | ±0,5%, ±1 digit |
| CT+/1500*                                  | 0,002 – 0,005 In                                    | ±1,5%, ±1 digit |
|  | 0,005 – 0,02 In                                     | ±0,5%, ±1 digit |
|  | 0,02 – 2 In   | ±0,2%, ±1 digit |
| CT+/5151*<br>CT+/5153 (Channel 1-3)        | 0,02 – 0,05 In                                      | ±3%, ±1 digit   |
|  | 0,05 – 20 In  | ±0,5%, ±1 digit |

\* The defined accuracy regarding the CT+/1500 and CT+/5151 modules are valid from 2020/Q2 or on customer request. For the values before this date, see [Table 2-7](#) in the next chapter.

Table 2-5 Technical data of the line measurement function (voltages)

| VOLTAGE MEASUREMENT (PHASE, PHASE-TO-PHASE, SEQUENTIAL) | RANGE         | ACCURACY        |
|---|---------------|-----------------|
| <b>HW MODULES</b>                                       |               |                 |
| VT+/2211  | 0,05 – 1,5 Un | ±0,5%, ±1 digit |

Table 2-6 Technical data of the frequency measurement function

| FREQUENCY MEASUREMENT | VALUE  | ACCURACY |
|-----------------------|--|----------|
| Frequency             | 40 - 60 Hz (50 Hz system)<br>50 - 70 Hz (60 Hz system) | ± 2 mHz  |





### 3.3.5.4. Parameters of the function block

#### Enumerated parameter

| Parameter name            | Title              | Selection range                  | Default |
|---------------------------|--------------------|----------------------------------|---------|
| Time window for averaging |                    |                                  |         |
| MXU_TimWin_EPar_T _       | Average TimeWindow | Off,5min,10min,15min,30min,60min | Off     |

Table 1-1 The enumerated parameters of the average and maximum measurement function

#### Integer parameter

| Parameter name                            | Title             | Unit | Min | Max | Step | Default |
|---|-------------------|------|-----|-----|------|---------|
| Time window for finding the maximum value |                   |      |     |     |      |         |
| MXU_MaxResInt_IPar_T                      | MaxReset Interval | day  | 0   | 365 | 1    | 1       |
| Moment of time for reporting and reset    |                   |      |     |     |      |         |
| MXU_MaxResTime_IPar_T                     | MaxReset Time     | hour | 0   | 23  | 1    | 12      |

Table 1-2 The integer parameters of the average and maximum measurement function

### 3.3.5.5. Status signals of the function block

The average and maximum measurement function block has **binary input signals**, which serve the purpose of resetting the values and enabling logging the average value. **The conditions are defined by the user, applying the graphic equation editor.**

| Binary status signal  | Explanation  |
|-----------------------|--|
| MXU_Reset_GrO_IL1 *   | This signal resets both the calculated average and the found maximum value. At the end of the running cycles, the values found during the shortened cycle will be processed. |
| MXU_DemHMIEna_GrO_IL1 | During the active state of this signal also the calculated average value is logged   |

\* Note: In this example “IL1” is indicating that in the instant of the function block processes the RMS value of the current in line 1

Table 1-3 The binary input signal for the average and maximum measurement function block

The average and maximum measurement function block **has no binary output signals.**

### 3.3.5.6. The function block

The function block of the average and maximum measurement function is shown in Figure 1-1. This block shows all binary input (and output) status signals that are applicable in the graphic equation editor.





Figure 1-1 The function block of the average and maximum measurement function block



### 3.3.6. Metering

#### 3.3.6.1. Application

The metering function can be applied to calculate the active and reactive energy supply and demand values based on the own measurement of the device or the energy meter impulses.

##### 3.3.6.1.1. Mode of operation

There is an “Input selection” parameter to select the input of energy the calculation “Measurement” or “Impulse”. Chapter 1.1.1 and Chapter 1.1.2 describe the difference of operation.

##### 3.3.6.1.2. Measurement mode

The input values of the EuroProt+ devices are the secondary signals of the voltage transformers and those of the current transformers.

These signals are pre-processed by the “Voltage transformer input” function block and by the “Current transformer input” function block. These function blocks are described in separate documents. The pre-processed values include the Fourier basic harmonic phasors of the voltages and currents. Additionally, it is in these function blocks that parameters are set concerning the voltage ratio of the primary voltage transformers and current ratio of the current transformers.

Based on the pre-processed values and the transformer parameters, the “Line measurement” function block calculates “P” and “Q” values in every process cycle and based on these values the “Metering” function block calculates the active and reactive power supply and demand. These values are accumulated to obtain, separately:

- Active power demand,
- Active power supply,
- Reactive power demand.
- Reactive power supply,

This means that the positive and negative values are accumulated separately.

The time period of the accumulation is defined by parameter setting. It can be selected in a broad range. The start of the accumulation is based on the integrated real-time clock of the device. For example, for the “Time Interval” setting of 15min, the trigger is: at 0h0min, 0h15min, 0h30min, 0h45 min, 1h0min, etc.

When the accumulation time is over, the calculated values are reported to the SCADA system. The displayed values change continuously.

The calculated values are available as primary quantities, and they can be displayed on the on-line screen of the device or on the webpage of the device and they are available for the SCADA system using the configured communication system.

The **inputs** of the metering function are:

- the Fourier components of the measured voltages and currents,
- parameters.

The **output** of the metering function is:

- displayed measured values.

NOTE: the scaling values are entered as parameter setting for the “Voltage transformer input” function block and for the “Current transformer input” function block.





### 3.3.6.1.5. The measurement

#### 3.3.6.1.5.1. Reference direction

“Reference direction” parameter setting defines the direction when voltage and current vectors are in phase. Setting can be “Demand” or “Supply”.

#### 3.3.6.1.5.2. The measured values

Unit prefix of the **measured values** of the metering function depends on the configuration: it can be kilo or Mega. The “Line measurement” function uses the same unit prefix as the Metering.

| MEASURED VALUE | EXPLANATION                               |
|----------------|---|
| MTR_PosP_OLM_  | Demand kWh – active power consumption     |
| MTR_NegP_OLM_  | Supply kWh – active power supply          |
| MTR_PosQ_OLM_  | Demand kVArh – reactive power consumption |
| MTR_NegQ_OLM_  | Supply kVArh – reactive power supply      |

*Table 1-1 Measured values of the metering function*

The measured values available are shown as on-line information, see the figure below.



*Figure 1-1 Measured values of the metering function*

#### 3.3.6.1.6. Parameter setting

The time period of accumulation is defined by parameter setting. This can be selected in a broad range, as it is shown in Table 1-2.

##### Enumerated parameter

| PARAMETER NAME                                  | TITLE         | SELECTION RANGE                       | DEFAULT |
|---|---------------|---------------------------------------|---------|
| Selection of the time period for power metering |               |                                       |         |
| MTR_TimInt_EPar_                                | Time Interval | Off, 5min, 10min, 15min, 30min, 60min | 30min   |

*Table 1-2 The enumerated parameter of the metering function*



### 3.3.6.2. Metering function overview

The graphic appearance of the function block of the metering function is shown below. The block shows all binary input and output status signals which are applicable in the graphic equation editor.




Figure 2-1 Graphic appearance of the function block of the metering function

#### 3.3.6.2.1. Settings

##### 3.3.6.2.1.1. Parameters

The available parameters are listed below in order of their appearance in the *parameters* menu. If the setting range of a parameter should be extended, contact Protecta Support.

Table 2-1 The available parameters of the metering function

| TITLE                | DIM.            | RANGE  | STEP | DEFAULT     | EXPLANATION  |
|----------------------|-----------------|--|------|-------------|--|
| Time Interval        | -               | Off,<br>5min (On),<br>10min ,<br>15min ,<br>30min ,<br>60min | -    | 30min       | Time period of accumulation parameter for general operation of the function: |
| Input selection      | -               | Measurement,<br>Impulse,                                     | -    | Measurement | Input selection of energy calculation  |
| Cumulation mode      |                 | FALSE,TRUE   |      | FALSE       | Cumulation mode is used  |
| Reference direction  | -               | Demand,<br>Supply  | -    | Demand      | Energy direction reference selection.  |
| Active pulse scale   | kWh/<br>pulse   | 1 - 10000  | 1    | 100         | One impulse of energy meter is equal to this setting                         |
| Reactive pulse scale | kVarh/<br>pulse | 1 - 10000  | 1    | 100         | One impulse of energy meter is equal to this setting                         |

### 3.3.6.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.3.6.2.2.1. Analogue inputs

The function uses the sampled values of a voltage and current inputs. This is defined in the configuration.

#### 3.3.6.2.2.2. Analogue outputs (measurements)

The measured values of the metering function are listed in the table below.

*Table 2-2 The measured analogue values of the metering function*

| MEASURED VALUE | DIMENSION | EXPLANATION  |
|----------------|-----------|--|
| Demand P       | kWh       | <i>Demand P. Unit prefix can be kilo- or mega-, depends on the configuration</i> |
| Supply P       | kWh       | <i>Supply P. Unit prefix can be kilo- or mega-, depends on the configuration</i> |
| Demand Q       | kVArh     | <i>Demand Q. Unit prefix can be kilo- or mega-, depends on the configuration</i> |
| Supply Q       | kVArh     | <i>Supply Q. Unit prefix can be kilo- or mega-, depends on the configuration</i> |

#### 3.3.6.2.2.3. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the Logic editor.

*Table 2-3 The binary input signal of the metering function*

| BINARY OUTPUT SIGNAL | EXPLANATION  |
|----------------------|--|
| MTR_Reset_GrO_       | Reset input of the function has meaning only in cumulation mode  |
| MTR_ImpDemP_GrO_     | Demand P impulse of external energy meter input of the function has meaning only in impulse input mode |
| MTR_ImpSupP_GrO_     | Supply P impulse of external energy meter input of the function has meaning only in impulse input mode |
| MTR_ImpDemQ_GrO_     | Demand Q impulse of external energy meter input of the function has meaning only in impulse input mode |
| MTR_ImpSupQ_GrO_     | Supply Q impulse of external energy meter input of the function has meaning only in impulse input mode |

#### 3.3.6.2.2.4. Events

The following events are generated in the event list, as well as sent to the SCADA according to the configuration.

*Table 2-4 Generated events of the metering function*

| EVENT    | DIMENSION | EXPLANATION           |
|----------|-----------|-----------------------|
| Demand P | Wh        | <i>Demand P value</i> |
| Supply P | Wh        | <i>Supply P value</i> |
| Demand Q | VArh      | <i>Demand Q value</i> |
| Supply Q | VArh      | <i>Supply Q value</i> |

### 3.3.6.2.3. Technical data

Table 2-5 Technical data of the metering function

| FUNCTION       | RANGE         | ACCURACY  |
|----------------|---------------|-----------|
| Power accuracy | $I > 15\%I_n$ | $\pm 3\%$ |

### 3.3.6.2.4. Notes for testing

Time period of the accumulation is defined by parameter setting.

Starting accumulation is based on the integrated real-time clock of the device.

For example, for a “Time Interval” setting of 15min, the trigger is: at 0h0min, 0h15min, 0h30min, 0h45 min, 1h0min, etc.

Parameter changing resets the accumulation. Using the settings of the example above, setting new parameters at 0h07min will result in the following:


- the accumulated values are reset to zero,
- the new accumulation starts at 0h15min,
- the first report is sent at 0h30min. Measured values in Events list will also refresh at 0h30min.

### 3.3.6.2.5. 61850 LN

Instance number of Logical Node is not mentioned in the table below.

Table 2-6 Logical Node and Data Objects of the metering function

| LN NAME | DO NAME   | DA NAME | FC | EXPLANATION       |
|---------|-----------|---------|----|-------------------|
| EMMTR   | DmdVArhPV | mag.f   | MX | Demand VArh value |
|         |           | q       | MX | quality           |
|         |           | t       | MX | timestamp         |
|         | DmdWhPV   | mag.f   | MX | Demand Wh value   |
|         |           | q       | MX | quality           |
|         |           | t       | MX | timestamp         |
|         | SupVArhPV | mag.f   | MX | Supply VArh value |
|         |           | q       | MX | quality           |
|         |           | t       | MX | timestamp         |
|         | SupWhPV   | mag.f   | MX | Supply Wh value   |
|         |           | q       | MX | quality           |
|         |           | t       | MX | timestamp         |



### 3.3.7. Voltage selection function block

#### 3.3.7.1. Application

In several substation configurations with double busbar, there is no voltage measurement in the bays, but voltage transformers are connected to the busbars only.

If the protection functions configured in the bay devices apply voltage measurement then the correct selection of the voltage sources is needed. The role of the voltage selection is that the protection functions get the voltage of the busbar section to which the feeder or the transformer is connected.

To solve this problem the device gets both three-phase voltages of both busbar sections, and a binary signal decides which one is valid for the protection function.

The “Voltage selection” function block assigns the correct voltages to the protection functions.

#### 3.3.7.2. Mode of operation

The voltage selection is decided by a binary signal. **The conditions are defined by the user applying the graphic equation editor.**

If this input signal is FALSE then the voltages of the voltage input module configured as default input are assigned to the protection functions.

If however this input signal is TRUE then the voltages of the other voltage input module are assigned to the protection functions.

#### 3.3.7.3. The binary status signals

The voltage selection function block has a binary input signal. **The conditions are defined by the user applying the graphic equation editor.**

The **binary input status signal** of the voltage selection function block is shown in Table 1-1.

| Binary status signal    | Title   | Explanation                                     |
|-------------------------|---------|---|
| SelectVolt_USelect_GrO_ | USelect | Binary signal controlling the voltage selection |

Table 1-1 The binary input status signal of the voltage selection function block

The **binary output status signals** of the voltage selection function block.

The voltage selection function block has no binary output status signals.

#### 3.3.7.4. The parameters

The voltage selection function block has no parameters.

### 3.3.7.5. The symbol of the function block in the graphic editor




Figure 1-1 The function block of the voltage selection function block

The name of the input signal is a part of the “Binary status signal” name shown in Table 1-1.

### 3.3.7.6. Example

In this simple example the channel No.1 of the binary input module in position “F” is used as the signal controlling the selection.

If this input signal is FALSE then the voltages of the voltage input module configured as default input are assigned to the protection functions.

If however this input signal is TRUE then the voltages of the other voltage input module are assigned to the protection functions.





Figure 2-1 Example The simple application of the voltage selection function block



## 3.3.8. Trip Value Recorder

### 3.3.8.1. Application

For quick evaluating of network faults, it is very useful to see in the event list of the protection device the measured primary analog values (currents, voltages) before and during the fault state. The Trip value recorder function serves this purpose.

This function is not a default element of any configuration, but it can be acquired (please contact Protecta Support team).

#### 3.3.8.1.1. The measurement

The input values of the EuroProt+ devices are the secondary signals of the voltage transformers and those of the current transformers.

These signals are pre-processed by the “Voltage transformer input” function block and by the “Current transformer input” function block. These function blocks are described in separate documents. The pre-processed values include the Fourier basic harmonic phasors of the voltages and currents and the true RMS values. Additionally, it is in these function blocks that parameters are set concerning the voltage ratio of the primary voltage transformers and current ratio of the current transformers.

Based on the pre-processed analogue signals, several function blocks perform additional calculation, e.g.: active and reactive power, frequency, temperature, impedances, higher harmonics, symmetrical components, etc.

The Trip value recorder function calculates the primary values from its three input secondary signals (currents or voltages) and uses them as described in the following chapter.

#### 3.3.8.1.2. Operation principles

The Trip value recorder has two binary inputs: “Start” and “Trip”.

When the “Start” binary input receives a rising edge signal, the function stores the pre-fault value of the three analogue signals and the fault value of the three analogue signal as well and the function starts waiting for the trigger (Trip) signal. If no trigger signal coming and new start signal receives the stored pre-fault and fault values will be overwritten by the latest ones.

The “Trip” binary input of the function is applied for triggering the trip value recording to generate the events with the pre-fault and fault values.

After triggering the function, so the “Trip” binary input is activated, the function generates the following values in the event list and sends them automatically to the SCADA system:

- pre-fault values of the three analog signals 100 ms before the Start signal receives,
- fault values of the three analog signals: average of the values 10 ms and 20 ms after the Start.




Figure 1-1 Time diagram of the trip recording behaviour

### 3.3.8.2. Trip value recorder function overview

The graphic appearance of the function block of the trip value recorder function is shown below. The block shows all binary input and output status signals which are applicable in the graphic equation editor.

Usually, the collected general start signal of the protection functions is assigned to the “Start” input and the general trip signal of trip logic function is connected to the “Trip” input.




Figure 2-1 Graphic appearance of the function block of the trip value recorder function

### 3.3.8.2.1. Settings

#### 3.3.8.2.1.1. Parameters

The Trip value recorder function does not have any parameters.

### 3.3.8.2.2. Function I/O

This section describes briefly the analogue and digital inputs and outputs of the function block.

#### 3.3.8.2.2.1. Analogue inputs

The function uses the sampled values of a current input or voltage input. Moreover, calculated analogue signals i.e.: symmetrical values, differential/bias current values can be used as inputs.

The following table contains the available input channels of the trip value recorder function.

Table 2-1 Available analogue inputs of the trip value recorder function

| ANALOGUE INPUTS   | RELATED FUNCTION BLOCK |
|---|------------------------|
| Phase current, phase-to-phase, symmetrical, residual currents                         | CT4, CalcCurr          |
| Voltage in phase, phase-to-phase, and symmetrical; Reference (busbar) voltages        | VT4, CalcVolt          |
| Calculated Idiff/Ibias current of transformer differential protection                 | DIF87T                 |
| Calculated Idiff/Ibias current of busbar differential protection for each bus section | DIF87B                 |


**NOTE:** Displaying the fault current values of the line differential protection Idiff/Ibias current and the restricted earth fault protection Idiff/Ibias current are integrated into the protection function, thus not need additional trip value functions to display the trip values.

#### 3.3.8.2.2.2. Binary input signals (graphed output statuses)

The conditions of the binary inputs are defined by the user, applying the graphic equation editor (*Logic Editor*). Parts written in **bold** are seen on the left side function block in the Logic editor.

Table 2-2 The binary input signal of the trip value recorder function

| BINARY OUTPUT SIGNAL | EXPLANATION  |
|----------------------|--|
| TRE_Start_GrO_       | Dedicated input of the function to receive the start signal of the selected protection functions |
| TRE_Trip_GrO_        | Dedicated input of the function to receive the trip signal of the selected protection functions  |



### 3.3.8.2.2.3. Binary output signals (graphed input statuses)

The Trip value recorder function does not have any binary output signals.

### 3.3.8.2.2.4. Online data

No default visible values on the *online data* page.

### 3.3.8.2.2.5. Events

The following events are generated in the event list, as well as sent to the SCADA according to the configuration.

*Table 2-3 Generated events of the trip value recorder function*

| EVENT         | VALUE                          | EXPLANATION                          |
|---------------|--------------------------------|--------------------------------------|
| ... Prefault* | according to the applied input | Prefault value of the applied signal |
| ... Fault*    | according to the applied input | Fault value of the applied signal    |

*\*The event text may vary according to the actual device configuration (.epcs)*



### 3.3.9. RTD temperature input function

#### 3.3.9.1. Application of the RTD input

If the factory configuration includes an RTD temperature input hardware module, the temperature input function block is automatically configured among the software function blocks. Separate temperature input function blocks are assigned to each temperature input hardware module.

The RTD+1100 temperature input hardware module is equipped with four special input channels, the RTD+ 0200 has a single channel only. (See EuroProt+ hardware description document.) To each channel, a temperature sensor can be connected. The temperature is measured as the resistance value of the sensor, which depends upon the temperature.

The sensors can be connected by wiring methods, shown in Figure 1–1, Figure 1–2 and Figure 1–3. The connection mode is identified also by parameter setting.




Figure 1–1 2-wire RTD wiring




Figure 1–2 3-wire RTD wiring

When 3-wire connection is applied, it is supposed that  $R_A=R_D$ .




Figure 1-3 4-wire RTD wiring

The channels of the module is independent of each other. To each channel a dedicated measuring module is assigned. These measuring modules are described in a separate document: “**GGIORTD temperature measurement module function block description**”. The module is prepared to connect the following types of sensors:

- Pt100/Ni100
- Ni120/Ni120US
- Pt250/Ni250
- Pt1000/Ni1000
- Cu10
- Service-Ohm (60  $\Omega$  ... 1.6 k $\Omega$ )

The applied type of sensors define the conversion mode from measured resistance to temperature. These are selected by parameters of the temperature measuring module. See separate document: “**GGIORTD temperature measurement module function block description**”.



### 3.3.9.2. Technical summary

#### 3.3.9.2.1. Technical data

The technical data of the temperature input module are related to the hardware module. This is described in the document “**EuroProt+ Hardware description**, Chapter 10: RTD input module”.

#### 3.3.9.2.2. Summary of the parameters


The parameters of the temperature input function are explained in the following table.

##### Enumerated parameters

| Parameter name               | Title      | Selection range     | Default |
|------------------------------|------------|---------------------|---------|
| Connection mode of Channel 1 |            |                     |         |
| RTD_Ch1RangeOfMAn03_EPar_    | Channel 01 | 3wire, 4wire, 2wire | 3wire   |
| Connection mode of Channel 2 |            |                     |         |
| RTD_Ch2Range2OfMAn03_EPar_   | Channel 02 | 3wire, 4wire, 2wire | 3wire   |
| Connection mode of Channel 3 |            |                     |         |
| RTD_Ch3RangeOfMAn04_EPar_    | Channel 03 | 3wire, 4wire, 2wire | 3wire   |
| Connection mode of Channel 4 |            |                     |         |
| RTD_Ch4Range2OfMAn04_EPar_   | Channel 04 | 3wire, 4wire, 2wire | 3wire   |

*Table 1-1 The enumerated parameters of the voltage input function*

NOTE: The function block has no input and output binary signals, the graphic logic editor does not show this function block.



## 3.4. Disturbance recorder function

The disturbance recorder function can record analog signals and binary status signals. These signals are configured using the EuroCAP software tool.

The disturbance recorder function has a binary input signal, which serves the purpose of starting the function. **The conditions of starting are defined by the user, applying the graphic equation editor.** The disturbance recorder function keeps on recording during the active state of this signal but the total recording time is limited by the timer parameter setting.

The pre-fault time, max recording time and post-fault time can be defined by parameters.

### 3.4.1. Mode of recording

If the triggering conditions defined by the user - using the graphic equation editor – are satisfied and the function is enabled by parameter setting, then the disturbance recorder starts recording the sampled values of configured analog signals and binary signals.

The analog signals can be sampled values (voltages and currents) received via input modules or they can be calculated analog values (such as negative sequence components, etc.)

The number of the configured binary signals for recording is limited to 64, and up to 32 analog channels can be recorded.

The available memory for disturbance records is 12 MB.

*There are two function blocks available.* The first function (**DRE**) applies 20 sampling in a network period. Accordingly for 50 Hz, the sampling frequency is 1 kHz. (For 60 Hz the sampling frequency is 1.2 kHz). This is used in all configurations by default.

The second function (**DRE2**) is capable to be set by parameter to apply 20 or 40 sampling in a network period. This way accordingly for 50 Hz, the sampling frequency is 1 kHz or 2 kHz (and for 60 Hz the sampling frequency is 1.2 kHz or 2.4 kHz). *Except for this, the two function blocks are the same.*

As an example, for 50 Hz, if the duration of the record is 1000 ms then one analog channel needs about 7 kB and a binary channel needs 2 kB, Using the following formula the memory size can be estimated:

$$\text{Memory size of a record} = (n \cdot 7 \text{ kB} + m \cdot 2 \text{ kB}) \cdot \text{record duration (s)}$$


Here n,m: are the number of analog and binary channels respectively.

During the operation of the function, the pre-fault signals are preserved for the time duration as defined by the parameter “PreFault”.

The recording duration is limited by the parameter “Max Recording Time” but if the triggering signal resets earlier, this section is shorter.

The post-fault signals are preserved for the time duration as defined by the parameter “PostFault”.

During or after the running of the recording, the triggering condition must be reset for a new recording procedure to start.



### 3.4.2. Format of recording

The records are stored in standard COMTRADE format.

- The configuration is defined by the file .cfg,
- The data are stored in the file .dat,
- Plain text comments can be written in the file .inf.

### 3.4.3. Downloading and evaluating the disturbance records

The procedure for downloading the records is described in detail in the EuroProt+ manual “Remote user interface description”, Chapter 4.7. The three files are zipped in a file .zip. This procedure assures that the three component files (.cfg, .dat and .inf) are stored in the same location.

The evaluation can be performed using any COMTRADE evaluator software. Protecta offers the “**srEval**” software for this purpose. The application of this software is described in detail in the “srEval manual”. This manual can be downloaded from the following Internet address: [http://www.softreal.hu/product/sreval\\_en.shtml](http://www.softreal.hu/product/sreval_en.shtml).

### 3.4.4. Parameters of the disturbance recorder functions

#### Enumerated parameters

| Parameter name           | Title        | Selection range    | Default  |
|--------------------------|--------------|--------------------|----------|
| Parameter for activation |              |                    |          |
| DRE_Oper_EPar_           | Operation    | Off, On            | Off      |
| DRE_Resolution_EPar_     | Resolution * | 1/1.2kHz, 2/2.4kHz | 1/1.2kHz |

\*only on the optional 2/2.4 kHz disturbance recorder function

*Table 1-1 The enumerated parameters of the disturbance recorder functions*

#### Timer parameters

| Parameter name            | Title              | Unit | Min | Max   | Step | Default |
|---------------------------|--------------------|------|-----|-------|------|---------|
| Pre-fault time:           |                    |      |     |       |      |         |
| DRE_PreFault_TPar_        | PreFault           | msec | 100 | 1000  | 1    | 200     |
| Post-fault time:          |                    |      |     |       |      |         |
| DRE_PostFault_TPar_       | PostFault          | msec | 100 | 1000  | 1    | 200     |
| Overall-fault time limit: |                    |      |     |       |      |         |
| DRE_MaxFault_TPar_        | Max Recording Time | msec | 500 | 10000 | 1    | 1000    |

*Table 1-2 The timer parameters of the disturbance recorder functions*

NOTE: The device goes automatically in “Warning” state and sends a warning message (see [Figure 1-1](#)) if the sum of the pre-fault time and post-fault time is longer than the overall-fault time. The corresponding message in the RDSP log file is: „Wrong DR settings. PreFault + PostFault must be less than MaxFault. Check the parameters.”




Figure 1-1 Warning message if the settings are invalid

### 3.4.5. The input signals of the disturbance recorder functions

#### Binary status signals

The disturbance recorder function has a binary input signal, which serves the purpose of starting the function. **The conditions of starting are defined by the user, applying the graphic equation editor.**

| Binary status signal | Explanation   |
|----------------------|---|
| DRE_Start_GrO_       | Output status of a graphic equation defined by the user to start the disturbance recorder function. |

Table 1-3 The binary input signal of the disturbance recorder functions

The recording is performed if the function is enabled by the parameter setting AND the triggering condition as defined by the user is “True” as well.

### 3.4.6. The function blocks

The two function blocks of the disturbance recorder function is shown in [Figure 1-2](#). The block shows the binary input status signal, which serves the purpose of triggering the record. It is defined by the user in the graphic equation editor.





Figure 1-2 The function blocks of the disturbance recorder functions

### 3.4.7. The recorded signals

The analog and binary signals to be recorded are configured using the EuroCAP software tool in the menu item “Software configuration/Disturbance recorder”. (The access level of the user must be at least “Master”.) The application of this software is described in detail in the EuroCAP manual.



### 3.5. Event recorder

The events of the device and those of the protection functions are recorded with a time stamp of 1 ms time resolution. This information with indication of the generating function can be checked on the touch-screen of the device in the “Events” page, or using an Internet browser of a connected computer

## 4. Maintenance guide for EuroProt+ devices

### 4.1. Foreword

The EuroProt+ devices are designed with the most up-to-date and durable components available, to keep appliances in continuous operation for decades. For this range, the only type of components that can age and lead to equipment failure are the power supply capacitors. Therefore, this document, in addition to suggesting some general steps for planned inspections, contains important information on the inspection of power supply modules.

### 4.2. Safety precautions

The EP+ protection-family, depending on the type, operates at dangerous power supply voltages (220 VDC, 230 VAC, 60 VDC, 48 VDC).



In all cases where the connections of the appliance are to be installed or opened, the work must be carried out by a suitably qualified person.

In all cases, the first step of activity should be to switch off the power



The EuroProt+ protection family has a high operating internal temperature. Operations carried out immediately after operation may lead to dangerous burns.



The hardware and software of the EP+ protection family form a complex system. Setting, modifying, and mounting the individual components may severely affect the operation of the whole system.

In all cases where the device is to be operated or maintained, the activity must be carried out by qualified personnel only



## 4.2.1. General guidelines for a scheduled maintenance of EP+ devices

1. As a first step, it is recommended to send an email attaching a report.zip file to the Protecta Application Department on the email address [application@protecta.hu](mailto:application@protecta.hu). In the report file, the logs contain information that can indicate abnormal operation of a module before it causes an operational fault. Based on this information, Protecta can make recommendations for the replacement or repair of the modules concerned.



The report.zip file can be downloaded from the device's web interface, in the Backup / Report section of the Advanced / Status / Log menu, by pressing the "Get file" button. Attention! The file size should be about 700kB. If the downloaded file size is significantly smaller than this, please try again or contact Protecta's Application Department via our web-based support system (<https://support.protecta.hu/?language=English>)!

2. It is usually recommended to update the firmware of the devices during scheduled maintenance. Information about the new firmware releases can be found in the [Release Notes on the Protecta homepage](#). The information here can be used to consider upgrading the basic software for a single device, or all devices in a substation.



**Before starting the upgrade, always contact the Protecta Application Department or submit a ticket in the web-based support system from the following link: <https://support.protecta.hu/>**

For more details on the firmware update, please refer to Chapter 4.2.10.4 of the [EuroProt+ Operating Manual](#).


### 4.3. Power supply maintenance

Power supplies are designed with the longest possible life electrolytic capacitors. Their expected lifetime depends significantly on the environmental conditions of the device. During a scheduled inspection, we recommend visual inspection of the power supply for any abnormalities in the capacitors. The most common phenomena are: bloating, electrolyte leakage, discoloration, which typically occurs on capacitors, but can also occur on the surface of the PCB board due to leakage. In case of abnormality, the capacitors should be replaced. In such a case, please contact Protecta's Application Department via our support page (<https://support.protecta.hu/>)!

The following figures illustrate the different capacitor states in several photos.



*Figure 4-1 The capacitor on the right is already discolored*



*Figure 4-2 Healthy capacitors on visual inspection*

